



OPERATION & PARTS MANUAL EX-50 Excavator

EX50 Excavator SN: 061612A/F62687F

Publication No. 050182A

Rev. No. 240819, R250731

© Akkerman Inc. 2024, 2025
All Rights Reserved

Introduction

This manual contains important safety, operation, maintenance and parts information for your Akkerman EX-50 Excavator. You must read and understand this manual and any additional equipment manuals before you operate and maintain this equipment. Keep this manual with your EX-50 Excavator at all times. Additional copies of this manual may be purchased from the Akkerman Aftermarket Support Department, or downloaded from the Akkerman web site at www.akkerman.com.

The contractor is responsible for the overall safety program on the job site. Use this manual as a part of the safety program.

The use of second rate parts could affect the efficient performance of the EX-50 Excavator. ALWAYS use genuine Akkerman parts.

Understand safety signal words, DANGER, WARNING, CAUTION, SAFETY INSTRUCTIONS, and NOTICE. When you see these words in this manual or on safety decals mounted on your equipment, follow the safety message to avoid personal injury and/or property damage.


▲ DANGER Indicates an extremely hazardous situation which, if not avoided, WILL result in death or serious injury.

▲ WARNING Indicates a potentially hazardous situation which, if not avoided, COULD result in death or serious injury.

▲ CAUTION Indicates a potentially hazardous situation, which, if not avoided, MAY result in minor or moderate injury. It may also be used to alert against unsafe practices.

SAFETY INSTRUCTIONS Usually consists of individual messages stating procedures or actions that must be followed for the safe operation of a product.

NOTICE Identifies potential property damage and important installation, operator, or maintenance information.



Akkerman EX-50 Excavator

This instruction contains important safety, operation, and maintenance information for your Akkerman EX-50 Excavator. The EX-50 Excavator is used with the Excavator Boring Shield (EBS) to excavate soil in the installation of 100-inch and larger pipe jacking, liner plate and ring-beam and lagging tunnel building applications. The EX-50 is mounted to the interior top of the EBS with a slide mount system. The operator in the operator station uses joysticks to hydraulically control the EX-50's bucket, boom, frame and hoist range of motion.

If you find any errors with this manual or have any suggestions for improvement, please let us know. Email your comments via the Akkerman web site (Contact Us web page), or mail your suggestions to: Akkerman Inc, ATTN: Technical Publications, 58256 266th Street, Brownsdale, MN 55918.

Akkerman Inc. reserves the right to improve its product without notice or obligation.

NOTES

Contents

Safety	1-1	Transporting	7-1
Be Alert For Safety Information	1-1	Transporting Guidelines	7-1
Read Operator's Manual	1-1	Lubricants	8-1
Wear Protective Clothing	1-1	Grease	8-1
Keep First-Aid Kit Accessible	1-1	Storing Lubricants	8-1
Hydraulic Oil/Fluids Under Pressure	1-2	Periodic Maintenance	9-1
Beware Of Suspended Loads	1-2	Lubrication & Maintenance Intervals	9-1
Keep Personnel Away From Moving Parts.....	1-2	Lockout Tagout Power Before Servicing	9-1
Unauthorized Welding	1-2	Before Performing Maintenance	9-2
Regularly Clean And Inspect Equipment.....	1-3	Hydraulic Oil/Fluids Under Pressure	9-2
Inspect Electrical Connections	1-3	Avoid Pinch Points	9-2
Avoid Pinch Points	1-3	Unauthorized Welding	9-2
Stay Away From Crane	1-3	Maintenance Charts	
Practice Safe Maintenance	1-4	Prior To Each Job Launch.....	9-3
Test Tunnel Ventilation	1-4	Daily Or Every 10 Hours Of Operation	9-4
Stored Energy Do Not Use Unsupported	1-5	Completion Of Each Drive	9-5
Keep Away From Belt Conveyor	1-5	As Required	9-6
Avoid Tunnel Wall Contact	1-5	Maintenance Instructions	
Watch For Conveyor	1-5	Prior To Each Job Launch	9-7
Keep Job Site Clean And Organized.....	1-6	Daily Or Every 10 Hours Of Operation	9-12
Slippery When Wet.....	1-6	Completion Of Each Drive.....	9-17
Fire Prevention.....	1-6	As Required	9-18
No Smoking In Shaft Or Tunnel	1-6	Storage	10-1
Lockout Tagout Power Haul Unit.....	1-7	Preparing For Storage	10-1
Keep Riders Off Haul Unit.....	1-7	Removing From Storage	10-1
Avoid Laser Light Exposure	1-7	Troubleshooting	11-1
Recycle Waste	1-7	EX-50 Excavator	11-1
Lockout Tagout Procedure Guideline	1-8	Schematics	
Decals	2-1	Electrical - EX-50 Main Power Box	11-2
Control Console & Main Power Control	2-1	Electrical - EX-50 Control Console.....	11-3
EX-50 Excavator	2-2	Hydraulics - EX-50 Boom.....	11-4
Terminology	3-1	Specifications	12-1
EX-50 Excavator	3-1	EX-50 Excavator	12-1
Hydraulic Valves.....	3-1	Torque Chart	12-2
EX-50 Control Console	3-2	Identification Numbers	13-1
Controls & Instruments	4-1	Safety Data Sheets	14-1
Emergency Stop.....	4-1	Warranty	15-1
Power Phase Indicators	4-2	Parts	16-1
Main Power Disconnect Switch.....	4-3	Introduction	16-2
System Pressure Gauge	4-3	Decals	16-4
Operator Control Console Controls.....	4-4	Parts	16-9
Select Switch.....	4-5	Alphabetical Index	17-1
Auxiliary Flow Switch	4-5	Numerical Index	18-1
Pre-Start Inspection	5-1		
Operation	6-1		
Operating Guidelines	6-1		
Using Emergency Stop	6-3		
Site Planning	6-4		
System Setup.....	6-4		
Connecting Electrical Connections	6-6		
Setting Up Pump Unit & EX-50 Hydraulics	6-7		
Connecting Hydraulic Hose QDs	6-8		
Power Start-Up Procedure	6-9		
Checkout Equipment Prior to Start-Up.....	6-9		
Check Hydraulics After System Setup	6-10		
Launch & Operation Procedure.....	6-11		
Cold Weather Operation.....	6-14		
Daily Shutdown	6-15		

NOTES

Safety

BE ALERT FOR SAFETY INFORMATION

When you see this safety alert symbol on your equipment or in this manual, be alert to the possibility of personal injury or property damage.

Read all safety information.

Keep safety decals clean and in good condition. Replace missing or damaged safety decals.




**ATTENTION!
BECOME ALERT!
YOUR SAFETY IS INVOLVED!**

READ OPERATOR'S MANUAL

⚠ WARNING Unsafe operation or maintenance can cause severe injury or death.

Read and understand the Operator's Manual before operating or servicing this equipment.

Any unauthorized modifications will void the warranty.



WEAR PROTECTIVE CLOTHING


Wear OSHA approved protective clothing, such as hard hat, gloves, safety goggles, earmuffs or ear plugs, face shield, and steel-toed boots, when operating and servicing this equipment.

Wear reasonably close fitting clothing and remove jewelry before working on or near this equipment. This will help prevent the danger of catching them in moving parts or controls.



KEEP FIRST-AID KIT ACCESSIBLE

Keep a first-aid kit handy and properly maintained. Call 9-1-1 for emergencies.



HYDRAULIC OIL/FLUIDS UNDER PRESSURE

⚠ WARNING Escaping oil or other fluids under pressure can penetrate your skin causing serious injury or death.

Release all pressure before performing maintenance or repairs. Never weld near pressurized fluid lines.

DO NOT use your hands to check for leaks. When searching for leaks, use a piece of wood or cardboard.

Contact medical help immediately if any oil or fluid is injected into your skin. A serious infection or reaction can emerge without proper medical treatment.



BEWARE OF SUSPENDED LOADS

⚠ WARNING Suspended loads may fall and cause severe personal injury or death.

If a hydraulic hose from the boom of a crane or excavator breaks, the boom can fall instantly.

Do not enter area under or around a load.



KEEP PERSONNEL AWAY FROM MOVING PARTS


⚠ WARNING Crushing hazard. Keep personnel away from inside of jacking frame. Failure to do so could result in serious personal injury or death.



UNAUTHORIZED WELDING

⚠ WARNING Unauthorized welding can cause structural failure resulting in possible injury or death.


Do not weld on any structural member. Unauthorized welding or repair will void the warranty.



REGULARLY CLEAN AND INSPECT EQUIPMENT

Remove any grease, oil, or debris buildup to avoid potential injury or equipment damage.

Inspect equipment for damage. If damaged, repair or replace immediately.



INSPECT ELECTRICAL CONNECTIONS

⚠ WARNING Regularly inspect electrical connections to be sure they are secure. Failure to do so could cause an explosion if moisture enters an unsecured electrical connection.



AVOID PINCH POINTS

⚠ WARNING Moving parts or the mishandling of parts can cause severe personal injury.

Keep hands away from moving parts.

Watch your fingers, hands, and legs while equipment is in operation.

Handle parts carefully to avoid crushing and pinch point hazards.



STAY AWAY FROM CRANE

⚠ DANGER Stay away from operating crane. If close to power lines, the crane, load, and ground may become electrified resulting in serious injury or death.



PRACTICE SAFE MAINTENANCE

⚠ WARNING Unexpected equipment movement may cause serious personal injury.

LOCKOUT/TAGOUT power before performing any maintenance.


Shut down equipment before making repairs, adjustments, or removing obstructions.

Only trained and qualified personnel should perform any maintenance or repairs.

Keep the area around the equipment clean and dry when performing maintenance.

Do not service the machine while it is in motion.

Replace worn or damaged parts. Remove grease, oil, or debris buildup.



TEST TUNNEL VENTILATION

⚠ WARNING Keep boring head and tunnel well ventilated at all times.

Use an approved air analyzer to detect hazardous gases and oxygen content.



Before and during the shaft operation, test for combustible and toxic gases and oxygen deficiency.

If the levels exceed OSHA prescribed levels, leave tunnel and shaft immediately! Do not activate or deactivate any electrical or hydraulic devices, since any sparks could cause an explosion.

Once ALL personnel are out of tunnel/shaft, cut power from power source.

Gases must be removed before reentering tunnel/shaft.

Do not use haul unit to evacuate the tunnel. The electrical contacts with the unit can cause an explosion.



STORED ENERGY DO NOT USE EX-50 UNSUPPORTED

⚠ DANGER This equipment contains stored energy. Do not remove hoses with EX-50 boom unsupported.

Failure to do so may cause serious injury or death from escaping oil under pressure and a crush hazard from falling boom.



KEEP AWAY FROM BELT CONVEYOR

⚠ DANGER Contact with rotating conveyor belt or idler rollers will cause severe injury or death.

Keep hands, body, and objects clear of rotating conveyor.

Do not operate without covers and guards in place.

Lockout tagout power before servicing belt conveyor.



AVOID TUNNEL WALL CONTACT

⚠ WARNING Contacting tunnel wall and other pipeline obstructions can cause severe personal injury or death.

Keep all body parts on haul unit while unit is moving.



WATCH FOR CONVEYOR

⚠ WARNING Avoid contact with conveyor. Failure to do so could cause severe injury or death.

While moving haul unit into tunnel, avoid hitting the conveyor.



KEEP JOB SITE CLEAN AND ORGANIZED

⚠ WARNING Tripping can cause serious personal injury.

Be sure to keep job site clean and organized.



SLIPPERY WHEN WET

⚠ WARNING Slips and falls can cause serious personal injury.

Ensure firm footing in wet or slippery conditions.

Replace skid-resistant material if it is damaged or missing to prevent slips and falls.

Remove any buildup of grease, oil, or debris.



FIRE PREVENTION

⚠ CAUTION Fires can cause injury or property damage.

Keep equipment clean. Remove all debris from equipment.

Have a fire extinguisher available at all times. Keep the fire extinguisher fully charged.



NO SMOKING IN SHAFT OR TUNNEL

⚠ WARNING Smoking in shaft or tunnel could cause an explosion if combustible gases are present.


Do not smoke in shaft or tunnel.



LOCKOUT TAGOUT POWER BEFORE SERVICING HAUL UNIT

⚠ WARNING Failure to lockout/tagout power before servicing can cause severe personal injury or death.

Disconnect battery harness from contactor harness and remove battery pack from haul unit to LOCKOUT/TAGOUT power before performing any maintenance.



KEEP RIDERS OFF HAUL UNIT

Allow only operator on operating seat when moving haul unit. Keep riders off.

Riders on haul unit can be easily injured by being struck by objects or being thrown off of the equipment. Riders can also obstruct the operator's view resulting in the equipment being operated in an unsafe manner.

A rider may be allowed in an empty dirt bucket (with contractor approval only), to transport personnel from the tunnel opening to the boring head. If allowed, the rider **MUST** be fully inside dirt bucket, including head and all other body parts, to avoid contact with obstructions. Also, rider cannot obstruct the operator's view.




AVOID LASER LIGHT EXPOSURE

⚠ DANGER Staring into laser light will cause severe injury.

Do not stare into laser guidance system light beam. Avoid direct eye exposure.


To avoid possible exposure to radiation in excess of acceptable emission limits, all repairs to laser must be performed by the original manufacturer or an authorized service technician.



RECYCLE WASTE

Follow local, state, federal, and international regulations when recycling or disposing of waste. Waste includes fluids/oil, fuel, filters, coolant, and batteries.

Use leakproof containers when draining fluids/oil. Do not pour waste on the ground, down a drain, or into any water source.




LOCKOUT TAGOUT PROCEDURE GUIDELINE

LOCKOUT TAGOUT power before attempting to make repairs, service or adjustments.

Proper lockout tagout will prevent accidents and save lives. OSHA requires equipment placed in lockout tagout when the unexpected machine start up or release of stored energy could injure workers during cleaning, adjustments, repairing and servicing.

⚠ DANGER Failure to lockout tagout power before adjustments, repairs or servicing **WILL** cause severe personal injury or death.

LOCKOUT TAGOUT power before adjustments, repairs or servicing. Electrical repairs must be performed only by a certified electrician.




The contractor is fully responsible for the safety of all personnel on the job site. Use the following as a guideline for a lockout/tagout procedure. The contractor must determine the best lockout tagout practices for their employees on the job site.

1. Follow all Federal, State and Local safety regulations and procedures.
2. Be sure OSHA prescribed safety personal protective equipment is being worn by all personnel.
3. Be sure the area is safe for operation. Keep work site clean and organized.
4. Set all controls to the OFF or neutral position.
5. Push IN all E-Stop buttons.

6. There are two lockout/tagout options for the EX-50 Excavator and Controls:

- Lockout/tagout the generator (or other external power source), refer to step 7 for details.
- Lockout Tagout the EX-50 Main Power Control Box **AND** the 5200 Pump Unit Main Breaker (or other power support equipment) on the Main Power Panel - refer to step 8 for details.



7. Lockout Tagout the Power Source Option

Lockout/tagout generator (or other external power source). Refer to the power source or generator manufacturer for proper lockout/tagout procedure.



(continued on next page)

8. Lockout Tagout the EX-50 Main Power Control Box **AND** the 5200 Pump Unit Main Breaker (or other power support equipment) on the Main Power Panel Option

• **EX-50 Main Power Control Box Lockout Tagout:**

Be sure the main power disconnect switch (A) on the EX-50 main power control box is in the OFF position. Flip safety latch out on main power disconnect switch and install shackle of OSHA approved lock (B) with tag through latch.



Secure lock by pushing shackle into body of the lock until the shackle is locked into the locking mechanism.

Turn key to lock shackle in place.

Remove key from lock.

Test to be sure shackle is fully secured into lock.

Sign "Equipment Locked Out" tag or equivalent.



• **5200 Pump Unit Main Breaker Lockout Tagout:**


Be sure the main power breaker (C) on the main power electrical panel is in the OFF position. Flip safety latch (D) out on main power breaker and install shackle of OSHA approved lock (E) with tag (F) through latch.

Secure lock by pushing shackle into body of the lock until the shackle is locked into the locking mechanism. Turn key to lock shackle in place.

Remove key from lock.

Test to be sure shackle is fully secured into lock.

Sign "Equipment Locked Out" tag or equivalent.



IMPORTANT: By placing lockout/tagout at the Tunnel Power switch (G) on 5200 Pump Unit, **ONLY** the electrical power (tunnel) from the 5200 to the TBM is locked out. **The hydraulic power from the 5200 to the TBM is still energized and the electrical power on the 5200 is still live.**

To lockout power to the 5200, the 5200 main power breaker MUST be in lockout/tagout. Refer to 5200 Pump Unit Main Breaker Lockout Tagout above.



NOTES


Decals

Keep all decals clean and readable. Use soft cloth, water, and a mild soap to clean the decals if they are too dirty to read. DO NOT clean decals with solvent. Solvent can damage them. Replace safety decals immediately if they are damaged, missing, or hard to read.

Serious injury or property damage can occur if safety instructions are not followed. Contact Akkerman Aftermarket Support for free replacement safety decals.


If a part is replaced that has a safety decal on it, apply a new safety decal to the replacement part. Before applying a new decal, be sure the surface is clean and dry.

CONTROL CONSOLE & MAIN POWER CONTROL BOX




Terminology

EX-50 EXCAVATOR




HYDRAULIC VALVES




- | | |
|-------------------------|---------------------------------|
| 1. Bucket | 9. Hoist & Swing Frame Assembly |
| 2. Bucket Cylinder | 10. Boom Rotation Drive |
| 3. Boom Extension | 11. Boom Extension Cylinder |
| 4. Wear Pads (2) | 12. Wear Pucks (4) |
| 5. Boom Hoist Cylinder | 13. Wear Wedges (2) |
| 6. Slide Frame Assembly | 14. Jacking & Auxiliary Valve |
| 7. Frame Slide Cylinder | 15. EX-50 Valve |
| 8. Boom Swing Cylinder | |

EX-50 CONTROL CONSOLE




LIGHTS	EX50 VALVE
LIGHTS	LOAD SENSE SOLENOID
LIGHTS	GAS DETECTOR
LIGHTS	
E STOP	SEAT CONTROL
SEAT	SCAVENGE PUMP
SCAVENGE PUMP	SCAVENGE PUMP
FLOAT	



14

E-STOP CONTROL BOX ASSEMBLY



EX-50 MAIN POWER CONTROL BOX

1. EX-50 Control Console
2. Operator's Seat
3. E-Stop
4. Boom Extend / Swing Joystick
5. Frame Movement Toggle Switch
6. Select Switch (EX-50/Jacking Can)
7. Boom Rotation Toggle Switch
8. Auxiliary Flow Switch
9. Bucket / Hoist Joystick
10. Seat Assembly Adjuster Lever
11. Arm Rest Adjuster

12. Seat Control
13. E-Stop Seat Cable Connection
14. E-Stop Control Box Assembly (Remote E-Stop)
15. 120V GFI 20 AMP
16. Incoming Power
17. EX-50 Main Power Control Box
18. Phase OK Indicator
19. Phase Error Indicator
20. Main Power Disconnect
21. E-Stop Control Cable Connection (Remote E-Stop)
22. System Pressure Gauge

Controls & Instruments

EMERGENCY STOP

⚠ WARNING ALL Emergency Stop (E-Stop) buttons MUST be tested and operating properly BEFORE operating EX-50 Excavator. Failure to do so may cause severe injury or death.

E-Stop on EX-50 Control Console

Push EX-50 Excavator Control Console E-Stop button (A) IN to stop all electrical and hydraulic functions on the EX-50 Excavator.

E-Stop on E-Stop Control Box Assembly


Push E-Stop Control Box Assembly E-Stop button (B) IN to stop all electrical and hydraulic functions on the EX-50 Excavator.

The E-Stop button will illuminate when it is pulled OUT.


NOTICE All E-Stop buttons [EX-50 Control Console (A) and E-Stop Control Box Assembly (B)] MUST be pulled out to restart operation.

NOTICE The E-Stop Control Box Assembly must be connected to the E-Stop connection (C) on the EX-50 Main Power Control Box. Failure to do so will prevent the electrical and hydraulic systems from functioning.

NOTICE Activating all E-Stop buttons will also extinguish lights powered from the EX-50 Main Power Control Box.



E-Stop on EX-50 Control Console



E-Stop Control Box Assembly

POWER PHASE INDICATORS

⚠ DANGER Hazardous voltage. Disconnect and lockout/tagout power from source before servicing.

⚠ DANGER If high voltage cables or cable connections are damaged, contact with cables/connections may result in electrical shock causing severe injury or death. Disconnect and lockout/tagout power from source before servicing.

⚠ WARNING Any electrical work performed on the EX-50 Main Power Control Box must be performed by a certified electrician.




The input power on the EX-50 Excavator Main Power Control Box is monitored for proper three-phase electrical power. Therefore, the green Phase OK light **MUST** be illuminated before operating equipment.

IMPORTANT: DO NOT start up electric components if the green phase indicator light is not illuminated. Doing so will run components backwards causing damage.

Once the generator (or other external power source) is powered ON and power is connected to the 5200 Pump Unit (or other power support equipment) and turned ON, and connected to the EX-50 Main Power Control Box by tunnel power line, flip the main disconnect switch (A) to the ON position.

If the green Phase OK indicator light (B) on the EX-50 Main Power Control Box is illuminated, this indicates that the external power source phase power is installed correctly and the system is available for use.

If the red Phase Error indicator light (C) is illuminated, flip the main disconnect switch to the OFF position, and lockout/tagout ALL power before attempting to reverse two of the generator power leads on the power circuit.



- A - Main Power Disconnect
- B - Phase Indicator (Green) (Phase OK)
- C - Phase Indicator (Red) (Phase Error)

MAIN POWER DISCONNECT SWITCH

⚠ DANGER Hazardous voltage. Disconnect and lockout/tagout power from source before servicing.

⚠ DANGER If high voltage cables or cable connections are damaged, contact with cables/connections will result in electrical shock causing severe injury or death. Disconnect and lockout/tagout power from source before servicing.


⚠ WARNING Any electrical work performed on the electrical components must be completed by a certified electrician.

NOTICE All Emergency Stop buttons must be pulled out to restart operations.

With the generator (or other external power source) powered ON, connected to the 5200 Pump Unit (or other power support equipment) and turned ON, connected by tunnel power line to the EX-50 Main Power Control Box, flip the main disconnect switch (A) to the ON position.

Check to see that the green Phase OK indicator light (B) is illuminated. This indicates that the external power source phase power is installed correctly and the system is available for use.

DO NOT flip the main disconnect ON if the red Phase Error light (C) is illuminated. The red light indicates that the generator phase power is installed incorrectly. Disconnect and lockout/tagout ALL power before attempting to reverse the two generator power leads.




- A - Main Power Disconnect
- B - Phase Indicator (Green) (Phase OK)
- C - Phase Indicator (Red) (Phase Error)

SYSTEM PRESSURE GAUGE

The EX-50 Excavator is equipped with a system pressure gauge to monitor the EX-50 Excavator system pressure pump.

This system is capable of 3,000 psi.



OPERATOR CONTROL CONSOLE CONTROLS

The EX-50 Excavator is controlled by joysticks and switch controls to remove soil and obstacles at the face of the bore between the boring shield shelves with the boom bucket.

EX-50 Excavator joystick controls:

Left-Hand Joystick (A)





Boom Extend / Swing Joystick
Frame Movement Toggle Switch

Right-Hand Joystick (B)

Bucket / Hoist Joystick
Boom Rotation Toggle Switch

The Operator Control Console joysticks feature operator presense switches. To engage the joystick controls, simultaneously squeeze the operator presense switch lever (C) and move the controls as shown in the diagram below.

The joystick controls are spring, centered, variable control and will return to the neutral position when released.




* The Select Switch allows the operator to choose either the EX-50 or Jacking Can operation controls.

SELECT SWITCH

The Select Switch allows the operator to choose either the EX-50 or Jacking Can operation controls (A).

When the Select Switch is turned to EX-50 (left), the operator can control the EX-50 or auxiliary tooling (using the Auxiliary Flow Switch).

When the Select Switch is turned to Jacking Can (right), the operator can push the right-hand joystick forward (while simultaneously squeezing the operator presence switch lever) in Jack Can Extend mode to hydraulically advance the jacking can cylinders, or pull the right hand-joystick backwards (while simultaneously squeezing the operator presence switch lever) in Jack Can Retract mode to hydraulically retract the jacking can cylinders.




AUXILIARY FLOW SWITCH

The Auxiliary Flow Switch (B) allows the operator to control the flow rate/speed using numerical sections of customer supplied and connected auxiliary tooling.

NOTICE

If using rotary tool/powered accessory and the auxiliary flow switch, be sure the operator's shield is installed. Contact Akkerman Aftermarket Support for more information.



NOTES

Pre-Start Inspection

⚠ WARNING

Do not operate this equipment until you read, study, and understand this manual and any other equipment manuals that may be used. A daily inspection of the equipment must be performed to prevent severe personal injury or death and equipment damage.

The contractor is fully responsible for the safety of all personnel on the job site. Check with the contractor that all site preparation requirements are in place. Be sure to comply with all OSHA regulations, such as: an active safety program is in practice, a confined space permit (if needed) is issued, personal protective equipment is being worn, monitoring of combustible and toxic gases including the depletion of oxygen; flammable, combustible, and hazardous materials are properly stored; and a lockout/tagout procedure is in place (for more information, refer to Safety, section one, Lockout Tagout Procedure Guideline).

Use the following checklist ✓ as a guide for your daily pre-start inspection. Make a copy of this Pre-Start Inspection checklist. Once it is complete, check off, initial and date each item and file the copy as a record of maintenance.

	1. Use "ONE-CALL" notification to check for buried utility lines prior to tunneling.
	2. Check the excavated launch and reception shafts for proper shoring or bracing to prevent slides or cave-ins.
	3. Thoroughly clean equipment of mud and dirt.
	4. Check condition of personal protective equipment. Replace equipment if defective.
	5. Contractor is responsible for all personnel to wear proper protective equipment on the job site.
	6. Remove combustible or flammable materials from equipment. Store materials properly.
	7. Test <u>ALL</u> Emergency Stop (E-Stop) buttons for proper operation at the start of each shift.
	8. Test air monitoring and ventilation detectors for proper operation. Tunnel must be ventilated with fresh air.
	9. Thoroughly inspect all equipment for damage. Repair or replace before operating.
	10. Be sure all covers and guards are in place before operation.
	11. Check for loose or missing hardware. Replace damaged or missing hardware.
	12. Check for worn, loose, or damaged wire connections. Repair or replace wiring.
	13. Tighten loose clamps or fittings.
	14. Check electrical cables for frayed or worn insulation or wiring. Replace damaged or worn harnesses.
	15. Check for fluid leaks. Repair leak or replace components.
	16. Keep job site clean and organized.
	17. Perform all lubrication and maintenance procedures. Refer to Section 9, Periodic Maintenance.
	18. Test each function and control to ensure correct operation.
	19. Check hydraulic hoses and lines for leaks, wear and/or damage. Replace any defective hoses and/or lines.
	20. Be sure the green Phase OK Indicator light is illuminated before starting electrical components.
	21. Check cable for continuity and shorting before each use. Constantly check cables for damage.
	22. Perform pre-start inspection on your equipment. Refer to the equipment operator's manual.
	23. Decals must be clean and legible.

NOTES

Operation

OPERATING GUIDELINES

⚠ WARNING Do not operate this equipment until you read, study, and understand this manual and all other support equipment operation manuals. Failure to do so, could result in severe personal injury or death.

1. Before operating, read and understand the Safety, Pre-Start Inspection, Operation and Maintenance sections.
2. Do not operate this equipment while under the influence of alcohol, drugs, or medication.
3. Follow all Federal, State, and Local safety regulations and procedures.
4. Be sure OSHA prescribed safety protective equipment is being worn by all personnel.
5. Be sure the area is safe for operation. Keep work site clean and orderly.
6. NEVER operate equipment if it has been engulfed with water. Contact your Akkerman Aftermarket Support Representative for proper procedures on how to restore equipment for operation.
7. Have fully charged fire extinguishers on the job site at all times.
8. Be sure the excavated launch and reception shafts are properly shored or braced to prevent slides or cave-ins.
9. Before operation, determine whether the job site has confined spaces. Follow OSHA regulations for proper training required for employees working in and around confined spaces.
10. A fully trained and qualified signal person must direct the crane operator when lifting and lowering equipment into the launch or reception shafts.
11. Never walk or work under any part of the crane and suspended loads.
12. Fresh air must be supplied to all underground work areas in sufficient amounts to prevent any dangerous or harmful accumulation of dusts, fumes, mists, vapor, or gases.
13. Before operating, thoroughly inspect all equipment and repair equipment problems. Check hoses for cuts or bulges. Replace worn or damaged hoses.
14. Before starting equipment, walk completely around all machines and equipment. Let all job site personnel know that you are starting up the equipment. Do not start until all unauthorized personnel are clear of the equipment.
15. Test air monitoring and ventilation detectors for proper operation. Never enter a tunnel without combustible gas detectors and oxygen deficiency detectors.
16. Test all Emergency Stop circuits for proper operation at the start of each shift.
17. Test each control function to make sure they work properly.
18. High pressure hydraulics are used in this EX-50 Excavator. Be sure all covers and guards are in place before operating.
19. Do not make any non-authorized modifications to any Akkerman products. Doing so could cause structural failure and will void the warranty.
(continued on next page)

Operating Guidelines (continued)

20. Check shields and guards. All must be in place and undamaged.
21. Never leave the EX-50 operator's control console without first releasing hydraulic pressure pressing E-Stop, performing daily system shutdown, and disconnecting the main power supply.
22. Conveyors MUST be secured with four safety chains to conveyor brackets in boring shield.
23. Before operating conveyor, all guards and/or safety devices must be in place and operable to prevent any contact with conveyor.
24. Conveyors must not be started until all personnel have been moved away from the conveyors and have been warned that the conveyors are about to start up.
25. The area around conveyor loading and unloading points must be kept clear of obstructions during conveyor operation.
26. Conveyors must be stopped and the power source in lock out, tagout during maintenance, repair, servicing or attempting to remove a jam or overload.
27. While excavator boring shield and conveyors are operating, the operator must remain seated in normal operating position.
28. **The EX-50 Excavator is designed to move spoils in the tunnel to the conveyor. DO NOT use EX-50 Excavator to aid in moving tunneling equipment or other site preparation equipment or parts. Doing so will result in EX-50 Excavator damage.**
29. When operating the EX-50 Excavator, operate slowly and carefully so the excavator does not hit the operator.
30. In hard ground, use the EX-50 Excavator to scrape the soil around the perimeter of the cutting area so the center spoils will drop to the conveyor.
31. In sand soils, the EX-50 excavator is used more for clean up and guiding spoils to the conveyor.
32. The operator must note and report any slow down of machine operating time that might be an early warning of future problems.
33. When installing ring beam and lagging sections, complete sections must be installed to provide proper thrusting of unit. Failure to do so WILL cause jacking/liner can component damage.
34. Do not make adjustments or repairs to any of the system components while in operation or until all pressure is released and electrical power is in lockout/tagout.
35. Check line and grade often to avoid misalignment. Keep excavator boring shield well ventilated to achieve a consistent temperature throughout the pipeline since changes in temperature inside the pipe can cause laser beam to stray off target.
36. After start-up, observe all gauges, controls and warning devices to assure they are functioning properly and their readings are within the operating range.
37. Before performing maintenance, follow the lockout/tagout procedure guideline in one, Safety.
38. Before servicing electrical components, follow the lockout/tagout procedure guideline in section one, Safety.
39. If this manual becomes lost, contact your Akkerman Aftermarket Support representative for a new manual.

USING EMERGENCY STOP

⚠ WARNING ALL Emergency Stop (E-Stop) buttons MUST be tested and operating properly BEFORE operating EX-50 Excavator. Failure to do so may cause severe injury or death.

E-Stop on EX-50 Control Console

Push EX-50 Excavator Control Console E-Stop button (A) IN to stop all electrical and hydraulic functions on the EX-50 Excavator.

E-Stop Control Box Assembly


Push E-Stop Control Box Assembly E-Stop button (B) IN to stop all electrical and hydraulic functions on the auxiliary functions.

The E-Stop button will illuminate when it is pulled OUT.


NOTICE All E-Stop buttons [EX-50 Control Console (A), E-Stop Control Box Assembly (B)] MUST be pulled out to restart operation.

NOTICE The E-Stop Control Box Assembly must be connected to the E-Stop connection (C) on the EX-50 Main Power Control Box. Failure to do so will prevent the electrical and hydraulic systems from functioning.

NOTICE Activating all E-Stop buttons will also extinguish lights powered from the EX-50 main control box.



E-Stop on EX-50 Control Console



E-Stop on E-Stop Control Box Assembly

SITE PLANNING

It is important to carefully review the site and make sure that it is arranged in the most effective manner possible. Here is a list of equipment and site considerations that are typically needed for a EBS project.

Equipment:

- | | | |
|--------------------------------|--------------------|-----------------------------|
| - EBS | - Crane | - Pipe Lubrication Pump |
| - Power Pack (if not On-Board) | - Portable Welders | - Spoil Removal Truck |
| - Skid and Jacking Frame | - Small Generator | - Portable Toilet |
| - Yoke (if needed) | - Fork Lift | - Generator Or Power Source |

Other site considerations:

- | | | |
|--|-------------------------|-------------------------------|
| - Spoil Removal Truck Access | - Pipe Unloading area | - Fresh Water Supply |
| - Launch Shaft Size | - Hose Interconnections | - Electrical Interconnections |
| - Walkways | - Pipe Staging Area | - Jacking Shaft Access Area |
| - Any Traffic or Other Physical Restraints | | |

SYSTEM SETUP

This is a general overview of a system setup. The operation and installation details are determined by the owner and contractor of the project.

1. The contractor is fully responsible for the design and construction of the OSHA required launch and reception shafts. For setup and installation drawings specific to the project, pipe size and shoring type, contact the Akkerman Sales Department.


⚠ WARNING Gases may be present during excavation and could cause severe personal injury or death. Use an approved air analyzer to detect hazardous gases on the job site and in the tunnel at all times.

2. After the soil analysis, shaft layout design, and survey are complete, excavate the launch and reception shafts. Be sure the shafts will be well drained and use proper shoring or bracing in accordance with your local, state, and federal regulations.
3. Construct a shaft floor with a solid base suitable for the weight of the tunneling equipment. Consult your civil and structural engineers for your shaft floor requirements.
4. Place steel plates on the launch shaft floor for supporting the base of all tunneling equipment components.
5. Construct a concrete thrust block designed to withstand the applied load. A structural engineer must be consulted on the design of this block. This block must be square with the line of the tunnel axis and skid/rail assembly.

NOTICE If using a jacking frame, space must be provided for the mounting of the laser behind the jacking frame.

(continued on next page)

ex50opm-050182A



AEM is the original author and publisher of the above illustration



⚠ WARNING

Suspended loads may fall and cause severe injury or death. Do not allow anyone to enter area under or around a suspended load.

NOTICE

Be sure the crane and all lifting equipment is rated to lift load. Remember, you may be able to lift the load in close at ground level, but as the load radius and elevation change, the lifting capacity of the crane or excavator or other lifting equipment decreases.

6. Lower skid or rail system into launch shaft place against the thrust block. Adjust skid or rail system to line and grade. Be sure there is at least 6 inches between the front of the jacking rails and where the launch seal will be located.
7. Check to be sure skid/rail system is making full contact against thrust block structure.
8. Lower jacking system (if used) onto skid/rail system and be sure the frame is properly centered on rails.
9. (External Power Pack if used) Lower power pack on a level, solid foundation an appropriate distance from the edge of the shaft to prevent shaft cave-in.
10. Place the generator (or other external power source) as far away from the launch shaft as possible. This will reduce the noise to the operator and make it easier to communicate with the launch and reception shaft personnel.
11. Lower the stand for the laser guidance system as close to the rear of the jacking shaft as possible without contacting skid/rail system, jacking system (if used), or thrust block. Be sure the guidance system will not be affected by thrust applied to jacking system.

NOTICE

For proper guidance system installation, refer to your laser manufacturer's installation requirements. Be sure laser beam has a clear path to target.

12. Install the launch shaft seal and casing in the front of the launch shaft, if required.
13. Lower excavator boring shield (with conveyor installed, if used) onto the front of the skid/rail system.
14. Lower jacking/liner can (with conveyor installed if used) onto rails. Align jacking/liner can to boring shield four alignment pins. Secure boring shield with proper hardware. The jacking/liner can holes are threaded.
15. Recheck the skid/rail system base frame and alignment. Check machine elevation and make final tunnel calculations.
16. Lower support ring between the excavator boring shield and the thrust block/support structure. This support ring provides a thrust support against the complete diameter of the liner plate ring. It is also used to load/unload the dirt bucket.
17. Set up the excavator boring shield to jacking/liner can hydraulic hoses and electrical connections.

⚠ WARNING

Any electrical work performed on the electrical components must be completed by a certified electrician.

18. Connect generator/power source electric cables to the 5200 pump unit (or other power support equipment), then connect the tunnel power line from the 5200 pump unit to the EX-50 main power control box in the excavator boring shield (refer to Connecting Power Pack Electrical Connections on next page).

NOTICE

If using rotary tool/powerful accessory and the auxiliary flow switch, be sure the operator's shield is installed. Contact Akkerman Aftermarket Support for more information.

19. Ensure the excavator boring shield alignment and grade are steered parallel to the rail system base.
20. Be sure the conveyors are properly installed and secured to the lifting cables (four per conveyor). Adjust the conveyor as needed into the operating position.
21. A proper ventilation system must be installed throughout the tunnel. Fresh air must be supplied to all underground work areas in sufficient amounts to prevent any dangerous or harmful accumulation of dusts, fumes, mists, vapor, or gases.

CONNECTING ELECTRICAL CONNECTIONS

⚠ DANGER Hazardous voltage.
This system is powered by high voltage electricity.

Failure to lockout/tagout power before connecting power leads will cause severe personal injury or death.

Lockout/tagout main power supply before connecting power leads or servicing. **ONLY** a qualified and trained technician can operate this equipment. Electrical connections or repairs must be performed only by a certified electrician.



MAIN POWER FROM GENERATOR

1. With properly grounded generator (or other external power source), connect generator power cable to the 5200 pump unit (or other power support equipment), then connect tunnel power line to the EX-50 Main Power Control Box.

5200 Recommended Power Requirements

- Recommended Operating Power:
..... 275kW / 340kVA @ 480VAC
- Generator Minimum Motor Starting kVA (skVA):
..... 385skVA with less than 35% instantaneous voltage dip and greater than 90% sustained voltage

2. Proceed to Setting Up Pump Unit & EX-50 Supply/Return Hydraulics in this section.



SETTING UP PUMP UNIT & EX-50 SUPPLY/RETURN HYDRAULICS

There are two hydraulic supply/return options available for setting up the 5200 Pump Unit with the EX-50; single and dual feed supply lines. Single feed supplies 60 gpm of low-pressure oil to the EX-50, steering, and conveyor. Dual feed supplies up to an additional 60 gpm of low-pressure oil (for a total of 120 gpm) using the Boring Head 2 motor. Typically, the Boring Head 1 supply will run the EX-50 and steering. Boring Head 2 supply primarily powers the conveyor, though it can power the conveyor and provide additional power to the EX-50.


⚠ WARNING Escaping oil or other fluids under pressure can penetrate your skin causing serious injury. Contact medical help immediately if any oil or fluid is injected into your skin. Before hooking up the supply hoses to the pump unit ALWAYS use gloves before connecting or disconnecting hydraulic oil hoses/lines.

IMPORTANT: If switching from single feed to dual feed during drive, BEFORE connecting/disconnecting hoses, the boring head motors must be shut off.

Single Feed Hydraulics (60 GPM Minimum)

1. Connect return line quick coupler hose (A or B) to the EX-50 return line quick coupler. Cap other return line quick coupler hose. The pump unit return lines are common, thus either return line hose can be used.
2. Connect Boring Head 1 supply quick coupler hose (C) to the EX-50 supply quick coupler hose. Cap 5200 Pump Unit Boring Head 2 supply quick coupler hose (D) for single feed option.

NOTICE Boring Head 2 motor system can be used in place of the Boring Head 1 system. The Boring Head 1 and 2 motor systems are identical 100 HP hydraulic systems. It is critical to use the system that is connected to the TBM pressure and return lines.




(continued on next page)

Setting Up Pump Unit & EX-50 Supply/Return Hydraulics (continued)

Dual Feed Hydraulics (120 GPM Maximum)

1. Connect return line quick coupler hoses (A and B) to the EX-50 return line quick coupler hoses.
2. Connect Boring Head 1 supply quick coupler hose (C) to the EX-50 supply quick coupler hose.
3. Connect Boring Head 2 supply quick coupler hose (D) to the other EX-50 supply quick coupler hose.



POWER START-UP PROCEDURE

Once proper connection of the generator (or other external power source), to the 5200 Pump Unit (or other power support equipment), to the EX-50 Main Power Control Box, the power can be started as follows:

1. With E-Stop buttons pulled out, power on generator (or other external power source), and 5200 Pump Unit (or other power support equipment), and connect tunnel power line to the EX-50 Main Power Control Box.
2. Flip the main power disconnect switch (A) to the ON position.


If the green Phase OK indicator light (B) on the EX-50 Main Power Control Box is illuminated, this indicates that the external power source phase power is installed correctly and the system EX-50 Main Power Control Box can be turned on.

If the red Phase Error indicator light (C) is illuminated, the external power source is installed incorrectly. Lockout/tagout all power before disconnecting tunnel power line.

Have a certified electrician reverse the two generator electrical phase conductors on the power circuit and recheck phase power.


IMPORTANT: DO NOT start up electric components if the green phase indicator light is not illuminated. Doing so will run components backwards causing damage.

4. Proceed to Checkout Equipment Prior to Start-Up.



CHECKOUT EQUIPMENT PRIOR TO START-UP

1. Grease components as shown in Maintenance section.
2. Inspect conveyor lift cables daily and replace immediately at the first sign of wear.
3. Inspect all hoses and electrical lines for damage. Replace before operating.
4. Be sure all hydraulic hoses and electrical lines are properly installed.
5. Refer to all support equipment operation manuals for pre-start checks.
6. Proceed to Check Hydraulics After System Start-Up.



CHECK HYDRAULICS AFTER SYSTEM START-UP

⚠ WARNING Escaping oil or other fluids under pressure can penetrate your skin causing serious injury or death.

Release all pressure before performing maintenance or repairs, Never weld near pressurized fluid lines.


DO NOT use your hands to check for leaks. When searching for leaks, use a piece of wood or cardboard.

Contact medical help immediately if any oil or fluid is injected into your skin. A serious infection or reaction can emerge without proper medical treatment.

1. If equipped, check all return filter indicators.
2. Check hydraulic components and hoses for leaks. Repair or replace as needed.
3. Check the 5200 Pump Unit (or other power support equipment) hydraulic oil level gauge in hydraulic oil reservoir.

Fill reservoir with clean, fresh, **FILTERED** hydraulic oil to full mark on gauge. Filling reservoir with unfiltered oil will cause component damage. Do not mix oil manufacturers or grades.

4. Check the EX-50 Excavator pressure gauge for proper hydraulic operation and system pressure. The EX-50 System Pressure Gauge is capable of 3,000 psi.
5. Proceed to Launch & Operation Procedure in this section.



LAUNCH & OPERATION PROCEDURE

NOTICE

Be sure that Connecting Electrical Connections, Power Start-Up Procedure, and Check Hydraulics After System Start-Up have been properly performed prior to performing the Launch & Operation Procedure.

⚠ WARNING


Hearing protection **MUST** be worn by operator while EX-50 Excavator is in operation.

⚠ WARNING

Any electrical work performed on the electrical components must be completed by a certified electrician.


⚠ DANGER

Staring into laser light will cause severe injury. Do not stare into laser guidance system light beam. Avoid direct eye exposure.



This is a general overview of a launch and operation procedure for a ring beam and lagging tunneling project. The actual project may vary. The operation and installation details are determined by the owner and contractor of the project.

1. Set laser guidance system to grade and alignment (A). Be sure the laser beam can be easily seen on the excavator boring shield target bar (B) from the operator's EX-50 control console. Adjust the conveyor as needed.
2. Retract jacking cylinders using jacking control.
3. Assemble the ring beam and lagging section in jacking can.
4. Once the ring beam and lagging section is assembled in the jacking can of the excavator boring shield, turn Select Switch on the EX-50 control console to Jacking Can.
5. In Jacking Can mode, use the right-hand joystick (while simultaneously squeezing the operator presence switch lever) and push it forward to Jack Can Extend to hydraulically extend the Jacking Can cylinders. This applies pressure to the ring beam and lagging section which applies pressure to the thrust block or other support structure, and advances the excavator boring shield forward.




Launch & Operation Procedure (continued)

6. Lower the dirt bucket into position behind the conveyor; do not install the haul unit at this time.

⚠ WARNING Avoid contact with conveyor. Failure to do so could cause severe injury or death. While moving haul unit into tunnel, avoid hitting the conveyor.

7. Operate the conveyor and adjust the conveyor speed as needed.
8. Turn the Select Switch to EX-50.
9. Use the EX-50 Excavator joysticks and toggles to control the EX-50 movements and functions to load spoils onto the conveyor.

- In sand soils, the EX-50 excavator is used for clean up and guiding spoils to the conveyor.
- In hard ground, use the EX-50 to excavate around the perimeter of the cutting area so the center spoils will drop to the conveyor.
- In hard or cobble laden soil, operate the auxiliary tooling attachment using the Auxiliary Flow Switch speed control and joysticks. Auxiliary tooling will require additional flow/supply.



NOTICE If using rotary tool/powered accessory and the auxiliary flow switch, be sure the operator's shield is installed. Contact Akkerman Aftermarket Support for more information.

10. When the jacking cylinders are completely extended, retract the cylinders by turning the Select Switch to Jacking Can. Use the right-hand joystick (while simultaneously squeezing the operator presense switch lever) and pull it backward to Jack Can Retract mode to hydraulically retract the Jacking Can cylinders to allows spacing to assemble the next ring beam and lagging section.
11. Check and adjust grade and alignment often, making only minor adjustments.
12. Continue assembling ring beam and lagging sections until the excavator boring shield has been advanced forward enough to lower haul unit into excavator boring shield.




(continued on next page)

Launch & Operation Procedure (continued)

13. Remove dirt bucket from behind the conveyor.
14. Press E-Stop button IN (A) to shut down excavator boring shield power.
15. Perform lockout/tagout procedure on generator, (or other power source), 5200 pump unit (or other power support equipment) and EX-50 Main Power Control Box.
16. Install the first haul unit track section. Refer to your Haul Unit Operator's Manual for track installation. Sections of track will need to be added as new ring beam and lagging sections are assembled.
17. Lower haul unit onto the track. Refer to your Haul Unit Operator's Manual for haul unit installation.
18. Lower dirt bucket into place on haul unit. Move the haul unit into the tunnel until the dirt bucket is underneath conveyor.



⚠ WARNING Avoid contact with conveyor. Failure to do so could cause severe injury or death. While moving haul unit into tunnel, avoid hitting the conveyor.



19. Perform Power Start-Up Procedure (refer to Power Start-Up Procedure in this section).
20. Unload the dirt bucket once it is full by moving it to the unloading/loading zone in the launch shaft with the haul unit.
21. Recheck laser guidance system accuracy often, with and without forward thrust applied to avoid making improper steering corrections.
22. Continue to install additional ring beam and lagging sections, add power cable and ventilation system as needed until the tunnel is complete.



COLD WEATHER OPERATION

Freezing temperatures during the tunneling process, creates the necessity to prepare the site and equipment for the cold weather. Failure to do so will cause damage to components and supporting equipment.

There are various methods of keeping equipment from freezing:





- Tent working areas with a heating system when possible.
- When working with water, it needs to be constantly circulated to prevent freezing. Otherwise the equipment must be drained and/or treated with a RV anti-freeze solution to prevent freezing.
- If bentonite pump and/or water cooling pumps will be shut off for a considerable length of time and the temperature is at or below freezing, the fluids must be drained or treated with RV anti-freeze. Refer to pump manufacturer for more information.
- Water tanks must be drained or treated with RV anti-freeze.
- Drain hoses to prevent freezing and keep low areas properly drained to prevent freezing damage.
- For diesel engines, use a diesel conditioner as well as a non-gelling winter fuel.
- For all equipment, use proper lubricant based on ambient temperature to prevent damage.
- Use compressed air to purge a system of water. Be sure the discharge valve is open before doing so.
- Install heaters for hydraulic systems.
- A spoil (muck) dump needs to be located carefully since the wet loose material will freeze forming a pointed pile instead of a mound.

If systems were shut down for freezing weather, be sure to start systems slowly and let them run for at least five minutes to allow for warm up and in the case of a pump, to displace any surface ice that may have accumulated in the fluid before going back to full operation mode.

Remember it is also critical to keep the work site safe and employees comfortable during the freezing weather. Good training, supervision, proper clothing and limiting personal exposure to the weather is essential for keeping personnel and equipment safe on the job site.

DAILY SHUTDOWN

1. Lower EX-50 Excavator Boom completely until the Boom Bucket rests on the bottom of the excavator boring shield.
2. Push IN E-Stop button (A) on EX-50 control console or E-Stop Control Box Assembly to shut down EX-50 power.
3. Flip the EX-50 Main Power Control Box main disconnect switch to the OFF position (C).
4. Perform lockout/tagout on the EX-50 Main Power Control Box (D).
5. Push IN the E-Stop button on the 5200 Pump Unit (or other power support equipment) to shutdown power.
6. Flip the 5200 Pump Unit (or other power support equipment) main power disconnect switch to the OFF position.
7. Perform lockout/tagout on the generator (or other external power source).
8. Perform a visual machine inspection by checking the fluid levels, hydraulic hose and power cable wear or damage and any machine damage. Make repairs before operating. Also check to be sure all connections are properly connected and secured.



NOTES

Transporting

TRANSPORTING GUIDELINES



⚠ WARNING Suspended load may fall and cause severe personal injury or death.

Do not enter area under or around a load.

1. Know the local, state, and federal transportation regulations.
2. Obtain required permits for transporting.
3. Remove any obstacles from the trailer floor.
4. Clean debris from equipment.
5. Load and unload on level ground.
6. If lifting equipment with a hoist or other lifting device, the equipment lifting eyes and sling must be inspected for damage before lifting. If damaged, replace before lifting.
7. Ensure EX-50 boom is secured on stand and by chain to the frame lift eye.
8. Securely fasten equipment to trailer floor.
9. Secure all loose items in boring shield and jacking/liner can.
10. Be sure available cradles and supports are in place prior to shipping.
11. Observe the lifting instructions for other tunneling equipment.



NOTES

Lubricants

NOTICE

Use of inferior lubricants can affect the efficient performance of your excavator boring shield. Always use high quality lubricants as specified in this section.


Refer to the Periodic Maintenance section for proper lubrication quantity, maintenance intervals, and procedures.

GREASE

The lubrication points are greased with Mobilgrease® XHP222 Premium Lubricating Grease.

The XHP222 grease is a multi-purpose, high performance, high temperature, lithium grease.

Use Mobilgrease® XHP222 Premium Lubricating Grease or equivalent when lubricating the lubrication points.



STORING LUBRICANTS

Your equipment can operate at maximum performance only if clean lubricants are used. Use clean containers to handle all lubricants.

Lubricants should be stored in an area protected from dust, moisture, and other contaminants.

Store barrels inside whenever possible or at least under cover. Keep barrel bungs tight.

If barrels must be stored outside, lay barrels on their sides. If barrels cannot be laid on their sides, tilt them slightly so water or other contaminants cannot be drawn in around the bung.



NOTES

Periodic Maintenance


⚠ WARNING Review the Safety section in this manual and read, study, and understand this manual and all other support equipment operation manuals before performing maintenance. Failure to do so, could cause severe injury or death.

Maintenance and repairs must only be performed by a qualified service technician.

LUBRICATION & MAINTENANCE INTERVALS

The requirements for lubrication and maintenance are shown on the maintenance charts in this section.

Intervals of maintenance are based on normal operating conditions. If operating under more difficult conditions, use a shorter time interval between maintenance.



LOCKOUT TAGOUT POWER BEFORE SERVICING

⚠ WARNING Severe personal injury or death can result from unexpected pump unit start-up or machine movement.

LOCKOUT, TAGOUT power before attempting to make repairs or adjustments to this equipment, unless otherwise indicated. Proper lockout will prevent accidents and save lives. Performing the lockout will also prevent the equipment from moving or operating unexpectedly.

Refer to the Safety, section one, for the Lockout Tagout Procedure Guidelines.



BEFORE PERFORMING MAINTENANCE

1. Perform daily shutdown procedure. Refer to Daily Shutdown in the Operation section.
2. Relieve hydraulic pressure.
3. Push in all E-Stop buttons.
4. Do not work on hydraulic system if oil temperature exceeds 150° F (66° C).
5. **Lockout/tagout all power. Refer to the Safety Section II. for the Lockout Tagout Procedure Guidelines.**

HYDRAULIC OIL/FLUIDS UNDER PRESSURE

⚠ WARNING Escaping oil or other fluids under pressure can penetrate your skin causing serious injury or death.

Release all pressure before performing maintenance or repairs. Never weld near pressurized fluid lines.

DO NOT use your hands to check for leaks. When searching for leaks, use a piece of wood or cardboard.

Contact medical help immediately if any oil or fluid is injected into your skin. A serious infection or reaction can emerge without proper medical treatment.



AVOID PINCH POINTS

⚠ WARNING Moving parts or the mishandling of parts can cause severe personal injury.

Keep hands away from moving parts.

Watch your fingers, hands, and legs while equipment is in operation.


Handle parts carefully to avoid crushing and pinch point hazards.



UNAUTHORIZED WELDING


⚠ WARNING Unauthorized welding can cause structural failure resulting in possible injury or death.

Do not weld on any structural member. Unauthorized welding or repair will void the warranty.



MAINTENANCE CHARTS

Use the item number in the chart to refer to the detailed maintenance procedures later in this section.




PRIOR TO EACH JOB LAUNCH

ITEM	COMPONENT	SERVICE	REQUIREMENT	MATERIAL
1.	E-Stop	Check Operation	E-Stop Main Power & Control Box.	
2.	Structures	Inspect for Cracks/Wear	If damaged, repair prior to use.	
3.	Lift Eye	Inspect	If damaged, repair or replace prior to use.	
4.	Elect/Hyd Connect	Check	Connections must be secured.	
5.	Controls	Check Operation		
6.	Gauges	Check Operation		
7.	Phase Power	Check		
8.	Frame, Swing, Hoist, Telescopic, & Bucket Cylinders	Lubricate	Lubricate until grease is forced out.	Mobil XHP222
*9.	Decals	Inspect	Must be legible. Replace as needed.	
*10.	Supporting Equip.	Perform Maintenance	Refer to your machine's maintenance manual.	
11.	Swing Bearing	Lubricate	Lubricate until grease is forced out.	Mobil XHP222
**12.	Swing Bearing	Inspect Hardware	Visually inspect hardware.	
13.	Drive Chain	Lubricate		Lt. Wt. Motor Oil
14.	Thrust Washers	Inspect	If damaged, repair or replace prior to use.	
15.	Cleanout Cover	Clean out	Remove cover, clean out debris.	
16.	Bucket Fittings	Lubricate (2 places)	Lubricate until grease is forced out.	Mobil XHP222

* Not shown.

**If hardware is worn or damaged, replace with new, tighten 1/2 inch bolts to 79.8 ft-lbs lubed torque. Do not over tighten.

Maintenance Charts (continued)




DAILY OR EVERY 10 HOURS OF OPERATION

ITEM	COMPONENT	SERVICE	REQUIREMENT	MATERIAL
17.	E-Stop	Check Operation	E-Stop Main Power & Control Box.	
18.	Structures	Inspect for Cracks/Wear	If damaged, repair prior to use.	
19.	Elect/Hyd Connect	Check	Connections must be secured.	
20.	Controls	Check Operation		
21.	Gauges	Check Operation		
22.	Phase Power	Check		
23.	Frame, Swing, Hoist, Telescopic, & Bucket Cylinders	Lubricate	Lubricate until grease is forced out.	Mobil XHP222
*24.	Decals	Inspect	Must be legible. Replace as needed.	
*25.	Supporting Equip.	Perform Maintenance	Refer to your machine's maintenance manual.	
26.	Swing Bearing	Lubricate	Lubricate until grease is forced out.	Mobil XHP222
**27.	Swing Bearing	Inspect Hardware	Visually inspect hardware.	
28.	Drive Chain	Lubricate		Lt. Wt. Motor Oil
29.	Thrust Washers	Inspect	If damaged, repair or replace prior to use.	
30.	Cleanout Cover	Clean out	Remove cover, clean out debris.	
31.	Bucket Fittings	Lubricate (2 places)	Lubricate until grease is forced out.	Mobil XHP222

* Not shown.

**If hardware is worn or damaged, replace with new, tighten 1/2 inch bolts to 79.8 ft-lbs lubed torque. Do not over tighten.


Maintenance Charts (continued)



COMPLETION OF EACH DRIVE

ITEM	COMPONENT	SERVICE	REQUIREMENT	MATERIAL
32.	Lift Eye	Inspect	Repair if damaged before lifting.	
33.	Hoses/Pwr. Cables	Inspect	Replace if damaged before operating.	
34.	Structures	Inspect	If damaged, repair or replace.	

Maintenance Charts (continued)



AS REQUIRED

ITEM	COMPONENT	SERVICE	REQUIREMENT	MATERIAL
35.	Top & Side Wear Pads & Pucks	Inspect (2 & 4 places)	If damaged, replace prior to use.	
36.	Drive Chain	Check Tension & Lubricate	Adjust to 1/4 inch deflection.	Lt. Wt. Motor Oil
37.	Side Wear Pucks (4)	Chatter/Vibration	Adjust shims for clearance.	
38.	Adjuster Wedges (2)	Chatter/Vibration	Adjust screw for clearance.	

PRIOR TO EACH JOB LAUNCH


1. CHECK EMERGENCY STOP OPERATION

⚠ WARNING Emergency Stop (E-Stop) buttons MUST function properly BEFORE operating. Failure to do so may cause severe injury or death.


Check E-Stop buttons (A and B) for proper operation. When pushed in, the E-Stop must stop hydraulic and electrical power. Be sure to check the function of both E-Stop buttons, on the control console and control box assembly.

The button will function as follows:

- STOP - Push button IN
- Power for Start Circuit - Pull button OUT



EX-50 Control Console E-Stop (A)



E-Stop Control Box Assembly/Remote E-Stop (B)

2. INSPECT STRUCTURES

Perform a visual inspection of the EX-50 excavator, boring shield and all other system components for cracks, wear or other damage. Repair or replace BEFORE operation.


Check for oil leaks and debris buildup. Make repairs as needed and remove debris.

Check for loose, damaged or missing parts. Repair or replace any defective parts as necessary.



3. INSPECT LIFTING EYES

Inspect lifting eyes (C) for wear or damage. Worn or damaged lifting eyes MUST be replaced before lifting.




(continued on next page)

Prior To Each Job Launch (continued)

4. CHECK ELECTRIC/HYDRAULIC CONNECTIONS

⚠ DANGER If high voltage cables or cable connections are frayed, worn or damaged, contact with cables/connections will result in electrical shock causing severe injury or death.


With power in lockout tagout, check EX-50 Main Power Control Box cable connections for fraying, wear or damage. If damaged, the cables must be replaced **BEFORE** operation. Be sure connections are secure.



5. CHECK CONTROL OPERATIONS

⚠ WARNING **BEFORE** checking control operations, be sure all personnel are away from machine. Unexpected movement may cause severe injury or death.

Check all controls for proper operation. If controls do not function properly, repair or replace **BEFORE** operation.



6. CHECK GAUGE OPERATION

Check system pressures for proper operation. If systems are not functioning properly, repair or replace system components **BEFORE** operation.

Check pressure gauges for proper hydraulic operation.



(continued on next page)


Prior To Each Job Launch (continued)

7. CHECK PHASE POWER

The input power on the EX-50 Excavator Main Power Control Box is monitored for proper three-phase electrical power. Therefore, the green Phase OK indicator **MUST** be illuminated before operating equipment.

IMPORTANT: DO NOT start up electric components if the green phase indicator light is not illuminated. Doing so will run components backwards causing damage.


If the green Phase OK indicator light (A) on the EX-50 Main Power Control Box is illuminated, this indicates that the external power source phase power is installed correctly and the system is available for use.



If the red Phase Error indicator light (B) is illuminated, this indicates that the external power source is installed incorrectly. Lockout, tagout all power before disconnecting power lead cables. Have a certified electrician reverse the two generator electrical phase conductors on the power circuit and recheck phase power.

8. LUBRICATE EX-50 FRAME LUBRICATION POINTS

Lubricate EX-50 frame, swing, and hoist, telescopic and bucket cylinders with Mobilegrease® XHP222 or equivalent until grease is forced out.



(continued on next page)

Prior To Each Job Launch (continued)


9. INSPECT DECALS

Inspect ALL decals, operational and safety decals to be sure they are clean and readable.

Use soft cloth, water and mild soap to clean the decals if they are too dirty to read. DO NOT clean safety decals with solvent. Solvent will damage decals. Replace decals immediately if they are damaged, missing, or hard to read.


Before applying a new decal, be sure the surface is clean and dry.

Contact Akkerman Aftermarket Support for free replacement safety decals.




10. PERFORM MAINTENANCE ON ALL SUPPORTING EQUIPMENT

Be sure ALL supporting equipment such as the haul unit, jacking frame, and generator are properly operating and maintained. Be sure to repair or replace equipment before operation. Refer to the operation and maintenance manuals of all supporting equipment.




11. LUBRICATE SWING BEARING

Lubricate EX-50 swing bearing (A) with Mobilegrease® XHP222 or equivalent until grease is forced out.



12. INSPECT SWING BEARING HARDWARE

Visually inspect swing bearing (B) hardware for damage. If damaged, or missing, replace with new.




(continued on next page)

Prior To Each Job Launch (continued)

13. LUBRICATE DRIVE CHAIN


Thoroughly lubricate drive chain (A) with a high quality chain lubricant.

Replace drive chain guard before operating.




14. INSPECT THRUST WASHERS

Visually inspect thrust washers (B) (under rotary boom chain guard) for damage. If damaged, or missing, replace with new.




15. CLEAN OUT CLEANOUT COVER

Remove cleanout cover (C), and clean out debris. Be sure to replace cover when complete.



16. LUBRICATE BUCKET FITTINGS

Lubricate bucket fittings (D) (2 places) with Mobilegrease® XHP222 or equivalent until grease is forced out.



(continued on next page)

DAILY OR EVERY 10 HOURS OF OPERATION


17. CHECK EMERGENCY STOP OPERATION

⚠ WARNING Emergency Stop (E-Stop) buttons MUST function properly BEFORE operating. Failure to do so may cause severe injury or death.


Check E-Stop buttons (A and B) for proper operation. When pushed in, the E-Stop must stop hydraulic and electrical power. Be sure to check the function of both E-Stop buttons, on the control console and control box assembly.

The button will function as follows:

- STOP - Push button IN
- Power for Start Circuit - Pull button OUT



EX-50 Control Console E-Stop (A)



E-Stop Control Box Assembly/Remote E-Stop (B)

18. INSPECT STRUCTURES

Perform a visual inspection of the EX-50 excavator, boring shield and all other system components for cracks, wear or other damage. Repair or replace BEFORE operation.

Check for oil leaks and debris buildup. Make repairs as needed and remove debris.

Check for loose, damaged or missing parts. Repair or replace any defective parts as necessary.




19. CHECK ELECTRIC/HYDRAULIC CONNECTIONS

⚠ DANGER If high voltage cables or cable connections are frayed, worn or damaged, contact with cables/connections will result in electrical shock causing severe injury or death.

With power in lockout/tagout, check EX-50 Main Power Control Box cable connections for fraying, wear or damage. If damaged, the cables must be replaced BEFORE operation. Be sure connections are secure.


(continued on next page)



Daily Or Every 10 Hours Of Operation (continued)

20. CHECK CONTROL OPERATIONS

⚠ WARNING BEFORE checking control operations, be sure all personnel are away from machine. Unexpected movement may cause severe injury or death.



Check all controls for proper operation. If controls do not function properly, repair or replace BEFORE operation.

21. CHECK GAUGE OPERATION

Check system pressures for proper operation. If systems are not functioning properly, repair or replace system components BEFORE operation.




Check pressure gauges for proper hydraulic operation.

22. CHECK PHASE POWER

The input power on the EX-50 Excavator Main Power Control Box is monitored for proper three-phase electrical power. Therefore, the green Phase OK indicator **MUST** be illuminated before operating equipment.

IMPORTANT: DO NOT start up electric components if the green phase indicator light is not illuminated. Doing so will run components backwards causing damage.

If the green Phase OK indicator light (A) on the EX-50 Main Power Control Box is illuminated, this indicates that the external power source phase power is installed correctly and the system is available for use.




If the red Phase Error indicator light (B) is illuminated, this indicates that the external power source is installed incorrectly. Lockout, tagout all power before disconnecting power lead cables. Have a certified electrician reverse the two generator electrical phase conductors on the power circuit and recheck phase power.

(continued on next page)

Daily Or Every 10 Hours Of Operation (continued)

23. LUBRICATE EX-50 FRAME LUBRICATION POINTS

Lubricate EX-50 frame, swing, and hoist, telescopic and bucket cylinders with Mobilegrease® XHP222 or equivalent until grease is forced out.




24. INSPECT DECALS

Inspect ALL decals, operational and safety decals to be sure they are clean and readable.

Use soft cloth, water and mild soap to clean the decals if they are too dirty to read. DO NOT clean safety decals with solvent. Solvent will damage decals. Replace decals immediately if they are damaged, missing, or hard to read.


Before applying a new decal, be sure the surface is clean and dry.

Contact Akkerman Aftermarket Support for free replacement safety decals.



25. PERFORM MAINTENANCE ON ALL SUPPORTING EQUIPMENT

Be sure ALL supporting equipment such as the haul unit, jacking frame, and generator are properly operating and maintained. Be sure to repair or replace equipment before operation. Refer to the operation and maintenance manuals of all supporting equipment.




(continued on next page)

Daily Or Every 10 Hours Of Operation (continued)


26. LUBRICATE SWING BEARING

Lubricate EX-50 swing bearing (A) with Mobilegrease® XHP222 or equivalent until grease is forced out.



27. INSPECT SWING BEARING HARDWARE


Visually inspect swing bearing (B) hardware for damage. If damaged, or missing, replace with new.



28. LUBRICATE DRIVE CHAIN


Thoroughly lubricate drive chain (C) with a high quality chain lubricant.

Replace drive chain guard before operating.



29. INSPECT THRUST WASHERS

Visually inspect thrust washers (D) (under rotary boom chain guard) for damage. If damaged, or missing, replace with new.




(continued on next page)

Daily Or Every 10 Hours Of Operation (continued)


30. CLEAN OUT CLEANOUT COVER

Remove cleanout cover (A), and clean out debris. Be sure to replace cover when complete.



31. LUBRICATE BUCKET FITTINGS


Lubricate bucket fittings (B) (2 places) with Mobilegrease® XHP222 or equivalent until grease is forced out.



COMPLETION OF EACH DRIVE

32. INSPECT LIFTING EYES

Inspect lifting eyes (C) for wear or damage. Worn or damaged lifting eyes **MUST** be replaced before lifting.




33. INSPECT HYDRAULIC HOSES & POWER CABLES

⚠ DANGER If high voltage cables or cable connections are frayed, worn or damaged, contact with cables/connections will result in electrical shock causing severe injury or death.

With power in lockout, tagout, check electrical power cables and connections for fraying, wear or damage. If damaged, the cables must be replaced **BEFORE** operation. Be sure connections are secured.

Inspect **ALL** hydraulic hoses for cracks, wear or other damage. Repair or replace **BEFORE** operation.



34. INSPECT STRUCTURES

Perform a visual inspection of the EX-50 excavator, boring shield and all other system components for cracks, wear or other damage. Repair or replace **BEFORE** operation.

Check for oil leaks and debris buildup. Make repairs as needed and remove debris.

Check for loose, damaged or missing parts. Repair or replace any defective parts as necessary.




(continued on next page)

AS REQUIRED

35. INSPECT TOP & SIDE WEAR PADS

Inspect the boom assembly top wear pads (A) (2 places) and side wear pucks (B) (4 places) for cracks, wear or other damage. If cracked, worn or damaged, replace BEFORE operation.




36. CHECK DRIVE TRAIN TENSION & LUBRICATE

1. Remove drive chain guard (not shown).
2. Inspect drive chain (C). If worn or damaged, replace with new.
3. Check chain tension. The center of the chain should have a maximum deflection of 1/4 in. (6.4 mm).

To adjust chain tension, loosen motor mount plate bolts (D) on motor mount plate (E) and tighten chain until the 1/4 in. (6.4 mm) deflection is achieved. Then retighten motor mount plate bolts.

4. Thoroughly lubricate drive chain (C) with a high quality chain lubricant.

Replace drive chain guard before operating (not shown).




(continued on next page)

As Required (continued)

37. ADJUST SIDE WEAR PUCKS

1. Install equal number of shims (A) on each side wear puck (B) location.
2. Check that the boom can slide without chatter or vibration. If the boom is too tight, add an 0.02 inch shim (A) to each side's wear pads to achieve the closest possible clearance for the boom to operate without chatter/vibration. Repeat on the other side until the chatter/vibration is alleviated.




NOTE: Wear pucks and shims contain wear resistant properties. Do not grease or lubricate wear pucks or shims.


38. ADJUST ADJUSTER WEDGES

Adjust adjuster wedges (2 places) to achieve the closest possible clearance for the boom to operate without chatter/vibration.

1. To adjust adjuster wedges, loosen screws (C) (4 total) on the bottom side of the wedge ramps and tighten the wedge adjuster screws (D) on the back side of the wedges.
2. Repeat on the other adjuster wedge until chatter/vibration is alleviated.
3. Re-tighten the bottom bolts (C) (4 total) to 74 ft-lb. (100 N·m) of torque after the adjustment has been made.



Bottom side of EX-50 Boom Shown



Adjuster Wedge Assembly

NOTE: Adjuster wedges contain wear resistant properties. Do not grease or lubricate adjuster wedges.

NOTES

Storage

PREPARING FOR STORAGE

NOTICE

Follow the lubrication and maintenance requirements in the Periodic Maintenance section.

1. Repair worn or damaged parts.
2. Wash all equipment thoroughly.
3. Lubricate all grease points. Grease threads on bolts used for adjustments.
4. Retract all hydraulic cylinders if possible. If not, coat exposed cylinder rods with a corrosion preventive.
5. Repaint equipment where necessary.
6. Drain hydraulic oil, flush oil reservoirs, change hydraulic filters, and refill hydraulic reservoirs. Check for leaks.
7. Wipe up lube spills. Dispose of rags and trash properly. Store oily rags and other flammable material in protective containers.
8. If possible, store equipment under cover and out of the weather in a ventilated area.
9. Remove laser guidance system and place it in the storage box.
10. Do not smoke in areas where flammable materials are stored.
11. Store fuels and lubricants in properly marked containers.

REMOVING FROM STORAGE

NOTICE

Follow the lubrication and maintenance requirements in the Periodic Maintenance section.

1. Clean equipment thoroughly.
2. Check to make sure all decals including safety decals are clean and readable.
3. Check condition of wires and cables. Repair or replace as necessary.
4. Remove the cylinder corrosion preventive from the cylinder rods if it is not compatible with hydraulic oil or seal materials.
5. Check for leaks. Repair or replace as necessary.
6. Check hydraulic oil level in reservoir. If fluid is low, check for leaks and add oil as required. Refer to Lubricants section.
7. Perform a oil analysis on the oil in the hydraulic reservoir. Replace the hydraulic oil and filters if the test reveals contamination.
8. Check the return filter indicators. Replace filter(s) as needed.
9. Check condition of all hoses and connections. Tighten, repair or replace with new as needed.
10. Before operating, cycle hydraulic functions several times to purge air from the hydraulic system.
11. Review this Operator's Manual.


NOTES

Troubleshooting


EX-50 EXCAVATOR

Problem	Cause	Solution
Excavator does not operate.	Improper phase power.	Contact electrician to correct phase.
	Power source is OFF.	Turn on power source.
	Motor is OFF.	Turn motor ON.
	Pump(s) are OFF.	Turn pumps ON.
	Improper motor rotation.	Electrician must re-wire motor for clockwise motor rotation.
	E-Stop is pushed in.	Pull out E-Stop button.
	CAN bus communication issue.	Correct CAN bus network issues. Ensure each node is seeing 60 ohms of resistance between CAN high and CAN low.
Joysticks movement does not cause EX-50 to move.	Joystick operator presense switch issue.	Operator presense switch levers must be OFF when the system powers on. One switch must be on to operate EX-50 functions.
	Operator's presense lever is not engaged.	Engage operator's presense lever and move joystick.
Noise, chatter or vibration in EX-50 boom.	Load sense hose is kinked, pinched or disconnected.	Unkink, unpinch or plug in load sense hose/cable.
	Additional clearance is needed for wear pucks.	Added shims to either side of boom until resolved.
	Additional clearance is need for boom wedges.	Tighten or re-tighten the wedges to add or reduce clearance until resolved.

ELECTRICAL - EX-50 CONTROL CONSOLE




HYDRAULICS - EX-50 BOOM



Specifications

EX-50 EXCAVATOR



Excavating Power (Primary Functions) (in Pounds Force)

Weight	7,500 lbs	
Bucket Cylinder (A1)	11,600 lbf	
Boom Extension Cylinder (A2) - 48 in.		
Extension	24,000 lbf	
Retraction	12,000 lbf	
Boom Swing Cylinder (A3)		
Bucket Position	Bucket Ready	Bucket Rolled
Boom Retracted	8,900 lbf	10,700 lbf
Boom Extended	5,800 lbf	6,500 lbf
Boom Hoist Cylinder (A4) - Bucket is ready		
Hoist Motion	Hoist Up	Hoist Down
Boom Retracted	5,400 lbf	11,600 lbf
Boom Extended	3,700 lbf	7,900 lbf
Frame Advance Cylinder (A5) - 36 in.		
Extension	48,000 lbf	
Retraction	24,000 lbf	
Boom Rotation (A6)	Bi-Directional, 225 degrees	

Hydraulic Controls

The EX-50 supply is fed by the 5200 pump unit (or other power support equipment) where the oil is dispersed to the main valve bank. Primary functions are proportionally controlled from the joysticks. Position functions are on/off controls.

A. Six Section Valve Bank	30 gpm @ 3,000 psi
1. Boom Swing Control	Primary Function
2. Boom Extension Control	Primary Function
3. Boom Rotation Control	Positioning Function
4. Bucket Control	Primary Function
5. Hoist Control	Primary Function
6. Frame Extension Control	Positioning Function

Akkerman Inc. reserves the right to improve its product without notice or obligation.

TORQUE CHART

Use these torque values as a guideline when tightening hardware unless otherwise specified in this manual.

Lubricated Coarse UNC Threads Grade 8 Fasteners			Lubricated Fine UNF Threads Grade 8 Fasteners		
Bolt Size	Torque		Bolt Size	Torque	
	ft. lbs.	(N·m)		ft. lbs.	(N·m)
1/4 - 20	10	(14)	1/4 - 28	11	(15)
5/16 - 18	20	(27)	5/16 - 24	22	(30)
3/8 - 16	35	(47)	3/8 - 24	39	(53)
7/16 - 14	56	(76)	7/16 - 20	62	(84)
1/2 - 13	85	(115)	1/2 - 20	96	(130)
9/16 - 12	123	(167)	9/16 - 18	137	(186)
5/8 - 11	170	(231)	5/8 - 18	192	(260)
3/4 - 10	301	(408)	3/4 - 16	336	(456)
7/8 - 9	450	(610)	7/8 - 14	500	(678)
1 - 8	680	(922)	1 - 12	740	(1003)
1-1/8 - 7	960	(1302)	1-1/8 - 12	1030	(1397)
1-1/4 - 7	1360	(1844)	1-1/4 - 12	1500	(2034)
1-1/2 - 6	2360	(3200)	1-1/2 - 12	2660	(3607)


Identification Numbers

Model and serial numbers are required when ordering parts or requesting service information. Record your model and serial number below.

EX-50 EXCAVATOR (A)

Model Number _____

Serial Number _____



NOTES

Safety Data Sheets

The Federal Occupational, Safety, and Health Administration (OSHA) Standard 29 CFR 1910.1200, require that specific safety data sheets (SDS) be available to employees before operating this equipment. This may include information on substances contained in this equipment such as fuel and gear lubricant.

Akkerman Inc. will provide, at no cost, SDS which apply to its product line. Simply contact your Akkerman Aftermarket Support representative for a copy.

To ensure a prompt response to your SDS request, include your return address (including zip or postal code) and the equipment's model numbers and serial numbers with your request.

NOTES

Warranty

Akkerman warrants that all equipment manufactured by it be free from defects due to workmanship or material when normally used and serviced for a period of 90 days from the date of shipment by Akkerman. Normal wear and tear to the equipment, including, but not limited to, wear on the cutter face tooling, hydraulic filters, augers, casings, slurry line and seals is not covered by this warranty. Akkerman does not warrant that the equipment meets the requirements of any particular safety code or rule governing equipment classification. If the Customer has questions about local safety codes, rules or ordinances, authorities local to the project should be consulted.

In order to be considered as a potential warranty claim, the component in question must be returned to Akkerman (freight prepaid) for factory inspection and analysis, and determination of warranty applicability. No warranty is provided for electronics or electrical components of any kind. The validity of all warranty claims are subject to the discretion and determination of the Akkerman Aftermarket Support Department. All such determinations are final.

Warranty

NOTES

Parts

Contents

Introduction	16-2
Decals	16-4
EX-50 Decal Kit, 1255-136	16-4
EX-50 Operator Shield Decal Kit, 1255-142	16-7
Parts	16-9
<i>EX-50 Excavator</i>	
Arm & Hydraulics Assembly, F62687F	16-9
Excavator & Hoist Assembly, 061612A	16-10
Boom Assembly, 061510A	16-12
Inner Boom Assembly, 061383A	16-14
Rotary Boom Assembly, 061448A	16-16
Wedge Adjuster Assembly, 061456A	16-18
Extend Cylinder & Power Chain Assembly, 061489A	16-20
Dirt Guard Assembly, 061503A	16-22
Telescopic Boom Seal Assembly, 062317A	16-23
Standard Bucket, 062412A	16-24
EX-50 Boom Hydraulic Assembly, 062155A	16-26
EX-50 Hydraulic Schematic, 062206P	16-28
Operator Seat Assembly, 062158A	16-29
EX-50 Electrical Assembly, 062212A	16-30
EX-50 Electrical Schematic, 062244P	16-32
Electrical Box - E-Stop Assembly, 019023A	16-34
Gas Detector With Alarm Assembly, 031499A	16-35
Enclosure Assembly, 062243A	13-36
<i>Attachment</i>	
Drum Cutter Kit, 063003A	16-39
Drum Cutter & Mounting Assembly, 062621A	16-40
Fixed Link Assembly, 062576A	16-41
Operator Shield Assembly, 062638A	16-42

INTRODUCTION

This parts section of the manual contains assembly illustrations of the Akkerman EX-50 Excavator. The illustrations in this section are intended to show typical construction of various parts. In some instances, the details of parts illustrated may not exactly represent their actual appearance, but will help to identify parts performing the same functions.

LOCATING PARTS

This manual is organized to help you locate parts information quickly. An Alphabetical Index, Section 17, is provided to determine the page number of the assembly a part is used. If the part number is known, the Numerical Index, Section 18, can also be utilized to find the page number of the assembly.

USE GENUINE AKKERMAN PARTS

The use of second-rate parts could affect the efficient performance of the EX-50 Excavator.

ALWAYS use genuine Akkerman parts.

PARTS ORDERING

To order fast, accurate, and reliable parts service, call (800) 533-0386, (507) 567-2261, or fax (507) 567-2720, and provide the following information.

1. Model Number
2. Serial Number
3. Part Number, Description, and Quantity
4. Shipping Preference

MEASUREMENTS

The unit of measure in this manual is in inches unless indicated otherwise.

HARDWARE SPECIFICATION

All Akkerman products are assembled with SAE Grade 8 bolts, nuts, and washers. **ALWAYS** use matched fastener hardware when replacing or repairing the unit.

If you find any errors with this manual or have any suggestions for improvement, please let us know.


Mail your suggestions to:

Akkerman Inc., ATTN: Technical Publications, 58256 266th Street, Brownsdale, MN 55918.


Akkerman Inc. reserves the right to improve its product without notice or obligation.

NOTES

EX-50 DECAL KIT, 1255-136



EX-50 DECAL KIT, 1255-136




ITEM	QTY	PART NO.	DESCRIPTION
0	1	1255-136	KIT, Decal EX-50
1	10	1250-480	DECAL, Warning Pinch Points
2	2	1250-558	DECAL, Flag
3	2	1251-246	DECAL, Akkerman Logo - Large
4	3	1250-004	DECAL, Warning Guards In Place
5	2	1251-875	DECAL, Warning Suspended Load
6	4	1250-562	DECAL, Warning Pinch Points
7	3	1252-235	DECAL, EX-50 Cylinder & Frame Lube Points
8	3	1252-236	DECAL, Warning Stored Energy
9	1	-	PLATE, Serial Number
10	1	1250-544	DECAL, Made In USA
11	1	1251-377	DECAL, Model EX-50
12	1	1252-238	DECAL, EX-50 Valve

(Continued on next page)

EX-50 DECAL KIT, 1255-136

ITEM	QTY	PART NO.	DESCRIPTION
13	4	1252-242	DECAL, Shim Wear Pucks
14	2	1252-240	DECAL, Boom Cleanout Cover
15	2	1252-241	DECAL, Wedge Bolt Torque
16	1	1252-234B	DECAL, Bucket Hoist Joystick
17	1	1252-234A	DECAL, Boom Extend - Swing Joystick
18	1	P0310-474F	DECAL, Emergency Stop
19	1	1252-234D	DECAL, Aux Flow Switch
20	1	1252-237B	DECAL, Seat Control - E-Stop
21	1	1252-234C	DECAL, Select Switch
22	1	1251-607AE	DECAL, Phase OK.
23	1	1251-607AF	DECAL, Phase Error
24	1	1252-237C	DECAL, E-Stop Control
25	1	1251-607CI	DECAL, System Pressure
26	1	1251-607CF	DECAL, Main Power Disconnect
27	1	1251-607CG	DECAL, Incoming Power
28	1	1251-607CH	DECAL, 120V GFI 20 AMP
29	1	1252-237A	DECAL, Electric Box Labels
30	1	P0310-474F	DECAL, Emergency Stop


EX-50 OPERATOR SHIELD DECAL KIT, 1255-142



ITEM	QTY	PART NO.	DESCRIPTION
0	1	1255-142	KIT, Decal EX-50 Operator Shield Rotary Tool
1	2	1252-233	DECAL, Warning, Pinch Points Vertical
2	1	1252-264	DECAL, Warning, Flying Debris

NOTES

ARM & HYDRAULICS ASSEMBLY, F62687F




ITEM	QTY	PART NO.	DESCRIPTION
0	1	F62687F	ARM & HYDRAULIC - EX-50 ASSEMBLY
1*	1	061612A	ASSEMBLY, Excavator & Hoist
2*	1	062155A	ASSEMBLY, Boom Hydraulics
3*	1	062158A	ASSEMBLY, Operator Seat
4**	1	062212A	ASSEMBLY, Electrical EX-50

* Refer to this section for parts information.

** Not part of F62687F assembly.

^ A rotary cutter attachment option is available. Refer to Drum Cutter Kit, 06003A in this section.

EXCAVATOR & HOIST ASSEMBLY, 061612A



EXCAVATOR & HOIST ASSEMBLY, 061612A


ITEM	QTY	PART NO.	DESCRIPTION
0	1	061612A	EXCAVATOR & HOIST ASSEMBLY
1	1	008805A01	FRAME, Slide (Includes items 1a - 1c) (Standard)
1a	8	P0001-06-005	BOLT, Hex 3/8 UNC x 1.25
1b	6	P0040-005	WASHER, Hardened Flat 5/16
1c	6	P0001-05-003	BOLT, Hex 5/16 UNC x .75
2	1	008810A05	FRAME, Hoist & Swing (Includes items 2a - 2f)
2a	2	008957P00	PIN, Frame Slide
2b	2	061575P	PIN, Hoist Pivot
2c	8	P0001-06-005	BOLT, Hex 3/8 UNC x 1.25
2d	8	P0001-08-008	BOLT, Hex 1/2 UNC x 2
2e	8	P0040-006	WASHER, Hardened Flat 3/8
2f	8	P0040-008	WASHER, Hardened Flat 1/2
3	2	008879P00	PIN, Swing Cylinder
4	2	008957P00	PIN, Frame Slide
5	2	009080A00	HANGER, Safety (Includes items 5a - 5b)
5a	8	P0001-08-006	SCREW, Hex Cap 1/2 UNC x 1.5
5b	8	P0045-008	WASHER, Lock 1/2
6	2	009822A00	FRAME SLIDE, Back Clevis (Includes items 6a - 6b)
6a	1	008958P00	PIN, Frame Slide
6b	4	P0001-06-005	BOLT, Hex 3/8 UNC x 1.25
7	14	011115P00	BAR, Safety
8	12	021057P00	ROD
9*	1	061510A	ASSEMBLY, Boom
10	14	P0001-10-009	BOLT, Hex 5/8 UNC x 2.25
11	18	P0013-08-000	NUT, Lock Flex 1/2
12	24	P0031-08-012	SCREW, Socket Head Cap 1/2 UNC x 3
13	18	P0031-08-018	SCREW, Socket Head Cap 1/2 UNC x 4.5
14	78	P0040-008	WASHER, Hardened Flat 1/2
15	14	P0040-010	WASHER, Hardened Flat 5/8
16	2	P0063-004	FITTING, Grease 1/8-NPT Straight
17	1	P0065-069	BEARING
18^	2	P0307-247	CYLINDER, Frame Slide
19^	2	P0307-248	CYLINDER, Swing Frame
20^	2	P0307-249	CYLINDER, Boom Hoist
21**	1	1255-136	KIT, Decal EX-50 V2 (Not Shown)

* The 2" slide frame, 013252A is available by special request. The 013252A slide frame is used in smaller shield units, 102" diameter and less. Contact your Akkerman Aftermarket Support representative for more information.

** Refer to this section for parts information.

^ This cylinder uses Seal Kit, P0307-254.

BOOM ASSEMBLY, 061510A




BOOM ASSEMBLY, 061510A

ITEM	QTY	PART NO.	DESCRIPTION
0	1	061510A	BOOM ASSEMBLY, EX-50-02
1	2	021057P00	ROD
2*	1	061383A	BOOM, Inner
3	4	061444P	PUCK, Wear 4
4*	1	061448A	BOOM, Rotary
5*	2	061456A	ADJUSTER, Wedge
6*	1	061489A	ASSEMBLY, Extend Cylinder & Power Chain
7*	1	061503A	GUARD, Dirt
8	4	061504P	COVER, Wear Puck
9	8	061505P	SHIM, Puck Cover - 1 mm
10	20	061506P	SHIM, Puck Cover -1/2 mm
11	2	061507P	MOUNT, Wear Pad
12*	1	062317A	SEAL, Telescopic Boom
13	1	062330P	PLATE, Cleanout
14*	1	062412A	BUCKET, Standard
15	2	062454P	BUMPER, Telescopic Boom
16	4	062456P	PAD, Telescopic Boom Bumper
17	3	P0001-05-003	BOLT, Hex 5/16 UNC x .75
18	4	P0001-06-006	BOLT, Hex 3/8 UNC x 1.5
19	16	P0001-08-005	SCREW, Hex Cap 1/2 UNC x 1.25
20	2	P0001-08-040	BOLT, Hex 1/2 UNC x 10
21	24	P0001-10-007	BOLT, Hex 5/8 UNC x 1.75
22	2	P0003-08-000	NUT, Hex 1/2 UNC
23	12	P0030-06-003	SCREW, Flat Head Socket Cap 3/8 x .75
24	2	P0030-06-004	SCREW, Flat Head Cap 3/8 UNC x 1
25	3	P0040-005	WASHER, Hardened Flat 5/16
26	4	P0040-006	WASHER, Hardened Flat 3/8
27	24	P0040-008	WASHER, Hardened Flat 1/2
28	24	P0040-010	WASHER, Hardened Flat 5/8
29	2	P0066-134	PAD, Wear
30	4	PM10A-1.50-020	BOLT, Hex M10 x 1.50 x 20 10.9

* Refer to this section for parts information.

INNER BOOM ASSEMBLY, 061383A




INNER BOOM ASSEMBLY, 061383A

ITEM	QTY	PART NO.	DESCRIPTION
0	1	061383A	INNER BOOM ASSEMBLY
1	1	-	BUSHING, Bucket Mounting - Extension Boom
2	2	-	BAR, Mount
3	1	-	EXTENSION, Wear Plate
4	1	-	CORE, Extension Boom
5	1	-	PLATE, Boom End - Right
6	1	-	PLATE, Boom End - Left
7	2	-	WEAR PLATE, Inner Boom - Side
8	1	-	WEAR PLATE, Inner Boom - Top
9	1	-	WEAR PLATE, Inner Boom - Bottom
10	2	061400A	BEARING, Bucket Cylinder (Includes items 10a - 10c)
10a	1	061399P	MOUNT, Bucket Cylinder Flange
10b	1	P0063-001	FITTING, Grease 1/4-28 Straight
10c	1	P0065-086	BEARING
11	1	-	GUSSET, Inner Boom
12	1	061402P	BUSHING, Pin Retainer
13	1	061403P	PIN, Extension Cylinder - Inner Boom
14	1	061492P	COVER, Top Access
15	1	-	STOP, Bucket - Right
16	1	-	STOP, Bucket - Left
17	2	-	GUARD, Bolt Head
18	8	P0001-12-007	BOLT, Hex 3/4 UNC x 1.75
19	6	P0030-05-003	SCREW, FLAT Socket Head Cap 5/16 UNC x .75
20	4	P0030-06-003	SCREW, FLAT Head Socket Head Cap 3/8 UNC x .75
21	1	P0031-08-005	SCREW, Socket Head Cap 1/2 UNC x 1.25
22	8	P0040-012	WASHER, Hardened Flat 3/4
23	2	P0066-046	BUSHING
24*	1	P0307-246	ASSEMBLY, Trunnion Mount Cylinder

* This cylinder uses Seal Kit, P0307-254.


ROTARY BOOM ASSEMBLY, 061448A



ROTARY BOOM ASSEMBLY, 061448A

ITEM	QTY	PART NO.	DESCRIPTION
0	1	061448A	ROTARY BOOM ASSEMBLY
1	1	007551P00	STOP, Boom
2	1	007552P00	STOP, Boom
3	1	011074P00	SPROCKET
4	2	061418P	BUSHING, Excavator Pivot
5	1	061419A	HOUSING, Rotator (Includes item 5a)
5a	2	008877P00	PIN, Hoist Cylinder
6	1	061423A	OUTER BOOM - Excavator (Includes items 6a -6d)
6a	1	061439P	PLATE, Bottom
6b	8	P0001-08-006	SCREW, Hex Cap 1/2 UNC x 1.5
6c	8	P0040-008	WASHER, Hardened Flat 1/2
6d	1	008878P00	PIN, Boom Extension Cylinder
7	1	061430P	PLATE, Rear Rotary Boom
8	1	061445A	MOUNT, Motor - Rotation Drive (Includes items 8a - 8b)
8a	6	P0001-08-006	SCREW, Hex Cap 1/2 UNC x 1.5
8b	4	P0040-008	WASHER, Hardened Flat 1/2
9	1	061446P	RETAINER RING, Rotator Housing
10	2	061447P	BUSHING, Rotator Housing
11	2	061449P	WASHER, Rotary Boom Thrust
12	1	062407P	RETAINER RING, REAR-ROTATOR
13	1	062479A	GUARD, Chain (Includes items 13a - 13d)
13a	1	062478P	PAD, Chain Guard
13b	4	P0030-04-003	SCREW, Flat Head Cap 1/4 UNC x .75
13c	4	P0013-04-000	NUT, Nylock 1/4
13d	1	061601A	GUARD, Chain (Includes items 13d1 - 13d4)
13d1	1	061602P	PLATE, Guard Mount
13d2	8	P0001-06-003	BOLT, Hex 3/8 UNC x .75
13d3	8	P0011-006C	NUT, Tab Weld 3/8-16
13d4	8	P0040-006	WASHER, Hardened Flat 3/8
14	1	062737P	SPACER, Arbor
15	1	062738P	WASHER, Shaft Sprocket Retaining
16	8	P0001-06-003	BOLT, Hex 3/8 UNC x .75
17	4	P0001-08-005	SCREW, Hex Cap 1/2 UNC x 1.25
18	8	P0001-08-006	SCREW, Hex Cap 1/2 UNC x 1.5
19	24	P0001-08-007	BOLT, Hex 1/2 UNC x 1.75
20	1	P0001-08-008	BOLT, Hex 1/2 UNC x 2
21	1	P0003-08-000	NUT, Hex 1/2 UNC
22	1	P0030-06-003	SCREW, Flat Head Socket Cap 3/8 UNC x .75
23	12	P0031-10-016	SCREW, Socket Head Cap 5/8 UNC x 4
24	8	P0040-006	WASHER, Hardened Flat 3/8
25	38	P0040-008	WASHER, Hardened Flat 1/2
26	1	P0049-081	PIN, Spring/Roll 3/16 x 1.25
27	8	P0063-001	FITTING, Grease 1/4-28 Straight
28	68	P0078-003	CHAIN, Single #80 Riv.
29	1	P0078-006	LINK, Repair #80
30	1	P0304-134	MOTOR, Excavator 24 C.I.D.


WEDGE ADJUSTER ASSEMBLY, 061456A



ITEM	QTY	PART NO.	DESCRIPTION
0	1	061456A	WEDGE ADJUSTER ASSEMBLY
1	1	061457P	BLOCK
2	1	061509P	BAR
3	2	P0001-08-006	SCREW, Hex Cap 1/2 UNC x 1.5
4	1	P0007-08-000	NUT, Jam 1/2 UNC
5	1	P0034-08-012	SCREW, Square Head Set 1/2 UNC x 3
6	5	P0040-008	WASHER, Hardened Flat 1/2
7	1	P0066-135	ASSEMBLY, Wedge
8	2	PM12A-1.75-050	SCREW, Hex Head M12-1.75 x 50 -12.9

NOTES

EXTEND CYLINDER & POWER CHAIN ASSEMBLY, 061489A




EXTEND CYLINDER & POWER CHAIN ASSEMBLY, 061489A

ITEM	QTY	PART NO.	DESCRIPTION
0	1	061489A	EXTEND CYLINDER & POWER CHAIN ASSEMBLY
1	1	061467A	GUIDE, Hose Chain (Includes item 1a)
1a	2	P0030-04-003	SCREW, Flat Head Cap 1/4 UNC x .75
2	4	061476P	BAR, Line Retainer
3	1	061477P	SPACER BUSHING, Line Clamp
4	1	061478P	MOUNT, Hose Chain Bracket
5	1	061479A	ASSEMBLY, Hydraulic Tube - Boom Retract
6	1	061480A	ASSEMBLY, Hydraulic Tube - Boom Acc - Left
7	1	061484A	BULKHEAD, Hydraulic Tube
8	1	061486A	UNION, Retract Tube
9	4	061487P	TAB, Weld 1/4-20
10	1	062408A	ASSEMBLY, Twin Hose
11	1	062409P	CLAMP, Twin Hose
12	1	062411A	BRACKET, Hose Guide
13	1	062416A	ASSEMBLY, Hydraulic Tube - Boom Acc - Right
14	1	062429P	BAR, Line Mount
15	3	062452P	WASHER, Spacer - Line Mount
16	4	P0001-04-004	BOLT, Hex 1/4 UNC x 1
17	1	P0001-04-007	SCREW, Hex Head 1/4 UNC x 1.75
18	1	P0001-05-002	BOLT, Hex 5/16 UNC x .5
19	2	P0001-05-003	BOLT, Hex 5/16 UNC x .75
20	2	P0001-06-004	BOLT, Hex 3/8 UNC x 1
21	1	P0001-06-005	BOLT, Hex 3/8 UNC x 1.25
22	2	P0013-04-000	NUT, Nylock 1/4
23	1	P0030-04-006	SCREW, Flat Head Socket 1/4 UNC x 1.5
24	4	P0035-016	BOLT, Flanged Head 1/4 UNC x .375
25	4	P0040-004	WASHER, Hardened Flat 1/4
26	3	P0040-005	WASHER, Hardened Flat 5/16
27	3	P0040-006	WASHER, Hardened Flat 3/8
28	1	P0300-143	FITTING, 10MJ-08MP90
29	1	P0300-200	FITTING, 10MJ-08MB
30	1	P0300-305	FITTING, 08MFOR-08MB
31	2	P0300-325	FITTING, 08MJ-08MJBKHD
32	1	P0300-340	FITTING, 08MFOR-08MP90
33	2	P0300-923	FITTING, 08MFFOR-08MJ
34*	1	P0307-245	CYLINDER, Boom Extension
35	120 LI	P0313-142	SLEEVE, Abrasion Resistant

LI - Linear Inch


^ This cylinder uses Seal Kit, P0307-254.

DIRT GUARD ASSEMBLY, 061503A




ITEM	QTY	PART NO.	DESCRIPTION
0	1	061503A	DIRT GUARD ASSEMBLY
1	1	061511P	RUBBER
2	1	061512P	RETAINER, Bellow
3	1	061516A	SHELL, Dirt Guard
4	10	P0001-05-006	BOLT, Hex 5/16 UNC x 1.5
5	10	P0013-05-000	NUT, Nylock 5/16
6	20	P0040-005	WASHER, Hardened Flat 5/16

TELESCOPIC BOOM SEAL ASSEMBLY, 062317A



ITEM	QTY	PART NO.	DESCRIPTION
0	1	062317A	TELESCOPIC BOOM SEAL ASSEMBLY
1	1	062320P	MOUNT, Seal
2	1	062319P	RETAINER, Seal
3	1	062318P	BAR, Seal Mount
4	14	P0040-005	WASHER, Hardened Flat 5/16
5	14	P0001-05-004	BOLT, Hex 5/16 UNC x 1
6	14	002624P00	WASHER
7	1	062321P	RUBBER, Seal
8	1	062322P	BAR, Seal Retainer


STANDARD BUCKET, 062412A



ITEM	QTY	PART NO.	DESCRIPTION
0	1	062412A	STANDARD BUCKET
1	1	011156P01	BUSHING, Bucket
2	1	011160P01	PIN, Bucket - Excavator
3	1	062325P	PIN, Bucket Cylinder
4	1	011170P00	BUSHING, Bucket - Excavator\
5	1	011171P00	BUSHING, Bucket - Excavator
6	1	011172P00	BUSHING, Bucket - Excavator
7	2	-	PLATE, Backhoe Bucket
8	2	-	PLATE, Backhoe Bucket
9	1	-	PLATE, Backhoe Bucket
10	1	-	PLATE, Backhoe Bucket
11	2	-	PLATE, Backhoe Bucket
12	1	-	PLATE, Backhoe Bucket
13	2	P0001-06-014	BOLT, Hex 3/8 UNC x 3.5
14	1	P0003-06-000	NUT, Hex 3/8
15	4	P0040-006	WASHER, Hardened Flat 3/8
16	1	P0001-06-012	BOLT, Hex 3/8 UNC x 3
17	1	P0063-004	FITTING, Grease 1/8 NPT Straight
18	3	P0051-007	HOLDER, Tooth
19	3	P0051-008	PINS, Excavator
20	3	P0050-023	TEETH, Cutter

NOTES

EX-50 BOOM HYDRAULIC ASSEMBLY, 062155A



ITEM	QTY	PART NO.	DESCRIPTION
0	1	062155A	EX-50 BOOM HYDRAULIC ASSEMBLY
1	1	P0302-924	VALVE, 6 Section
2	8	P0300-300	FITTING, 08MFOR-10MB
3	2	P0300-634	FITTING, 06MFOR-10MB
4	3	P0300-613	FITTING, 06MFOR-06FFORX-06MFOR
5	4	P0300-717	FITTING, 6MFFOR-8MB90
6	11	P0300-430	FITTING, 06MFOR-08MB
7	1	P0300-378	FITTING, 12MFFOR-16MB
8	1	P0300-632	FITTING, 12MFFOR-16MB90
9	1	P0300-883	FITTING, 06MFFOR-05MB
10	2	P0300-788	FITTING, 10MB-08FB
11	2	P0300-400	FITTING, 08MFOR-08MB-LONG
12	1	P0300-314	FITTING, 04MFOR-05MB
13	7	P0001-05-003	BOLT, Hex 5/16 UNC x .75


(Continued on next page)

EX-50 BOOM HYDRAULIC ASSEMBLY, 062155A


ITEM	QTY	PART NO.	DESCRIPTION
14	6	P0040-005	WASHER, Hardened Flat 5/16
15	6	P0040-004	WASHER, Hardened Flat 1/4
16	2	P0001-04-010	BOLT, Hex 1/4 UNC x 2.5
17	2	P0001-04-009	BOLT, Hex 1/4 UNC x 2.25
18	2	P0040-006	WASHER, Hardened Flat 3/8
19	2	P0001-06-011	BOLT, Hex 3/8 UNC x 2.75
20	1	062294P	MANIFOLD, Junction
21	5	P0300-305	FITTING, 08MFOR-08MB
22	5	P0300-355	FITTING, 06MFOR-06MB90
23	1	062292P	MANIFOLD, Right Angle
24	2	P0300-356	FITTING, 06MFOR-06MB
25	1	P0302-174B	VALVE
26	1	P0300-565	FITTING, 12MORB-08FORB
27	1	P0300-726	FITTING, 08MFOR-08MFOR-08MB
28	1	P0300-373	FITTING, 08MFOR-12MB90
29	4	A10368A-060	HOSE ASSEMBLY, 1/2 x 60
30	1	P0300-877	FITTING, 8MJ-8MB90
31	4	P0302-819	JOINT, Swivel 8 x 8 JIC
32	1	P0300-116	FITTING, 08MJ-08MP90
33	1	P0300-945	FITTING, 08FB-08FB
34	1	P0300-542	FITTING, 08MB-08MB
35	4	P0004-05-000	NUT, Hex 5/16 UNF
36	4	002269P01	CLAMP, Line
37	1	A10079A-031	HOSE ASSEMBLY, 3/8 x 31
38	1	A10079A-026	HOSE ASSEMBLY, 3/8 x 26
39	2	A10079A-042	HOSE ASSEMBLY, 3/8 x 42
40	1	A10079A-048	HOSE ASSEMBLY, 3/8 x 48
41	2	A10474A-028	HOSE ASSEMBLY, 3/8 x 28
42	1	A10313A-036	HOSE ASSEMBLY, 3/8 x 36
43	1	A10313A-025	HOSE ASSEMBLY, 3/8 x 25
44	1	A10079A-036	HOSE ASSEMBLY, 3/8 x 36
45	1	A10079A-025	HOSE ASSEMBLY, 3/8 x 25
46	1	A10324A-098	HOSE ASSEMBLY, 1/2 x 98
47	2	A10079A-018	HOSE ASSEMBLY, 3/8 x 18
48	1	A10366A-032	HOSE ASSEMBLY, 3/8 x 32
49	1	A10324A-066	HOSE ASSEMBLY, 1/2 x 66
50	1	A10388A-017	HOSE ASSEMBLY, 3/8 x 17
51	1	A61746A-116	HOSE ASSEMBLY, 3/4 x 116
52	1	A10464A-104	HOSE ASSEMBLY, 3/4 x 104
53	2	A10474A-046	HOSE ASSEMBLY, 3/8 x 46
54	2	A10324A-025	HOSE ASSEMBLY, 1/2 x 25
55	2	A10324A-078	HOSE ASSEMBLY, 1/2 x 78
56	1	A10082A-076	HOSE ASSEMBLY, 3/8 x 76
57	1	A10079A-090	HOSE ASSEMBLY, 3/8 x 90
58	1	A09889A-156	HOSE ASSEMBLY, 1/4 x 156
59	6	P0300-375	FITTING, 08MFOR-12MB
60	1	P0302-496	RELIEF, Dual Crossover - 5000PSI
61	2	P0001-04-015	BOLT, Hex 1/4 UNC x 4.5
62	1	P0300-735	FITTING, 06MFFOR-04MB
63	2	P0300-595	FITTING, 8MFFOR-8MFFOR-BKHD
64	1	062332P	PLATE, Bulkhead Fitting

NOTE: Refer to 062206P, Hydraulic Schematic on next page.

EX-50 BOOM HYDRAULIC SCHEMATIC, 062206P




OPERATOR SEAT ASSEMBLY, 062158A



ITEM	QTY	PART NO.	DESCRIPTION
0	1	062158A	OPERATOR SEAT ASSEMBLY
1	1	062159A	BASE, Seat
2	1	062165P	PLATE, Seat Base Removable
3	1	062166A	CONSOLE, Left
4	1	062167A	CONSOLE, Right
5	2	062186A	SUPPORT, Console
6	1	062187A	SUPPORT, Rear
7	1	062194P	BRACKET, Arm Rest - Left
8	1	062195P	BRACKET, Arm Rest - Right
9	1	062196P	MOUNT, E-Stop
10	1	062197P	PLATE, Joystick 2 Position Switch
11	1	062198P	PLATE, Joystick With Rotary
12	12	P0020-14-202	SCREW, Machine Truss HD 1/4 x .5
13	16	P0040-004	WASHER, Hardened Flat 1/4
14	16	P0001-04-002	BOLT, Hex 1/4 UNC x .5
15	8	P0001-05-003	BOLT, Hex 5/16 UNC x .75
16	12	P0040-005	WASHER, Hardened Flat 5/16
17	6	P0030-06-004A	SCREW, Button Head 3/8 UNC x 1
18	1	P0113-006	SEAT
19	4	P0003-05-000	NUT, Hex 5/16 UNC
20	1	P0315-002	ARMREST, Left
21	1	P0315-004	ARMREST, Right
22	4	P0040-008	WASHER, Hardened Flat 1/2
23	2	P0013-08-000	NUT, Lock Flex 1/2 UNC
24	2	P0001-08-006	SCREW, Hex Cap 1/2 UNC x 1.5
25	4	P0001-06-004	BOLT, Hex 3/8 UNC x 1
26	4	P0040-006	WASHER, Hardened Flat 3/8

EX-50 ELECTRICAL ASSEMBLY, 062212A



EX-50 ELECTRICAL ASSEMBLY, 062212A

ITEM	QTY	PART NO.	DESCRIPTION
0	1	062212A	EX-50 ELECTRICAL ASSEMBLY
1*	1	019023A	ASSEMBLY, Electrical Box - E-Stop
2*	1	031499A	ASSEMBLY, Gas Detector With Alarm
3^	1	062242A	HARNESS. Extension Control
4*	1	062243A	ENCLOSURE, Electrical
5	4	A09783A	ASSEMBLY, 24V LED Light
6	144 LI	P0054-012	WIRE, Standard 16 GA
7	1	P0054-073A	RECEPTACLE, 5 C 16 GA Mini Male SK x 12
8^	2	P0054-136	CABLE, 5C 16 GA Mini Fem SK x 12 ft
9^	2	P0054-288	CABLE, 4 C 16 GA Mini M/F SK 12 ft
10^	1	P0054-347	CABLE, 2C 22G Micro M/F DK Ext 12 ft
11^	1	P0054-700	CABLE, 3P MM AC AWM 22/3 20 ft
12	1	P0056-121F	CONTACT, N. O.
13	1	P0056-122F	BLOCK, Contact - Normally Closed
14	1	P0251-171	MODULE, LED
15	1	P0302-528A	ASSEMBLY, Connector
16	1	P0302-928	JOYSTICK, Left
17	1	P0302-929	JOYSTICK, Right
18	1	P0302-930	CONTROL, Rotary Speed
19	2	P0310-419F	LATCH, Mounting
20	1	P0310-420F	E-STOP, Pushbutton, Illuminated
21	1	P0310-421AF	SWITCH 2 Position
22	5	P0313-007	PINS #16
23	12	P0313-008	SOCKET #16
24	1	P0313-066A	RECEPTACLE, Wedgelock 8 Way
25	1	P0313-066B	RECEPTACLE, 8 Way Flange
26	3	P0313-067	PLUG, 4 Way
27	3	P0313-067A	PLUG, Wedgelock 4 Way


* Refer to this section for parts information.

^ Cable lengths may vary depending on shield diameter. Contact your Akkerman Aftermarket Support representative for more information.

LI - Linear Inch


For electrical schematic, refer to EX-50 Electrical Schematic 062244P, on next page.

EX-50 ELECTRICAL SCHEMATIC, 062244P




ELECTRICAL SCHEMATIC FOR 062212A

EX-50 ELECTRICAL SCHEMATIC, 062244P




ELECTRICAL BOX - E-STOP ASSEMBLY, 019023A




ITEM	QTY	PART NO.	DESCRIPTION
0	1	019023A	ELECTRICAL BOX - E-STOP ASSEMBLY
1	1	019024P	BOX
2	1	P0310-419F	LATCH, Mounting
3	1	P0310-420F	E-STOP, Pushbutton, Illuminated
4	1	P0251-171	MODULE, LED
5	1	P0054-073A	RECEPTACLE, 5 C 16 GA Mini Male SK 12
6	1	P0311-018	NUT, Lock 1/2
7	2	P0056-122F	BLOCK, Contact - Normally Closed
8	1	P0310-474F	DECAL, E-Stop

GAS DETECTOR WITH ALARM ASSEMBLY, 031499A



ITEM	QTY	PART NO.	DESCRIPTION
0	1	031499A	GAS DETECTOR WITH ALARM ASSEMBLY
1	1	P0251-861	SOUNDER, Panel Mount with LED
2	1	P0310-105	BOX
3	1	P0310-154	COVER
4	1	P0054-286	RECEPTACLE, 4 C 16 GA Mini Male SK 12
5	2	P0300-012	FITTING, 12MP-08FPS
6	1	P0405-002	NIPPLE, 1/2 x 2
7	6	P0040-004	WASHER, Hardened Flat 1/4
8	3	P0003-04-000	NUT, Hex 1/4 UNC
9	3	P0070-065	MOUNT, Vibration Isolation
10	1	P0310-283B	MAGNET, Pickup
11	1	031645P	BRACKET, Beacon
12	1	S10057A	ASSEMBLY, Gas Max Detector (Includes item 12 a)
12a	1	P0251-1065	DETECTOR, Gas, Methane, IR, 24VDC (Includes item 12 a1)
12a1	1	P0251-1065A	ELEMENT, Sensor
13	2	P0001-04-002	BOLT, Hex 1/4 UNC x .5
14	1	P0013-04-000	NUT, Nylock 1/4

ENCLOSURE ASSEMBLY, 062243A



ITEM	QTY	PART NO.	DESCRIPTION
0	1	062243A	ENCLOSURE ASSEMBLY
1	1	P0017-14-204	SCREW, Machine 1/4-20 x .75
2	6	P0020-83-022	SCREW, Truss Head 8-32 x .375
3	48	P0054-012	WIRE, Standard 16 GA
4	24	P0054-013	WIRE, 14 GA
5	24	P0054-014	WIRE, Black & White 12 GA
6	1	P0054-067G	PIGTAIL, 6 C 10 GA Chan-Out
7	2	P0054-073B	RECEPTACLE, 5 C 16 GA Mini Fem SK 3 ft
8	5	P0054-402	RECEPTACLE, 2C 18G Micro Fem DK 3 ft


(Continued on next page)

ENCLOSURE ASSEMBLY, 062243A

ITEM	QTY	PART NO.	DESCRIPTION
9	1	P0055-157	LUGS, 1 GA
10	1	P0251-1023	BREAKER, Circuit 480V 2 Pole 8A
11	1	P0251-1042	PILOT, LED, 480V, Red
12	1	P0251-1043	PILOT, LED, 480V, Green
13	1	P0251-1047	COVER, GFCI Weatherproof
14	2	P0251-468	FUSE
15	1	P0251-478	CONTACTOR, 3/4 HP 480V 3 PH 24VDC
16	1	P0251-480	KIT, Connector
17	1	P0251-481	BREAKER, 480V 3PH 15/3 W/Lugs
18	1	P0251-482	BREAKER, Handle & Shaft
19	1	P0251-616	POWER SUPPLY, 24V, 10 AMP
20	1	P0251-806	MMP, 3HP, 480V, 3PH, 4-6.3A
21	1	P0251-841	RECEPTACLE, 3 22G Fem DK Mic-1/2 NPT
22	1	P0251-855	MODULE, Electrical IO
23	1	P0251-901	ENCLOSURE
24	1	P0251-906	PHASE MONITOR 500VAC
25	1	P0310-105	BOX
26	6	P0310-473B	HOLDER, Fuse DIN Rail Midget
27	13	P0310-500	BLOCK, Terminal DIN Rail
28	1	P0310-503-006	RAIL, DIN - 6.0
29	2	P0310-503-008	RAIL, DIN - 8.0
30	7	P0310-571	STOP, Fuse Holder End
1	13	P0310-573	JUMPERS, Terminal Strip
32	1	P0310-795	OUTLET, Ground Fault 20A
33	1	P0310-899	TRANSFORMER, Isolation
34	4	P0310-954	FUSE, Time Delay 1.4 AMP
35	1	P0311-013	NIPPLE, Chase 1/2
36	1	P0311-020	NUT, Lock 1
37	1	P0311-034	BUSHING, Insulating 1
38	1	P0311-112	CORD GRIP 1 NPT
39	12	P0313-007	PINS #16
40	2	P0313-049	RECEPTACLE, 4 Cond Female
41	1	P0313-066B	RECEPTACLE, 8 Way Flange
42	1	P0313-068B	RECEPTACLE, 4 Way Flange
43	1	P0313-068A	RECEPTACLE, Wedgelock 4 Way

NOTES

DRUM CUTTER KIT, 063003A




ITEM	QTY	PART NO.	DESCRIPTION
0	1	063003A	DRUM CUTTER KIT
1*	1	062621A	ASSEMBLY, Drum Cutter & Mounting (Includes items 1a - 1b)
1a	1	P0050-238A	FILTER, Leak Line
1b	1	P0050-238B	TOOTH SET, Drum Cutter
2*	1	062638A	ASSEMBLY, Operator Shield
3**	2	A10329A-XXX	HOSE ASSEMBLY, 1/2 x
4**	2	A10368A-XXX	HOSE ASSEMBLY, 1/2 x
5	1	P0300-438	FITTING, 08MJ-08MJ
6	1	P0300-202	FITTING, 10MJ-10MJ

* Refer to this section for parts information.

** Hose assembly lengths may vary depending on shield diameter. Contact your Akkerman Aftermarket Support representative for more information.


DRUM CUTTER & MOUNTING ASSEMBLY, 062621A



ITEM	QTY	PART NO.	DESCRIPTION
0	1	062621A	DRUM CUTTER & MOUNTING ASSEMBLY
1	1	062577A	MOUNT, Cutter (Includes items 1a - 1k)
1a	1	011160P01	PIN, Bucket-Excavator
1b	1	011156P01	BUSHING, Bucket-Excavator
1c	1	011170P00	BUSHING, Bucket-Excavator
1d	1	011172P00	BUSHING, Bucket-Excavator
1e	1	062325P	PIN, Bucket Cylinder
1f	1	011171P00	BUSHING, Bucket-Excavator
1g	1	P0001-06-014	BOLT, Hex 3/8 UNC x 3.5
1h	2	P0003-06-000	NUT, Hex 3/8 UNC
1i	3	P0040-006	WASHER, Hardened Flat 3/8
1j	1	P0001-06-012	BOLT, Hex 3/8 UNC x 3
1k	1	P0063-004	FITTING, Grease 1/8-NPT Straight
2	1	P0050-238	ASSEMBLY, Drum Cutter(Includes item 2a - 2b)
2a	1	P0050-238A	FILTER, Leak Line
2b	1	P0050-238B	TOOTH SET, Drum Cutter
3	12	P0040-012	WASHER, Hardened Flat 3/4
4	6	P0003-12-000	NUT, Hex 3/4 UNC
5	6	P0001-12-012	BOLT, Hex 3/4 UNC x 3
6*	1	062576A	ASSEMBLY, Fixed Link


* Refer to this section for parts information.

FIXED LINK ASSEMBLY, 062576A



ITEM	QTY	PART NO.	DESCRIPTION
0	1	062576A	FIXED LINK ASSEMBLY
1	1	062615P	MOUNT, Trunion Link
2	1	062614P	RING, Retainer
3	1	P0065-086	BEARING
4	1	P0076-050	SNAP RING, Internal
5	2	P0063-001	FITTING, Grease 1/4-28 Straight
6	1	062611P	BAR, Lock-Adjuster
7	1	062610P	ADJUSTER, Trunion Link
8	2	P0001-06-008	BOLT, Hex 3/8 UNC x 2
9	10	P0040-006	WASHER, Hardened FLat 3/8
10	8	P0001-06-005	BOLT, Hex 3/8 UNC x 1.25
11	1	062613A	TIE-ROD, Trunion Link

OPERATOR SHIELD ASSEMBLY, 062638A



ITEM	QTY	PART NO.	DESCRIPTION
0	1	062638A	OPERATOR SHIELD ASSEMBLY
1	1	062639A	FRAME, Operator Screen
2	18	062656P	SUPPORT, Lexan
3	1	062657P	SCREEN, Lexan - Side
4	1	062658A	MOUNT, Screen
5	2	062659P	SCREEN, Lexan - Lower
6	1	062660P	SCREEN, Lexan - Top
7	2	A11570P	WASHER
8	18	P0001-04-005	BOLT, Hex 1/4 UNC x 1.25
9	3	P0001-06-006	BOLT, Hex 3/8 UNC x 1.5
10	18	P0013-04-000	NUT, Nylock 1/4
11	3	P0013-06A-000	NUT, Nylock 3/8 UNC
12	36	P0040-004	WASHER, Hardened Flat 1/4
13	6	P0040-006	WASHER, Hardened Flat 3/8
14	1	P0059-031	FASTENER, Rubber Hood
15	1	P0253-112	BUMPER, Rubber
16*	1	1255-142	KIT, Decal EX-50 Shield (Not Shown)

* Refer to this section for parts information.

Alphabetical Index

A

Adjuster wedges	9-19
Adjuster wedges, adjust	9-19
Air monitoring	5-1
Alarm assembly, gas detector	16-35
Arm & hydraulics assembly	16-9
Auxiliary flow switch	4-5, 6-12
Auxiliary tooling	4-5
Avoid laser light exposure	1-7
Avoid pinch points	1-3, 9-2
Avoid tunnel wall contact	1-5

B

Battery harness, disconnect	1-7
Be alert for safety information	1-1
Before performing maintenance	9-2
Before servicing, lockout tagout power	9-1
Belt conveyor	1-5
Belt conveyor, keep away from	1-5
Beware of suspended loads	1-2
Bolts, sae grade 8	16-2
Boom assembly	16-12
Boom assembly, inner	16-14
Boom assembly, rotary	16-16
Boom extend	4-4
Boom extension cylinder	12-1
Boom hoist cylinder	12-1
Boom hydraulic assembly, ex-50	16-26
Boom hydraulic schematic, ex-50	16-28
Boom rotation	12-1
Boom rotation toggle switch	4-4
Boom seal assembly, telescopic	16-23
Boom swing cylinder	12-1
Boring head 1 supply	6-7
Boring head 1 supply quick coupler hose	6-7
Boring head 2 motor	6-7
Boring shield shelves	4-4
Bucket, standard	16-24
Bucket cylinder	12-1
Bucket fittings, lubricate	9-11, 9-16
Bucket / hoist joystick	4-4

C

Caution	i
Certified electrician	4-3
Chain guard	9-18
Chatter/vibration	9-19
Check emergency stop operation	9-7
Check hydraulics after system start-up	6-10
Checklist	5-1
Checkout equipment prior to start-up	6-9
Clean and inspect equipment, regularly	1-3
Clean out cleanout cover	9-11, 9-16
Cleanout cover	9-11
Clean out debris	9-11

C (continued)

Clothing, wear protective	1-1
Cobble laden soil, hard or	6-12
Cold weather operation	6-14
Combustible gases	5-1
Completion of each drive	9-5, 9-17
Confined space permit	5-1
Confined spaces	6-1
Connecting electrical connections	6-6
Control box assembly, e-stop	6-3
Control console controls	4-4
Control console controls, operator	4-4
Control console decals	2-1
Control console & main power control box	2-1
Control console terminology	3-2
Control operations, check	9-8, 9-13
Conveyor, watch for	1-5
Cradles and supports	7-1
Crane operator	6-1
Crane, stay away from	1-3

D

Daily inspection	5-1
Daily or every 10 hours of operation	9-4, 9-12
Daily shutdown	6-15
Danger	i
Decal kit, ex-50	16-4, 16-5
Decals	5-1
Decals clean and readable	2-1
Decals, ex-50 excavator	2-2
Decals, inspect	9-10, 9-14
Decals, main power control box	2-1
Dirt bucket	6-12
Dirt guard assembly	16-22
Do not use ex-50 unsupported	1-5
Drive chain, lubricate	9-11, 9-15
Drive train tension	9-18
Drum cutter kit	16-39
Drum cutter & mounting assembly	16-40
Drum mounting assembly	16-40
Dual feed hydraulics	6-8

E

Electrical assembly, ex-50	16-30
Electrical box - e-stop assembly	16-34
Electrical connections, connecting	6-6
Electrical connections, inspect	1-3
Electrical - ex-50 main power control box	11-2
Electrical schematic, ex-50	16-32
Electrical work	4-2, 6-5
Electric/hydraulic connections, check	9-8, 9-12
Emergency stop	4-1
Emergency stop operation, check	9-12
Emergency stop, using	6-3
Enclosure assembly	16-36

E (continued)

E-stop assembly, electrical box 16-34
 E-stop control box assembly 3-2, 6-3
 E-stop on e-stop control box assembly 4-1
 E-stop on ex-50 control console 4-1, 6-3
 Ex-50 boom hydraulic assembly 16-26
 Ex-50 boom hydraulic schematic 16-28
 Ex-50 boom schematic 11-4
 Ex-50 control console, e-stop on 6-3
 Ex-50 control console schematic 11-3
 Ex-50 decal kit 16-4
 Ex-50 electrical assembly 16-30
 Ex-50 electrical schematic 16-32
 Ex-50 excavator decals 2-2
 Ex-50 main power control box 1-8, 3-2
 Ex-50 main power control box schematic 11-2
 Ex-50 operator shield decal kit 16-7
 Excavator boring shield 6-13
 Excavator boring shield (ebs) i
 Excavator & hoist assembly 16-10, 16-11
 Exposure to radiation 1-7
 Extend cylinder 16-20
 Extend cylinder & power chain assembly 16-20

F

Fastener hardware 16-2
 Fire extinguishers 6-1
 Fire prevention 1-6
 Firm footing in wet 1-6
 First-aid kit 1-1
 Fixed link assembly 16-41
 Flow rate/speed 4-5
 Fluids under pressure 1-2
 Frame advance cylinder 12-1
 Frame movement toggle switch 4-4
 Fresh air 6-1

G

Gas detector with alarm assembly 16-35
 Gases, combustible 5-1
 Gases, hazardous 6-4
 Gases, toxic 5-1
 Gauge operation, check 9-8, 9-13
 Gauge, system pressure 4-3
 Generator manufacturer 1-8
 Generator minimum motor starting kva 6-6
 Genuine akkerman parts 16-2
 Grease 8-1
 Green phase indicator light ... 4-2, 4-3, 5-1, 6-9, 9-9
 Guard assembly, dirt 16-22
 Guards 5-1, 6-8
 Guidance system, laser 6-5
 Guideline, lockout tagout procedure 1-8
 Guidelines, operating 6-1
 Guidelines, transporting 7-1

H

Hard ground 6-12
 Hard or cobble laden soil 6-12
 Hardware specification 16-2
 Haul unit, keep riders off 1-7
 Haul unit, lockout/tagout power before svcg 1-7
 Hazardous gases 6-4
 Hazardous voltage 4-3
 Hoist assembly, excavator & 16-10, 16-11
 Hydraulic controls 12-1
 Hydraulic hoses & power cables, inspect 9-17
 Hydraulic oil 6-10
 Hydraulic oil/fluids under pressure 1-2, 9-2
 Hydraulic oil level gauge 6-10
 Hydraulic oil reservoir 6-10
 Hydraulics after system start-up, check 6-10
 Hydraulics assembly, arm & 16-9
 Hydraulic valves 3-1

I

Identification numbers 13-1
 Indicators, power phase 4-2
 Inner boom assembly 16-14
 Inspect electrical connections 1-3
 Inspect equipment, clean regularly 1-3

J

Jack can retract 6-12
 Job site clean and organized, keep 1-6
 Joysticks i, 4-4, 6-12

K

Keep away from belt conveyor 1-5
 Keep first-aid kit accessible 1-1
 Keeping equipment from freezing 6-14
 Keep job site clean and organized 1-6
 Keep personnel away from moving parts 1-2
 Keep riders off haul unit 1-7

L

Laser guidance system 6-5, 6-11
 Laser light exposure, avoid 1-7
 Launch & operation procedure 6-11
 Launch procedure 6-11
 Left-hand joystick 4-4
 Lifting cables 6-5
 Lifting eyes, inspect 9-7, 9-17
 Liner plate i
 Lockout tagout power before servicing 9-1
 Lockout tagout power before servicing haul unit .. 1-7
 Lockout tagout procedure guideline 1-8
 Lock shackle 1-9
 Low-pressure oil 6-7
 Lubricants, storing 8-1
 Lubricate, drive train 9-18
 Lubricate ex-50 frame 9-14

L (continued)

Lubricate ex-50 frame lubrication points 9-9
 Lubricate swing bearing 9-15
 Lubrication intervals 9-1
 Lubrication & maintenance intervals 9-1
 Lubrication points 8-1

M

Main breaker, 5200 pump unit 1-8
 Main power control box 6-3
 Main power control box decals 2-1
 Main power control box lockout tagout 1-9
 Main power disconnect switch 4-3
 Main power from generator 6-6
 Main power panel 1-8
 Maintenance charts
 Prior To Each Drive..... 9-3
 Daily Or Every 10 Hours Of Operation 9-4
 Completion Of Each Drive 9-5
 As Required 9-6
 Maintenance instructions
 Prior To Each Drive..... 9-7
 Daily Or Every 10 Hours Of Operation 9-12
 Completion Of Each Drive 9-17
 As Required 9-18
 Maintenance on supporting equipment, perform.. 9-14
 Maintenance, practice safe 1-4
 Measurements 16-2
 Minimum motor starting kva, generator 6-6
 Mobilgrease® xhp222 8-1
 Motor mount plate 9-18
 Motor mount plate bolts 9-18
 Moving parts, keep personnel away from 1-2

N

Normal operating conditions 9-1
 No smoking in shaft or tunnel 1-6
 Notice i
 Nuts, sae grade 8 16-2

O

Obtain permits for transporting 7-1
 Oil manufacturers 6-10
 One-call 5-1
 Operating guidelines 6-1
 Operating power 6-6
 Operation, cold weather 6-14
 Operation procedure 6-11
 Operator control console controls 4-4
 Operator presense switches 4-4
 Operator presense switch lever 6-11
 Operator seat assembly 16-29
 Operator shield assembly 16-42
 Operator shield decal kit, ex-50 16-7
 Operator's shield 4-5, 6-12
 Osha regulations 5-1, 6-1

P

Perform maintenance on all supporting equipment
 9-10, 9-14
 Periodic maintenance 9-1
 Phase power, check 9-9, 9-13
 Pinch points, avoid 1-3
 Planning, site 6-4
 Power chain assembly 16-20
 Powered accessory 6-5
 Power phase indicators 4-2
 Power start-up procedure 6-9
 Practice safe maintenance 1-4
 Preparing for storage 10-1
 Prevent fire 1-6
 Prevent freezing 6-14
 Prior to each job launch 9-3, 9-7
 Prior to start-up, checkout equipment 6-9
 Pump unit main breaker 1-9
 Pump unit main breaker, 5200 1-8

R

Read operator's manual 1-1
 Recommended power requirements, 5200 6-6
 Recycle waste 1-7
 Red phase error indicator 9-9
 Red phase error indicator light 4-2, 6-9
 Red phase error light 4-3
 Regularly clean and inspect equipment 1-3
 Release of stored energy 1-8
 Removing from storage 10-1
 Return filter indicators 6-10
 Return line quick coupler hose 6-7, 6-8
 Riders, keep off haul unit 1-7
 Right-hand joystick 4-4
 Ring beam and lagging i, 6-2, 6-11
 Rotary boom assembly 16-16, 16-17
 Rotary tool 6-5
 Rotary tool/powerd accessory 6-5, 6-12
 Rv anti-freeze solution 6-14

S

Sae grade 8 bolts 16-2
 Safety data sheets 14-1
 Safety decals 9-10
 Safety information, be alert for 1-1
 Safety instructions i
 Safety program 5-1
 Sand soils 6-12
 Seat assembly, operator 16-29
 Select switch 4-4, 4-5, 6-12
 Setting up ex-50 supply/return hydraulics 6-7
 Setting up pump unit & ex-50 supply/return
 hydraulics 6-7
 Setting up pump unit supply/return hydraulics .. 6-7
 Setup, system 6-4
 Shackle 1-9

S (continued)

Shafts 6-1
 Shafts, launch and reception 6-4
 Shield, operator's 4-5
 Side wear pucks 9-19
 Signal person 6-1
 Single feed hydraulics 6-7
 Site planning 6-4
 Skid-resistant material 1-6
 Slide mount system i
 Slippery when wet 1-6
 Smoking in shaft or tunnel, no 1-6
 Solvent 9-10
 Specifications 12-1
 Standard bucket 16-24
 Start-up procedure, power 6-9
 Stay away from crane 1-3
 Storage, preparing for 10-1
 Storage, removing from 10-1
 Stored energy do not use ex-50 unsupported .. 1-5
 Storing lubricants 8-1
 Structures, inspect 9-7, 9-12, 9-17
 Supply/return hydraulics 6-7
 Supporting equipment 9-10
 Support ring 6-5
 Suspended loads 6-1
 Suspended loads, beware of 1-2
 Swing bearing hardware, inspect 9-10, 9-15
 Swing bearing lubricate 9-10
 Swing joystick 4-4
 Switch, auxiliary flow 4-5
 Switch, main power disconnect 4-3
 System pressure gauge 3-2, 4-3, 6-10
 System setup 6-4

T

Telescopic boom seal assembly 16-23
 Temperature 6-2
 Temperature, consistent 6-2
 Test tunnel ventilation 1-4
 Three-phase electrical power 4-2
 Thrust block 6-4, 6-5
 Thrust washers, inspect 9-11, 9-15
 Toggles 6-12
 Torque chart 12-2
 Toxic gases 5-1
 Trailer floor 7-1
 Transporting guidelines 7-1
 Tunnel building i
 Tunnel ventilation 5-1
 Tunnel ventilation, test 1-4
 Tunnel wall contact, avoid 1-5

U

Unauthorized modifications 1-1
 Unauthorized welding 1-2, 9-2
 Unexpected machine start up 1-8
 Unsupported ex-50 boom 1-5
 Using emergency stop 6-3
 Utility lines 5-1

V

Valve bank 12-1
 Ventilation detectors 5-1
 Ventilation system 6-5
 Ventilation, tunnel 5-1
 Visual machine inspection 6-15
 Void the warranty 1-2

W

Warning i
 Warranty 1-1, 15-1
 Warranty, void the 1-2, 6-1
 Washers, sae grade 8 16-2
 Waste, recycle 1-7
 Watch for conveyor 1-5
 Water 6-1
 Wear pads, top & side 9-18
 Wear protective clothing 1-1
 Wear pucks, side 9-19
 Wedge adjuster assembly 16-18
 Weight 12-1
 Welding, unauthorized 1-2
 Wet, slippery when 1-6

Numerical Index

PART NO.	PAGE NO.	PART NO.	PAGE NO.	PART NO.	PAGE NO.
002269P01	16-27	061439P	16-17	062166A	16-29
002624P00	16-23	061444P	16-13	062167A	16-29
007551P00	16-17	061445A	16-17	062186A	16-29
007552P00	16-17	061446P	16-17	062187A	16-29
008805A01	16-11	061447P	16-17	062194P	16-29
008810A05	16-11	061448A	16-13	062195P	16-29
008877P00	16-17	061448A	16-17	062196P	16-29
008878P00	16-17	061449P	16-17	062197P	16-29
008879P00	16-11	061456A	16-13	062198P	16-29
008957P00	16-11	061456A	16-19	062206P	16-27
008957P00	16-11	061457P	16-19	062206P	16-28
008958P00	16-11	061467A	16-21	062212A	16-9
009080A00	16-11	061476P	16-21	062212A	16-31
009822A00	16-11	061477P	16-21	062242A	16-31
011074P00	16-17	061478P	16-21	062243A	16-31
011115P00	16-11	061479A	16-21	062243A	16-36
011156P01	16-24	061480A	16-21	062244P	16-31
011156P01	16-40	061484A	16-21	062244P	16-32
011160P01	16-24	061486A	16-21	062292P	16-27
011160P01	16-40	061487P	16-21	062294P	16-27
011170P00	16-24	061489A	16-13	062317A	16-13
011170P00	16-40	061489A	16-21	062317A	16-23
011171P00	16-24	061492P	16-15	062318P	16-23
011171P00	16-40	061503A	16-13	062319P	16-23
011172P00	16-24	061503A	16-22	062320P	16-23
011172P00	16-40	061504P	16-13	062321P	16-23
013252A	16-11	061505P	16-13	062322P	16-23
019023A	16-31	061506P	16-13	062325P	16-24
019023A	16-34	061507P	16-13	062325P	16-40
019024P	16-34	061509P	16-19	062330P	16-13
021057P00	16-11	061510A	16-11	062332P	16-27
021057P00	16-13	061510A	16-13	062407P	16-17
031499A	16-31	061511P	16-22	062408A	16-21
031499A	16-35	061512P	16-22	062409P	16-21
031645P	16-35	061516A	16-22	062411A	16-21
06003A	16-9	061575P	16-11	062412A	16-13
061383A	16-13	061601A	16-17	062412A	16-24
061383A	16-15	061602P	16-17	062416A	16-21
061399P	16-15	061612A	16-9	062429P	16-21
061400A	16-15	061612A	16-11	062452P	16-21
061402P	16-15	062155A	16-9	062454P	16-13
061403P	16-15	062155A	16-26	062456P	16-13
061418P	16-17	062158A	16-9	062478P	16-17
061419A	16-17	062158A	16-29	062479A	16-17
061423A	16-17	062159A	16-29	062576A	16-40
061430P	16-17	062165P	16-29	062576A	16-41

Numerical Index

PART NO.	PAGE NO.	PART NO.	PAGE NO.	PART NO.	PAGE NO.
062577A	16-40	1255-142	16-7	P0001-06-005	16-21
062610P	16-41	1255-142	16-42	P0001-06-005	16-41
062611P	16-41	A09783A	16-31	P0001-06-006	16-13
062613A	16-41	A09889A-156	16-27	P0001-06-006	16-42
062614P	16-41	A10079A-018	16-27	P0001-06-008	16-41
062615P	16-41	A10079A-025	16-27	P0001-06-011	16-27
062621A	16-39	A10079A-026	16-27	P0001-06-012	16-24
062621A	16-40	A10079A-031	16-27	P0001-06-012	16-40
062638A	16-39	A10079A-036	16-27	P0001-06-014	16-24
062638A	16-42	A10079A-042	16-27	P0001-06-014	16-40
062639A	16-42	A10079A-048	16-27	P0001-08-005	16-13
062656P	16-42	A10079A-090	16-27	P0001-08-005	16-17
062657P	16-42	A10082A-076	16-27	P0001-08-006	16-11
062658A	16-42	A10313A-025	16-27	P0001-08-006	16-17
062659P	16-42	A10313A-036	16-27	P0001-08-006	16-19
062660P	16-42	A10324A-025	16-27	P0001-08-006	16-29
062737P	16-17	A10324A-066	16-27	P0001-08-007	16-17
062738P	16-17	A10324A-078	16-27	P0001-08-008	16-11
063003A	16-39	A10324A-098	16-27	P0001-08-008	16-17
1250-004	16-5	A10329A-XXX	16-39	P0001-08-040	16-13
1250-480	16-5	A10366A-032	16-27	P0001-10-007	16-13
1250-544	16-5	A10368A-060	16-27	P0001-10-009	16-11
1250-558	16-5	A10368A-XXX	16-39	P0001-12-007	16-15
1250-562	16-5	A10388A-017	16-27	P0001-12-012	16-40
1251-246	16-5	A10464A-104	16-27	P0003-04-000	16-35
1251-377	16-5	A10474A-028	16-27	P0003-05-000	16-29
1251-607AE	16-6	A10474A-046	16-27	P0003-06-000	16-24
1251-607AF	16-6	A11570P	16-42	P0003-06-000	16-40
1251-607CF	16-6	A61746A-116	16-27	P0003-08-000	16-13
1251-607CG	16-6	F62687F	16-9	P0003-08-000	16-17
1251-607CH	16-6	P0001-04-002	16-29	P0003-12-000	16-40
1251-607CI	16-6	P0001-04-002	16-35	P0004-05-000	16-27
1251-875	16-5	P0001-04-004	16-21	P0007-08-000	16-19
1252-233	16-7	P0001-04-005	16-42	P0011-006C	16-17
1252-234A	16-6	P0001-04-007	16-21	P0013-04-000	16-17
1252-234B	16-6	P0001-04-009	16-27	P0013-04-000	16-21
1252-234C	16-6	P0001-04-010	16-27	P0013-04-000	16-35
1252-234D	16-6	P0001-04-015	16-27	P0013-04-000	16-42
1252-235	16-5	P0001-05-002	16-21	P0013-05-000	16-22
1252-236	16-5	P0001-05-003	16-11	P0013-06A-000	16-42
1252-237A	16-6	P0001-05-003	16-13	P0013-08-000	16-11
1252-237B	16-6	P0001-05-003	16-21	P0013-08-000	16-29
1252-237C	16-6	P0001-05-003	16-26	P0017-14-204	16-36
1252-238	16-5	P0001-05-003	16-29	P0020-14-202	16-29
1252-240	16-6	P0001-05-004	16-23	P0020-83-022	16-36
1252-241	16-6	P0001-05-006	16-22	P0030-04-003	16-17
1252-242	16-6	P0001-06-003	16-17	P0030-04-003	16-21
1252-264	16-7	P0001-06-004	16-21	P0030-04-006	16-21
1255-136	16-5	P0001-06-004	16-29	P0030-05-003	16-15
1255-136	16-11	P0001-06-005	16-11	P0030-06-003	16-13

Numerical Index

PART NO.	PAGE NO.	PART NO.	PAGE NO.	PART NO.	PAGE NO.
P0030-06-003.....	16-15	P0050-238A.....	16-40	P0251-478.....	16-37
P0030-06-003.....	16-17	P0050-238B.....	16-39	P0251-480.....	16-37
P0030-06-004.....	16-13	P0050-238B.....	16-40	P0251-481.....	16-37
P0030-06-004A.....	16-29	P0051-007.....	16-24	P0251-482.....	16-37
P0031-08-005.....	16-15	P0051-008.....	16-24	P0251-616.....	16-37
P0031-08-012.....	16-11	P0054-012.....	16-31	P0251-806.....	16-37
P0031-08-018.....	16-11	P0054-012.....	16-36	P0251-841.....	16-37
P0031-10-016.....	16-17	P0054-013.....	16-36	P0251-855.....	16-37
P0034-08-012.....	16-19	P0054-014.....	16-36	P0251-861.....	16-35
P0035-016.....	16-21	P0054-067G.....	16-36	P0251-901.....	16-37
P0040-004.....	16-21	P0054-073A.....	16-31	P0251-906.....	16-37
P0040-004.....	16-27	P0054-073A.....	16-34	P0253-112.....	16-42
P0040-004.....	16-29	P0054-073B.....	16-36	P0300-012.....	16-35
P0040-004.....	16-35	P0054-136.....	16-31	P0300-116.....	16-27
P0040-004.....	16-42	P0054-286.....	16-35	P0300-143.....	16-21
P0040-005.....	16-11	P0054-288.....	16-31	P0300-200.....	16-21
P0040-005.....	16-13	P0054-347.....	16-31	P0300-202.....	16-39
P0040-005.....	16-21	P0054-402.....	16-36	P0300-300.....	16-26
P0040-005.....	16-22	P0054-700.....	16-31	P0300-305.....	16-21
P0040-005.....	16-23	P0055-157.....	16-37	P0300-305.....	16-27
P0040-005.....	16-27	P0056-121F.....	16-31	P0300-314.....	16-26
P0040-005.....	16-29	P0056-122F.....	16-31	P0300-325.....	16-21
P0040-006.....	16-11	P0056-122F.....	16-34	P0300-340.....	16-21
P0040-006.....	16-13	P0059-031.....	16-42	P0300-355.....	16-27
P0040-006.....	16-17	P0063-001.....	16-15	P0300-356.....	16-27
P0040-006.....	16-17	P0063-001.....	16-17	P0300-373.....	16-27
P0040-006.....	16-21	P0063-001.....	16-41	P0300-375.....	16-27
P0040-006.....	16-24	P0063-004.....	16-11	P0300-378.....	16-26
P0040-006.....	16-27	P0063-004.....	16-24	P0300-400.....	16-26
P0040-006.....	16-29	P0063-004.....	16-40	P0300-430.....	16-26
P0040-006.....	16-40	P0065-069.....	16-11	P0300-438.....	16-39
P0040-006.....	16-41	P0065-086.....	16-15	P0300-542.....	16-27
P0040-006.....	16-42	P0065-086.....	16-41	P0300-565.....	16-27
P0040-008.....	16-11	P0066-046.....	16-15	P0300-595.....	16-27
P0040-008.....	16-11	P0066-134.....	16-13	P0300-613.....	16-26
P0040-008.....	16-13	P0066-135.....	16-19	P0300-632.....	16-26
P0040-008.....	16-17	P0070-065.....	16-35	P0300-634.....	16-26
P0040-008.....	16-17	P0076-050.....	16-41	P0300-717.....	16-26
P0040-008.....	16-17	P0078-003.....	16-17	P0300-726.....	16-27
P0040-008.....	16-19	P0078-006.....	16-17	P0300-735.....	16-27
P0040-008.....	16-29	P0113-006.....	16-29	P0300-788.....	16-26
P0040-010.....	16-11	P0251-1023.....	16-37	P0300-877.....	16-27
P0040-010.....	16-13	P0251-1042.....	16-37	P0300-883.....	16-26
P0040-012.....	16-15	P0251-1043.....	16-37	P0300-923.....	16-21
P0040-012.....	16-40	P0251-1047.....	16-37	P0300-945.....	16-27
P0045-008.....	16-11	P0251-1065.....	16-35	P0302-174B.....	16-27
P0049-081.....	16-17	P0251-1065A.....	16-35	P0302-496.....	16-27
P0050-023.....	16-24	P0251-171.....	16-31	P0302-528A.....	16-31
P0050-238.....	16-40	P0251-171.....	16-34	P0302-819.....	16-27
P0050-238A.....	16-39	P0251-468.....	16-37	P0302-924.....	16-26

Numerical Index

PART NO.	PAGE NO.	PART NO.	PAGE NO.
P0302-928	16-31	P0315-002	16-29
P0302-929	16-31	P0315-004	16-29
P0302-930	16-31	P0405-002	16-35
P0304-134	16-17	PM10A-1.50-020	16-13
P0307-245	16-21	PM12A-1.75-050	16-19
P0307-246	16-15	S10057A	16-35
P0307-247	16-11		
P0307-248	16-11		
P0307-249	16-11		
P0307-254	16-11		
P0307-254	16-15		
P0307-254	16-21		
P0310-105	16-35		
P0310-105	16-37		
P0310-154	16-35		
P0310-283B	16-35		
P0310-419F	16-31		
P0310-419F	16-34		
P0310-420F	16-31		
P0310-420F	16-34		
P0310-421AF	16-31		
P0310-473B	16-37		
P0310-474F	16-6		
P0310-474F	16-6		
P0310-474F	16-34		
P0310-500	16-37		
P0310-503-006	16-37		
P0310-503-008	16-37		
P0310-571	16-37		
P0310-573	16-37		
P0310-795	16-37		
P0310-899	16-37		
P0310-954	16-37		
P0311-013	16-37		
P0311-018	16-34		
P0311-020	16-37		
P0311-034	16-37		
P0311-112	16-37		
P0313-007	16-31		
P0313-007	16-37		
P0313-008	16-31		
P0313-049	16-37		
P0313-066A	16-31		
P0313-066B	16-31		
P0313-066B	16-37		
P0313-067	16-31		
P0313-067A	16-31		
P0313-068A	16-37		
P0313-068B	16-37		
P0313-142	16-21		

NOTES