



OPERATION & PARTS MANUAL

Lubrication Pump EH2325

Pump S/N: F61600F

Publication No. 050175A

Rev. No. 231220

© Akkerman Inc. 2023
All Rights Reserved

Akkerman Inc. 58256 266th Street Brownsdale, MN 55918
Phone: 507-567-2261 Fax: 507-567-2605 email: akk@akkerman.com

SERVICE • RELIABILITY • INNOVATION

Introduction

This manual contains important safety, operation, maintenance, and parts information for your Akkerman EH2325 Lubrication Pump. You must read and understand this manual and any additional equipment manuals before you operate and maintain this equipment. Keep this manual with your EH2325 Lubrication Pump at all times. Additional copies of this manual may be purchased from the Akkerman Aftermarket Support Department, or downloaded from the Akkerman web site at www.akkerman.com.

The contractor is responsible for the overall safety program on the job site. Use this manual as a part of the safety program.

The use of second rate parts could affect the efficient performance of the EH2325 Lubrication Pump. ALWAYS use genuine Akkerman parts.

Understand safety signal words, DANGER, WARNING, CAUTION, SAFETY INSTRUCTIONS, and NOTICE. When you see these words in this manual or on safety decals mounted on your equipment, follow the safety message to avoid personal injury and/or property damage.


▲ DANGER Indicates an extremely hazardous situation which, if not avoided, WILL result in death or serious injury.

▲ WARNING Indicates a potentially hazardous situation which, if not avoided, COULD result in death or serious injury.

▲ CAUTION Indicates a potentially hazardous situation, which, if not avoided, MAY result in minor or moderate injury. It may also be used to alert against unsafe practices.

SAFETY INSTRUCTIONS Usually consists of individual messages stating procedures or actions that must be followed for the safe operation of a product.

NOTICE Identifies potential property damage and important installation, operator, or maintenance information.



Akkerman EH2325 Lubrication Pump

The electro-hydraulic EH2325 Lubrication Pump lubricates the outside of the pipe to reduce friction between the pipe and ground and decrease thrust loads on pipe jacking and microtunneling operations. The control valve provides an efficient and effective means of bentonite injection. The in-tank hydraulic mixers prevent settlement. The Moyno[®] pump provides continuous, non-pulsating output at high volume.

If you find any errors with this manual or have any suggestions for improvement, please let us know. Email your comments via the Akkerman web site (Contact Us web page), or mail your suggestions to: Akkerman Inc, ATTN: Technical Publications, 58256 266th Street, Brownsdale, MN 55918.

Akkerman Inc. reserves the right to improve its product without notice or obligation.

NOTES

Contents

Safety	1-1	Transporting	7-1
Be Alert For Safety Information	1-1	Transporting Guidelines	7-1
Read Operator's Manual	1-1	Lifting Instructions	7-1
Wear Protective Clothing	1-1	Lubricants	8-1
Hydraulic Oil/Fluids Under Pressure	1-2	Hydraulic Tank Oil	8-1
Beware Of Suspended Loads	1-2	Electric Motor Bearing Grease	8-1
Avoid Contact With Mixer Shaft & Propeller... ..	1-2	Storing Lubricants	8-2
Lockout/Tagout Power Before Servicing	1-3	Periodic Maintenance	9-1
Exposure To Dangerous Chemicals	1-3	Lockout/Tagout Power Before Service	9-1
Inspect Electrical Connections	1-3	Hydraulic Oil/Fluids Under Pressure	9-1
Avoid Pinch Points	1-4	Avoid Pinch Points	9-1
Keep Personnel Away From Moving Parts	1-4	Maintenance Charts	9-2
Fire Prevention	1-4	Daily Or Every 10 Hours Of Operation	9-2
Be Careful Of Oil Cooler Fins	1-4	Weekly Or Every 50 Hours Of Operation ...	9-3
Unauthorized Welding	1-5	Monthly Or Every 250 Hours Of Operation ...	9-4
Regularly Clean & Inspect Equipment	1-5	Every 500 Hours Of Operation	9-4
Practice Safe Maintenance	1-5	After Each Drive	9-5
Slippery When Wet	1-6	Annually	9-5
Keep Job Site Clean & Organized	1-6	Maintenance Instructions	9-6
Recycle Waste	1-6	Daily Or Every 10 Hours Of Operation	9-6
Lockout Tagout Procedure Guideline	1-8	Weekly Or Every 50 Hours Of Operation..	9-10
Decals	2-1	Monthly Or Every 250 Hours	9-11
Terminology	3-1	Every 500 Hours Of Operation	9-12
EH2325 Lubrication Pump	3-1	After Each Drive	9-13
Control Panel	3-2	Annually	9-14
Controls & Instruments	4-1	Storage	10-1
Pump Control	4-1	Preparing For Storage	10-1
Bentonite Flow Control	4-1	Removing From Storage	10-2
In-Tank Mixer Controls	4-2	Troubleshooting	11-1
Tank Suction Valves	4-3	Specifications	12-1
Recirculation Valves	4-3	EH2325 Lubrication Pump	12-1
Discharge Outlet Shutoff Valve	4-3	Torque Chart	12-2
Hydraulic Tank	4-4	Identification Numbers	13-1
Hydraulic Return Filter Indicator	4-4	Safety Data Sheets	14-1
Control Panel	4-4	Warranty	15-1
Pre-Start Inspection	5-1	Parts	16-1
Operation	6-1	Introduction	16-2
Operating Guidelines	6-1	Decals	16-4
Lubrication Guidelines	6-2	Parts	
Setting Up Lubrication Pump	6-3	EH2325 Lubrication Pump	16-8
Setting Up The Electric Motor	6-4	Alphabetical Index	17-1
Starting The Electric Motor	6-5	Numerical Index	18-1
Shutting Down The Electric Motor	6-5		
Start Up Procedure	6-6		
Daily Shutdown	6-8		
Mixing Tanks	6-10		
Using Recirculation Valves To Transfer Fluid ..	6-12		
Cleaning Tanks	6-14		
Cold Weather Operation	6-17		
Cold Weather Protection	6-18		

Safety

BE ALERT FOR SAFETY INFORMATION

When you see this safety alert symbol on your equipment or in this manual, be alert to the possibility of personal injury or property damage.

Read all safety information.

Keep safety decals clean and in good condition.
Replace missing or damaged safety decals.




**ATTENTION!
BECOME ALERT!
YOUR SAFETY IS INVOLVED!**

READ OPERATOR'S MANUAL

⚠ WARNING Unsafe operation or maintenance can cause severe injury or death.

Read and understand the Operator's Manual before operating or servicing this equipment.

Any unauthorized modifications will void the warranty.



WEAR PROTECTIVE CLOTHING

Wear OSHA approved protective clothing, such as hard hat, gloves, safety goggles, earmuffs or ear plugs, face shield, and steel-toed boots, when operating and servicing this equipment.

Wear reasonably close fitting clothing and remove jewelry before working on or near this equipment. This will help prevent the danger of catching them in moving parts or controls.



HYDRAULIC OIL/FLUIDS UNDER PRESSURE

⚠ WARNING Escaping oil or other fluids under pressure can penetrate your skin causing serious injury.

Release all pressure before performing maintenance or repairs. Never weld near pressurized fluid lines.

DO NOT use your hands to check for leaks. When searching for leaks, use a piece of wood or cardboard.

Contact medical help immediately if any oil or fluid is injected into your skin. A serious infection or reaction can emerge without proper medical treatment.




BEWARE OF SUSPENDED LOADS

⚠ WARNING Suspended loads may fall and cause severe personal injury or death.

If a hydraulic hose, chain, or cable from the boom of a crane or excavator breaks, the boom and/or load can fall instantly.

Do not enter area under or around a load.



AVOID CONTACT WITH MIXER SHAFT & PROPELLER

⚠ WARNING Contacting shaft or propeller may cause serious injury.

Keep ALL parts of body and foreign objects from coming in contact with mixer shaft or propeller during operation.



LOCKOUT TAGOUT POWER BEFORE SERVICING

⚠ DANGER Failure to lockout tagout power before servicing will cause severe personal injury or death.

LOCKOUT TAGOUT power before attempting to make repairs or adjustments to this equipment, unless otherwise indicated. Proper lockout tagout will prevent accidents and save lives. Performing the lockout tagout will also prevent the equipment from moving or operating unexpectedly.

Refer to Lockout Tagout Procedure Guideline in this section for more information.




EXPOSURE TO DANGEROUS CHEMICALS

⚠ WARNING Exposure to chemicals may cause serious injury or death.

BEFORE mixing chemicals or other agents in the jetting and/or lubrication tanks, be sure the area is well ventilated and other personnel removed from the area.

Use proper personal protective equipment per the chemical manufacturer's instructions.



INSPECT ELECTRICAL CONNECTIONS

⚠ WARNING Regularly inspect electrical connections to be sure they are secure. Failure to do so could cause an explosion if moisture enters a unsecured electrical connection.




AVOID PINCH POINTS

⚠ WARNING Moving parts or the mishandling of parts can cause severe personal injury.

Keep hands away from moving parts.

Watch your fingers, hands, and legs while equipment is in operation.

Handle parts carefully to avoid crushing and pinch point hazards.



KEEP PERSONNEL AWAY FROM MOVING PARTS

⚠ WARNING Crushing hazard.
Keep personnel away from inside of jacking frame.
Failure to do so could result in serious personal injury or death.



FIRE PREVENTION

⚠ CAUTION Fires can cause injury or property damage.

Keep equipment clean. Remove all debris from equipment.

Have a fire extinguisher available at all times. Keep the fire extinguisher fully charged.



BE CAREFUL OF OIL COOLER FINS

⚠ WARNING Oil cooler fins are SHARP and may cause injury if touched.

Oil cooling system may be HOT and cause severe burns if contacted.


Always use gloves when near the oil cooler.
Perform service on oil cooler only when cool.



UNAUTHORIZED WELDING

⚠ WARNING Unauthorized welding can cause structural failure resulting in possible injury or death.


Do not weld on any structural member. Unauthorized welding or repair will void the warranty.



REGULARLY CLEAN AND INSPECT EQUIPMENT

Remove any grease, oil, or debris buildup to avoid potential injury or equipment damage.

Inspect equipment for damage. If damaged, repair or replace immediately.



PRACTICE SAFE MAINTENANCE

⚠ WARNING Unexpected movement may cause serious personal injury.

Shutdown engine before performing any maintenance, adjustments, or removing obstructions.

Only trained and qualified personnel should perform any maintenance or repairs.

Keep the area around the equipment clean and dry when performing maintenance.

Do not service the machine while it is in operation.

Replace worn or damaged parts. Remove grease, oil, or debris buildup.



SLIPPERY WHEN WET

⚠ WARNING Slips and falls can cause serious personal injury.

Ensure firm footing in wet or slippery conditions.

Replace skid-resistant material if it is damaged or missing to prevent slips and falls.

Remove any buildup of grease, oil, or debris.



KEEP JOB SITE CLEAN AND ORGANIZED

⚠ WARNING Tripping can cause serious personal injury.


Be sure to keep job site clean and organized.



RECYCLE WASTE

Follow local, state, federal, and international regulations when recycling or disposing of waste. Waste includes fluids/oil, fuel, filters, coolant, and batteries.

Use leakproof containers when draining fluids/oil. Do not pour waste on the ground, down a drain, or into any water source.




NOTES

LOCKOUT TAGOUT PROCEDURE GUIDELINE

LOCKOUT TAGOUT power before attempting to make repairs, service or adjustments. Proper lockout tagout will prevent accidents and save lives. OSHA requires equipment placed in lockout tagout when the unexpected machine start up or release of stored energy could injure workers during cleaning, adjustments, repairing and servicing.

⚠ DANGER Failure to lockout tagout power before adjustments, repairs or servicing **WILL** cause severe personal injury or death.

LOCKOUT TAGOUT power before adjustments, repairs or servicing. Electrical repairs must be performed only by a certified electrician.




The contractor is fully responsible for the safety of all personnel on the job site. Use the following as a guideline for a lockout tagout procedure. The contractor must determine the best lockout tagout practices for his/her employees on the job site.

1. Follow all Federal, State and Local safety regulations and procedures.
2. Be sure OSHA prescribed safety personal protective equipment is being worn by all personnel.
3. Be sure the area is safe for operation. Keep work site clean and organized.
4. Set all controls to the OFF or neutral position.
5. Push IN all E-Stop buttons (if equipped).

6. There are two lockout tagout options for the EH2325 Lubrication Pump:

- Lockout Tagout the Power Source
- refer to step 7 for details.
- Lockout Tagout the EH2325 Control Panel Box
- refer to step 8 for details.



7. Lockout Tagout the Power Source Option


Lockout Tagout power source or generator. Refer to the power source or generator manufacturer for proper lockout tagout procedure.

(Continued on next page)



8. Lockout Tagout the EH2325 Control Panel Option

- Be sure the main power disconnect switch (A) on the control panel box is in the OFF position.
- Flip safety latch (B) out on main power switch and install shackle of OSHA approved lock (C) with tag (D) through latch.
- Secure lock by pushing shackle into body of the lock until the shackle is locked into the locking mechanism. Turn key to lock shackle in place.
- Remove key from lock.
- Test to be sure shackle is fully secured into lock.
- Sign "Equipment Locked Out" tag or equivalent.




NOTES

Decals

Keep all decals clean and readable. Use soft cloth, water, and a mild soap to clean the decals if they are too dirty to read. DO NOT clean decals with solvent. Solvent can damage them. Replace safety decals immediately if they are damaged, missing, or hard to read.

Serious injury or property damage can occur if safety instructions are not followed. Contact your Akkerman Aftermarket Support representative for free replacement safety decals.


If a part is replaced that has a decal on it, apply a new decal to the replacement part. Before applying a new decal, be sure the surface is clean and dry.



EH2325 Right View Shown

(Continued on next page)


Decals (Continued)



EH2325 Left View Shown


Terminology

Eh2325 LUBRICATION PUMP



- | | | |
|-----------------------------|------------------------------------|-------------------------------------|
| 1. Left Tank Mixer PSI | 13. Removable Reducer Coupling | 25. Triple Pump |
| 2. Left Tank Mixer Control | 14. Mix Tube | 26. Bentonite PSI Reducing Valve |
| 3. Right Tank Mixer PSI | 15. Agitator Chamber | 27. Tank Suction Valve - Right Tank |
| 4. Right Tank Mixer Control | 16. Step | 28. Moyno Pump |
| 5. Storage Basket | 17. Mixer Motor With Propeller | 29. Tank Suction Valve - Left Tank |
| 6. Hydraulic Return Filter | 18. Electric Motor 30 HP | 30. Bentonite Flow Control |
| 7. Hydraulic Tank (25 gal.) | 19. Discharge Shutoff Valve | 31. Hydraulic Pump Drive Motor |
| 8. Tank Lid | 20. Discharge Outlet | 32. Bentonite Pump Discharge PSI |
| 9. Shelf | 21. Right Tank Recirculation Valve | 33. Oil Cooler |
| 10. Left Tank (325 gal.) | 22. Left Tank Recirculation Valve | 34. Pump Control |
| 11. Control Panel | 23. Bentonite Relief Valve | 35. Pump PSI |
| 12. Right Tank (325 gal.) | 24. Manual Storage Tube | 36. Mixer Speed Control - Right |
| | | 37. Mixer Speed Control - Left Tank |

CONTROL PANEL - EH2325



1. Stop Switch
2. Main Power Disconnect Switch
3. Start Switch
4. Hourmeter

Controls & Instruments

PUMP CONTROL

IMPORTANT: NEVER dry run or operate pump with both suction valves closed at the same time. Doing so WILL cause pump damage.

The Pump Control (A) is used to turn the Moyno pump on and off.


Pump ON	- Up Position
Pump OFF	- Down Position

Before starting pump:

1. Pump control lever must be OFF.
2. Mixer controls must be OFF.
3. At least one of the suction valves must be open.
4. There must be enough water/solution in each tank to cover inlet.

The Pump PSI gauge (B) indicates the hydraulic pressure to pump the fluid. Typically the gauge will register 500 - 2,000 psi, depending on the application.

Maximum pressure is 2,000 psi (13,790 kPa).




BENTONITE FLOW CONTROL

The Bentonite Flow Control (C) is used to regulate the fluid for lubricating the pipe line (bentonite injection) and for tank recirculation. The control is adjusted between 0 - 10 (0 to 100%), with 10 being the maximum output.


The Bentonite Pump Discharge Pressure is shown on gauge (D).

- 25 gpm max at 0 psi
- 18 gpm at 225 psi



IN-TANK MIXER CONTROLS

The in-tank mixers (A) aggressively mixes liquid based polymers and bentonite to prevent fluid settlement. The mixers are controlled with the Tank Mixer controls (B) (Left and Right tanks) and regulated with the Mixer Speed controls (C).




The Tank Mixer Controls (B) are used to turn the right and left tank mixers on and off.

Mixer ON	- Up Position
Mixer OFF	- Down Position

The Tank Mixer PSI gauge (B) indicates the hydraulic pressure to operate the mixer.

Maximum pressure is 2,000 psi (13,790 kPa).




The Tank Mixer Speed Controls (C) are used to regulate the speed of the mixers.



TANK SUCTION VALVES

The tank suction valves (A - left tank, B - right tank) are used to open and close the tank supply outlets.

NOTICE At least one of the tank shutoff valves **MUST** be open before starting the pump. Failure to do so **WILL** cause damage to pump and cause the hydraulic oil to heat up.




RECIRCULATION VALVES

The EH2325 Bentonite Pump is equipped with recirculation valves so the solution can be transferred from a full tank to an empty tank.

Open the suction valve on the full tank and open the recirculation valve on the empty tank. Then close the discharge shutoff valve. Start the pump and set the flow to the desired speed.

Left Tank Recirculation Valve (C)
Right Tank Recirculation Valve (D)




DISCHARGE OUTLET SHUTOFF VALVE

The Discharge Outlet Shutoff Valve (E) will open and close the discharge outlet.

Use the shutoff valve to close the discharge outlet when recirculating solution.

Remove/install plug (F) as needed per operation.

NOTICE If outlet shutoff valve is left open or outlet is unplugged, the fluid may slowly leak from tanks through pump and out the discharge outlet.



HYDRAULIC TANK

The hydraulic tank provides hydraulic oil for the Moyno pump and mixer motors. The tank includes a temperature and sight gauge (A).

Fill oil until fluid reaches high mark on sight gauge.


Recommended hydraulic oil:

Ambient Temp.	Hydraulic Oil
below 70°F (21°C)	ISO 46
above 70°F (21°C)	ISO 68

NOTICE

Do not mix oil manufacturers or grades.

Hydraulic oil tank capacity is 25 gal. (94.6 L).




HYDRAULIC RETURN FILTER INDICATOR

To prevent over or under servicing of the hydraulic return filter, a filter indicator (B) has been installed on the return filter housing.

The green OK zone indicates that the filter is functioning properly.

The yellow zone indicates that the filter will soon require replacement.

When the needle on the gauge is in the red CHANGE zone, replace filter as soon as possible to prevent component damage (for more information, refer to Check Hydraulic Return Filter in section 9, Periodic Maintenance).



CONTROL PANEL

The control panel consists of the start button, stop button, hourmeter and the main power disconnect switch.


Flip the main power disconnect switch (C) to the ON and OFF position.

Start and stop the electric motor by depressing the Start button (D) and the Stop button (E).

The input power is monitored for proper three phase electrical power:

- After turning power on, if the green START light is illuminated, the power is in proper phase and the motor can be started. After pressing START button, the red STOP light will illuminate.
- If the green START light is NOT illuminated after turning power on, the power is NOT in proper phase. The motor cannot be started. A certified electrician must reverse two of the generator power leads.

The hourmeter (F) registers in full and 1/100ths hours.



Pre-Start Inspection

⚠ WARNING

Do not operate this equipment until you read, study, and understand this manual and any other equipment manuals that may be used. A daily inspection of the equipment must be performed to prevent severe personal injury or death and equipment damage.

The contractor is fully responsible for the safety of all personnel on the job site. Check with the contractor that all site preparation requirements are in place. Be sure to comply with all MSHA and OSHA regulations, such as: an active safety program is in practice, a confined space permit (if needed) is issued, personal protective equipment is being worn; flammable, combustible, and hazardous materials are properly stored; and a lockout/tagout procedure is in place (for more information, refer to section 1, Safety, Lockout Tagout Procedure Guideline).

Use the following checklist ✓ as a guide for your daily pre-start inspection.

	1. Follow the MSHA (Mining Safety & Health Administration) and OSHA (Occupational Safety & Health Administration) regulations.
	2. Contractor is responsible for all personnel to wear proper protective equipment on the job site. Replace equipment if defective.
	3. Combustible, toxic and oxygen deficiency detectors MUST be in place, tested, and in proper working condition.
	4. A qualified electrician must check that all electrical connections are properly secured and grounded prior to operation.
	5. BEFORE connecting EH2325 to 480V power source, be sure the Main Power Disconnect switch is in the OFF position.
	6. Once power is properly connected, flip main power disconnect switch ON and check for proper motor rotation. If not, lock out/tag out power and switch phase connections and retest.
	7. Water/solution must be in tanks prior to start up.
	8. Be sure Pump and Mixer Controls are in the OFF position.
	9. Be sure pump shaft control shutoff valves are in Bypass position.
	10. The tank suction valves MUST be open prior to starting the pump.
	11. All pump connections must be secure to prevent cavitation.
	12. USE ONLY CLEAN WATER SOURCE.
	13. Check controls and switches for proper operation. Repair or replace if damaged or worn.
	14. Remove combustible or flammable materials from equipment. Store materials properly.
	15. Check hydraulic oil level. Add as needed.
	16. Check controls and switches for proper operation. Repair or replace if damaged or worn.
	17. Inspect equipment for damage. Repair or replace as needed.
	18. Thoroughly clean equipment of mud and dirt.
	19. Be sure all covers and guards are in place and securely fastened before operation.
	20. Check for loose or missing hardware. Replace damaged or missing hardware.
	21. Check for worn, loose, or damaged wire connections. Repair or replace wiring connections.
	22. Tighten loose clamps or fittings.
	23. Check for fluid leaks. Repair leak or replace components.
	24. If operating in freezing weather, be sure to constantly mix water/solution to prevent freezing.
	25. If EH2325 will be shut off for a considerable length of time and the temperature is at or below freezing, flush and drain pump, suction manifold, ALL fluid lines and tanks. Treat with RV anti-freeze.
	26. Keep job site clean and organized.

NOTES

Operation

OPERATING GUIDELINES

⚠WARNING Do not operate this equipment until you read, study, and understand this manual and any additional equipment manuals before you operate this equipment. Failure to do so, could result in severe personal injury or death.

1. Before operating, read and understand the Safety, Pre-Start Inspection, and Operation sections.
2. Do not operate this equipment while under the influence of alcohol, drugs, or medication.
3. Follow all Federal, State, and Local safety regulations and procedures.
4. Be sure OSHA prescribed safety protective equipment is being worn by all personnel.
5. Be sure the area is safe for operation. Keep work site clean and orderly.
6. Have a fully charged fire extinguisher on the job site at all times.
7. Before operating, inspect equipment and conduct repairs as needed.
8. Test the electrical motor for proper rotation prior to operating the lubrication pump.
9. Test air monitoring and ventilation detectors for proper operation. Never enter a tunnel or shaft without combustible gas detectors and oxygen deficient detectors.
10. Never walk or work under any part of the excavator or crane and suspended loads.
11. Do not make any modifications to any Akkerman products. Doing so could cause structural failure and will void the warranty.
12. Check shields and guards. They must be in place and undamaged prior to operation.
13. The tank suction valves MUST be open and the tanks filled with water/solution prior to startup. Failure to do so WILL cause damage to pump.
14. Check all fluid levels before operating. Add as necessary.
15. Remove combustible or flammable materials from equipment.
16. Test all controls and switches to make sure they operate properly.
17. Place all controls in the OFF position before start up.
18. Eye, ear and respiratory protection MUST be worn by operator while filling tanks with chemicals such as wetting agents, polymer, etc.
19. Never dry run or operate pump with tank suction valves closed.
20. In cold weather operation, constantly circulate water/solution to prevent freezing.
21. At daily shutdown or if pump will not be operated for a prolonged period of time in freezing weather, flush and drain pump and ALL fluid lines to prevent clogging or freezing.
22. Keep ALL parts of the body and foreign objects from coming in contact with mixer shaft or propeller during pump operation.
23. If repairs, adjustments or removing obstructions from mixing tanks are necessary, before making repairs etc., be sure to lockout/tagout power source to prevent accidental starting of equipment (for more information, refer to section 1, Safety, Lockout Tagout Procedure Guideline).
24. If this manual is lost, contact your Akkerman Aftermarket Support Representative for a new manual or download this manual from the Akkerman web site at www.akkerman.com.

LUBRICATION GUIDELINES

The lubrication type or mixture is based on soil conditions, consistency, clay, sand, cobble, rock, etc. Your polymer supplier can help you with the proper lubrication mixture based on your Geotech report for the project. The amount of bentonite is typically provided with the engineering project data requirements.

As a guideline, typical usage of lubricant as a **minimum** can be calculated with the following formula:

$$0.04 \times [\text{Overcut} - \text{Pipe OD}] = \text{Gallons of Bentonite per foot of advancement}$$

Example Using the Formula:

For a 72" OD Pipe With a 73.5" OD Overcut

$$0.04 \times [73.5^2 - 72^2] = \text{Gallons of Bentonite}$$

$$[5402 - 5184]$$


$$0.04 \times [218]$$

$$218 \times 0.04 = 8.72 \text{ gallons (minimum) of bentonite per foot of advancement}$$

Keep in mind the geology of the project will affect the volume of lubricant required as noted:

- Nonconductive Geology (Clay / rock) will generally use the minimum volume calculation.
- Conductive Geology (sand / gravel [voids]) will require an additional amount of lubricant than the minimum volume calculation.

Use the Bentonite Flow Control (A) to adjust the lubricant flow for lubricating the pipe line (bentonite injection) and for tank recirculation.



SETTING UP LUBRICATION PUMP

1. Position the Lubrication Pump on firm, level ground near desired area of use.


⚠ WARNING Do not position the pump near the edge of shaft where the ground may be unstable and cause a slide or cave-in. Doing so could cause severe injury or death.

2. Connect a 2 in. hose to the discharge outlet hose connection or a reducer adapter to hose. *Recommended that reducer is no smaller than 1 in hose connection.*




3. **Microtunneling:**

- Connect outlet hose to:
 - a. wall valve bentonite connection (A) or
 - b. ABIS system and then connect hose from ABIS to wall valve bentonite connection (A).
- Connect hose to bentonite outlet connection on wall valve and then to pipe bentonite pump line/hose connection (B).



4. **TBM:**

- Connect outlet hose to:
 - a. pipe bentonite pump line/hose connection (B) or
 - b. ABIS system and then connect hose from ABIS to pipe bentonite pump line/hose connection (B).



5. Once the outlet hose is properly connected, proceed to Setting Up The Electric Motor on the next page.



SETTING UP THE ELECTRIC MOTOR

⚠ DANGER Hazardous voltage.

Failure to lockout/tagout power before connecting power leads or performing service, WILL cause severe personal injury or death.

LOCKOUT TAGOUT main power supply BEFORE connecting power leads or performing service (refer to Section 1, Safety, Lockout Tagout Procedure Guideline). Electrical connections and repairs must be performed only by a certified electrician.



1. Turn OFF power source and perform lockout/tagout procedure (refer to Section 1, Safety, Lockout Tagout Procedure Guideline).
2. Test to ensure no voltage is present.
3. Be sure main power disconnect switch (A) is in the OFF position.
4. Connect the EH2325 power cables to a 480 VAC, 60 cycle, 3 phase power source.

Recommended Power Requirements:

- Recommended Operating Pwr: 40kW / 50 kVA @ 480VAC
- Generator Minimum Motor Starting KVA: 115 skVA with less than 30% instantaneous voltage dip and greater than 90% sustained voltage.


5. The input power is monitored for proper three phase electrical power. Flip the main power disconnect switch (A) to the ON position.
 - After turning power on, if the green START light is illuminated, the power is in proper phase and the motor can be started. After pressing START button, the red STOP light will illuminate.
 - If the green START light is NOT illuminated after turning power on, the power is NOT in proper phase. The motor cannot be started. A certified electrician must reverse two of the generator power leads.
6. Double check motor for proper rotation. Momentarily start and then stop the 30HP electric motor and check for proper rotation. If the rotation is incorrect, have a certified electrician switch the two generator power leads. Then recheck motor for proper rotation.

7. Proceed to Start Up Procedure in this section.




STARTING THE ELECTRIC MOTOR

1. Set up the electric motor for operation. Refer to Setting Up The Electric Motor in this section.
2. Proceed to Start Up Procedure in this section. DO NOT start the electric motor without following the start up procedure. Doing so may cause pump damage. NEVER dry run pumps.



SHUTTING DOWN THE ELECTRIC MOTOR

1. Depress Stop button (A).
2. Move main power disconnect switch (B) to the OFF position.
3. Perform lockout tagout procedure (refer to Section 1, Safety, Lockout Tagout Procedure Guideline) to main power source to prevent any accidental starting of the EH2325 Bentonite & Lubrication Pump.



START UP PROCEDURE

⚠ DANGER Hazardous voltage.

Failure to lockout tagout power before connecting power leads or performing service, WILL cause severe personal injury or death.

LOCKOUT TAGOUT main power supply BEFORE connecting power leads or performing service (refer to Section 1, Safety, Lockout Tagout Procedure Guideline). Electrical connections and repairs must be performed only by a certified electrician.



1. Set up the electrical motor for operation. Refer to Setting Up Electrical Motor in this section.
2. Be sure main power disconnect switch (A) is in the OFF position.



3. Check hydraulic oil tank level. Add oil if necessary.



4. Add CLEAN water in tanks before starting the electric drive motor. Replace tank lid securely to prevent foreign objects from entering tank.

NOTICE NEVER dry run pumps. Doing so will result in pump damage.




(Continued on next page)

5. Be sure at least one of the tank suction valves is open.



6. Place Pump Control (A) and both Tank /Mixer Controls (B) in the OFF position.



9. Move main power disconnect switch to the ON position.




10. Depress Start button.

11. Check for leaks.



DAILY SHUTDOWN

1. Place Pump Control (A) and both Tank /Mixer Controls (B) in the OFF position.



2. Place both Mixer Speed controls (C) in the Slow position.




3. Close both tank suction valves.



4. **BRIEFLY** turn Pump (D) ON until pressure decreases on discharge pressure gauge (E) to empty discharge line to prevent the lubricant from settling in the lines overnight. Be sure to shut pump OFF.

IMPORTANT: Do not dry run pump. Doing so WILL damage the pump.



(Continued on next page)

5. Close the discharge outlet shutoff valve.



6. Depress Stop button.



7. Move main power disconnect switch to the OFF position.



8. Perform Lockout Tagout procedure to main power source to prevent any accidental starting of the EH2325 Lubrication Pump (refer to Section 1, Safety, Lockout Tagout Procedure Guideline).

9. If the potential of freezing weather exists, refer to Cold Weather Protection in this section.



MIXING TANKS

⚠ WARNING Contacting shaft or propeller may cause serious injury.


Keep ALL parts of body and foreign objects from coming in contact with mixer shaft or propeller during operation.



⚠ WARNING Exposure to chemicals may cause serious injury or death.

BEFORE mixing chemicals or other agents in the jetting and/or lubrication tanks, be sure the area is well ventilated and other personnel removed from the area.

Use proper personal protective equipment per the chemical manufacturer's instructions.



1. Fill water tank with clean water as needed per instructions on lubricant packaging.

NOTICE Before mixing polymers and bentonite, the water should be stabilized to the following pH and hardness levels:

pH	8.5 - 9.5
Water Hardness	do not exceed 200 ppm (depending on lubricant)

Note:

- a. Pure water is neutral with a pH level of 7.
- b. Soda ash helps lower water hardness as well as raise the pH simultaneously.




2. Close tank suction valve(s) for mixing in the tank.

IMPORTANT: If mixing while pumping lubricant to prevent settlement, open tank suction valve(s). NEVER dry run pump. Doing so WILL cause pump damage.



(Continued on next page)

- Place Pump Control (A) and Mixer Controls (B) in the OFF position. Mixer Speed Controls should be in the SLOW position.



- Start electric motor.




- Flip the desired Tank Mixer control to the ON position.



- Adjust Mixer Speed control as needed.




- Remove cover on tank to gain access to hopper (C).
- Gradually pour lubricant into hopper in tank, following instructions on packaging (for example, depending on material, add material through the hopper at a rate not to exceed 3 - 5 minutes per 50 pounds).



- Replace tank cover to prevent foreign objects from entering the tank.
- Allow time for proper mixing of solution. Follow instructions on packaging.
- The tank solution is now available for use.
- If needed, repeat steps 1 through 11 for other tank.

USING RECIRCULATION VALVES TO TRANSFER FLUID

If the need arises to transfer fluid from one tank to the other tank, recirculation valves are equipped on the EH2325 Lubrication Pump.



NOTICE

This example is shown transferring fluid from the left tank to the right tank.

1. Open suction valve on the full tank. Be sure suction valve on empty tank is closed.



2. Close the recirculation valve on the full tank.



3. Open the recirculation valve on the empty tank.




(Continued on next page)


4. Close the discharge shutoff valve.



5. Start the EH2325 pump and set the flow control to the desired speed.



6. Once complete, close recirculation valve and resume normal operation as needed.




CLEANING TANKS

⚠ WARNING Exposure to chemicals may cause serious injury or death.

BEFORE mixing chemicals or other agents in the water tank, be sure the area is well ventilated and other personnel removed from the area.

Use proper personal protective equipment (PPE) per the chemical manufacturer's instructions.




⚠ WARNING Do not allow anyone to enter tank. Tank fumes or becoming accidentally trapped may cause severe injury or death.


1. Fill tanks with clean water.



2. Open tank suction valves (A), recirculation valves (B), and discharge shutoff valve (C).
3. Remove suction manifold drain plug (D), drain cap (E), recirculating manifold plug (F) and discharge outlet plug (G).
4. Operate pump to flush the tank and pump lines until the water is clear and free of sediment. Failure to do so will result in clogging of the fluid in the tank, hoses and/or components.



IMPORTANT: While pumping fluids, monitor water level in tank. NEVER dry run pump otherwise pump damage WILL result.



(Continued on next page)

NOTICE

If needed, the hopper can be removed from mix tube assembly for ease of cleaning tank. Be sure to replace hopper on mix tube assembly after cleaning.



NOTICE

To help drain tank, CAREFULLY tip EH2325 towards tank drains (A).

5. Continue using clean water to flush the tanks and fluid system components until the water is clear and free of sediment. Failure to do so will result in clogging of the fluid in the tank, hoses and/or components.
6. Flip Pump Control to the OFF position, depress Stop button and move the main power disconnect switch to the OFF position.
7. Once tanks are clean and water emptied:
 - Close tank suction valves, recirculation valves, and discharge shutoff valve.
 - Reinstall suction manifold drain plug, drain cap, recirculating manifold plug and discharge outlet plug.
8. Put enough water in each tank to cover outlet to prevent accidental dry running of pump.



NOTICE

NEVER operate pump without suction valve(s) open and tank(s) filled with water.

IMPORTANT: If operating in freezing weather, the tank must be drained and a RV anti-freeze solution must be added to the tank to prevent component damage. Refer to Cold Weather Protection in this section.

9. Replace tank covers.

NOTES

COLD WEATHER OPERATION

Freezing temperatures during the tunneling process, creates the necessity to prepare the site and equipment for the cold weather. Failure to do so will cause damage to components and supporting equipment. Refer to Cold Weather Protection in this section for more information.

There are various methods of keeping equipment from freezing:

- When working with water, it needs to be constantly circulated to prevent freezing. Otherwise the equipment must be drained and treated with a RV anti-freeze solution to prevent freezing.
- If the EH2325 Lubrication Pump will be shut off for a considerable length of time and the temperature is at or below freezing, the fluid must be drained and treated with RV anti-freeze.
- Water tanks must be drained and treated with RV anti-freeze.
- Drain hoses to prevent freezing and keep low areas properly drained to prevent freezing damage.
- For all equipment, use proper lubricant based on ambient temperature to prevent damage.
- Use compressed air to purge a system of water. Be sure the discharge valve is open before doing so.
- Install heaters for hydraulic systems.


If systems were shut down for freezing weather, be sure to start systems slowly and let them run for at least five minutes to allow for warm up and in the case of a pump, to displace any surface ice that may have accumulated in the fluid before going back to full operation mode.

Remember it is also critical to keep the work site safe and employees comfortable during the freezing weather. Good training, supervision, proper clothing and limiting personal exposure to the weather is essential for keeping personnel and equipment safe on the job site.



COLD WEATHER PROTECTION


To prevent component damage in freezing weather, the tank and pump system **MUST** be cleaned, drained and treated with a RV Anti-Freeze solution. Failure to do so will cause damage to pump components.




1. Fill tanks with clean water.



2. Open tank suction valves (A), recirculation valves (B), and discharge shutoff valve (C).
3. Remove suction manifold drain plug (D), drain cap (E), recirculating manifold plug (F) and discharge outlet plug (G).
4. Operate pump to flush the tank and pump lines until the water is clear and free of sediment. Failure to do so will result in clogging of the fluid in the tank, hoses and/or components.



IMPORTANT: While pumping fluids, monitor water level in tank. NEVER dry run pump otherwise pump damage WILL result.



(Continued on next page)

NOTICE

To help drain tank, CAREFULLY tip EH2325 towards tank drains (A).

5. Continue using clean water to flush the tanks and fluid system components until the water is clear and free of sediment. Failure to do so will result in clogging of the fluid in the tank, hoses and/or components.

6. Flip Pump Control to the OFF position,

7. Once tanks are clean and water emptied:

- Close discharge shutoff valve.
- Reinstall suction manifold drain plug, drain cap, recirculating manifold plug and discharge outlet plug.

8. Add approximately 4 - 5 gallons (15 - 19 L) of clean water in each tank.

9. Add 4 - 5 gallons (15 - 19 L) of RV anti-freeze in each tank. Be sure there is a 50/50 mixture of liquid to RV anti-freeze in the tanks.

NOTICE

Be sure to follow the proper solution instructions on the RV anti-freeze container.

10. Replace tank covers.

11. Flip Pump Control to the ON position. Cycle pump for at least two minutes to ensure the water/RV anti-freeze mixture is pumped through complete system.

NOTICE

NEVER dry run pump. Doing so will damage pump.

12. With the 50/50 mixture of water to RV anti-freeze in the tanks and pumped through the pumping system, close tank suction valves and recirculation valves.

13. Flip Pump Control to the OFF position and depress Stop button and move the main power disconnect switch to the OFF position.

14. Perform Lockout Tagout procedure to main power source to prevent any accidental starting of the EH2325 Lubrication Pump (refer to Section 1, Safety, Lockout Tagout Procedure Guideline).



NOTES


Transporting

TRANSPORTING GUIDELINES

1. Know the local, state, and federal transportation regulations.
2. Obtain required permits for transporting.
3. Remove any obstacles from the trailer floor.
4. Clean debris from equipment.
5. Load and unload on level ground.
6. Securely fasten the EH2325 Lubrication Pump to trailer floor.
7. BEFORE lifting equipment with a hoist or other lifting device, the equipment lifting eyes and sling must be inspected for damage before lifting.
8. Observe the lifting instructions on the equipment.

LIFTING INSTRUCTIONS

- Frame weight:
 - with full tank: 9,000 lbs (4,082 kg)
 - with empty tank: 3,800 lbs (1,724 kg)
- Lifting with a crane requires a three or four part sling with legs a minimum of 10 ft (3 m) long.
- Frame **MUST** lift freely. If it is stuck to the ground, it **MUST** be broken loose prior to lifting.
- Frame lifting eyes **MUST** be inspected prior to each lift. Any damage **MUST** be repaired prior to lifting.



Transporting

NOTES

Lubricants

NOTICE

Use of inferior lubricants will affect the efficient performance of your EH2325 Lubrication Pump. Always use high quality lubricants as specified in this section. Refer to the Periodic Maintenance section for proper lubrication quantity, maintenance intervals, and procedures.


HYDRAULIC TANK OIL

The hydraulic tank (A) is factory filled with ISO-VG-68, a premium AW (All-Weather) hydraulic oil.

Use ISO-VG-68 or equivalent when adding or changing lubricant.

Recommended: hydraulic oil:

<i>Ambient Temp.</i>	<i>Hydraulic Oil</i>
below 70°F (21°C)	ISO 46
above 70°F (21°C)	ISO 68



NOTICE

Do not mix oil manufacturers or grades.

Hydraulic oil tank capacity is 25 gal. (94.6 L).

ELECTRIC MOTOR BEARING GREASE

The electric motor lubrication grease fittings are lubricated with Mobil Polyrex® EM grease.

The Polyrex EM grease is a specially formulated grease for electric-motor bearings.

Use Mobil Polyrex® EM grease or equivalent (refer to Grease Type below) when lubricating the lubrication fittings.

When adding lubricant, keep dirt out of the lubrication area. Wipe the fitting completely clean and use clean greasing equipment.

GREASE TYPE (unless nameplate states otherwise:

Nameplate Ambient Temperature between -22°F (-30°C) to 150°F (65°C) inclusive:

Recommended grease for standard service conditions is Mobil Polyrex® EM. Equivalent and compatible greases include: Texaco Polystar RB, Rykon Premium #2, Pennzoil Pen 2 Lube, Chevron SRI & Mobil SHC 100.

Nameplate Ambient Temperature below

-22°F (-30°C): Special low temperature grease is recommended such as Aeroshell 7 or Beacon 325 for ball bearings and Mobil SHC 100 for roller bearings.



STORING LUBRICANTS

Your equipment can operate at maximum performance only if clean lubricants are used. Use clean containers to handle all lubricants.

Lubricants should be stored in an area protected from dust, moisture, and other contaminants.

All lubricants must be stored at least 100 ft (30.5 m) from the portal, entrance to the tunnel, launch shaft or reception shaft.



Periodic Maintenance

⚠ WARNING

Review the Safety section in this manual before performing maintenance. Failure to do so, could cause severe injury or death.

The requirements for maintenance are shown on the maintenance charts in this section. Intervals of maintenance are based on normal operating conditions. If operating under more difficult conditions, use a shorter time interval between maintenance.

LOCKOUT TAGOUT POWER BEFORE SERVICING

⚠ WARNING

Severe personal injury or death can result from unexpected machine movement.

LOCKOUT TAGOUT power before attempting to make repairs or adjustments to this equipment, unless otherwise indicated. Proper lockout tagout will prevent accidents and save lives. Performing the lockout tagout will also prevent the equipment from moving or operating unexpectedly.

Refer to Lockout Tagout Procedure Guideline in Section 1, Safety for more information.



HYDRAULIC OIL/FLUIDS UNDER PRESSURE

⚠ WARNING

Escaping oil or other fluids under pressure can penetrate your skin causing serious injury.

Release all pressure before performing maintenance or repairs. Never weld near pressurized fluid lines.

DO NOT use your hands to check for leaks. When searching for leaks, use a piece of wood or cardboard.

Contact medical help immediately if any oil or fluid is injected into your skin. A serious infection or reaction can emerge without proper medical treatment.



AVOID PINCH POINTS

⚠ WARNING

Moving parts or the mishandling of parts can cause severe personal injury.

Keep hands away from moving parts.

Watch your fingers, hands and legs while equipment is in operation.


Handle parts carefully to avoid crushing and pinch point hazards.



MAINTENANCE CHARTS

NOTICE

Use the item number in the chart to refer to the detailed maintenance procedures later in this section.




*DAILY OR EVERY 10 HOURS OF OPERATION

ITEM	COMPONENT	SERVICE	REQUIREMENT	MATERIAL
1.	Covers & Guards	Inspect	Replace if damaged.	
2.	Valves, Levers & Controls	Inspect	Inspect for proper operation.	
^3.	Wiring & Cables	Inspect	If damaged, replace with new.	
4.	Hydraulic Return Filter	Check Indicator	Replace filter as needed per indicator.	Return Filter
5.	Hydraulic Tank	Check Fluid Level	Add hydraulic fluid as needed.	See Section 8
6.	Water/Solution Tank	Inspect	Repair or replace if damaged.	
7.	Water/Solution Tank	Flush	Flush in freezing weather or is idle for more than a day.	
8.	Hoses & Tube	Check	Replace if damaged.	
^9.	Decals	Inspect	If damaged, replace with new.	
10.	Pump	Inspect	Refer to Moyno Pump Instructions.	

^ Not Shown

NOTICE

Use the item number in the chart to refer to the detailed maintenance procedures later in this section.




***WEEKLY OR EVERY 50 HOURS OF OPERATION**

ITEM	COMPONENT	SERVICE	REQUIREMENT	MATERIAL
11.	Oil Cooler Fins	Check & Clean	If damaged, repair or replace.	
12.	Motor Cooling Fins	Clean		

NOTICE

Use the item number in the chart to refer to the detailed maintenance procedures later in this section.



***MONTHLY OR EVERY 250 HOURS OF OPERATION**


ITEM	COMPONENT	SERVICE	REQUIREMENT	MATERIAL
13.	Motor Mounting Bolts	Inspect	If damaged, replace with new.	
14.	Pump Mounting Bolts	Inspect	If damaged, replace with new.	
15.	Pump Motor Mt. Bolts	Inspect	If damaged, replace with new.	

***EVERY 500 HOURS OF OPERATION**

ITEM	COMPONENT	SERVICE	REQUIREMENT	MATERIAL
16.	Hydraulic Tank	Drain & Fill	25 gal. (94.6 L)	See Section 8

NOTICE

Use the item number in the chart to refer to the detailed maintenance procedures later in this section.



AFTER EACH DRIVE

ITEM	COMPONENT	SERVICE	REQUIREMENT	MATERIAL
17.	Water/Solution Tank	Flush	Flush tank and prepare for storage.	

ANNUALLY

ITEM	COMPONENT	SERVICE	REQUIREMENT	MATERIAL
18.	Electric Motor Brgs.	Lubricate (2 Places)	2 Shots	Mobil Polyrex EM


DAILY OR EVERY 10 HOURS OF OPERATION

NOTICE

Refer to your engine operation manual for additional maintenance information.

1. INSPECT COVERS & GUARDS

Inspect all guards and covers to be sure they are properly mounted in place, and undamaged. Repair or replace as needed. NEVER operate without covers or guards in place.



2. INSPECT VALVES AND LEVERS


Inspect valves and levers for proper operation.

Repair or replace as needed.



3. INSPECT WIRING & CABLES

Inspect wiring and cable for cracking, fraying or other damage. Replace as needed.



4. CHECK HYDRAULIC RETURN FILTER INDICATOR

To prevent over or under servicing of the hydraulic return filter, a filter indicator (A) has been installed on the return filter housing.

The green OK zone indicates that the filter is functioning properly.



The yellow zone indicates that the filter will soon require replacement.

When the needle on the gauge is in the red CHANGE zone, replace filter as soon as possible using the following procedure:

1. Clean and dry area around return filter.
2. Remove filter. Dispose of oil and filter properly.

NOTICE Remove filter gasket if stuck in filter housing.

3. Fill new filter with clean hydraulic oil (refer to Section 8, Lubricants for oil specification).
4. Lubricate new filter gasket with a light coating of clean hydraulic oil.
5. Install new filter. Hand tighten only.
6. Start motor until the hydraulic system is warm. Then check for leaks.
7. Shut down motor.
8. Check hydraulic tank oil level on gauge (B). Add hydraulic oil, if necessary.




5. CHECK HYDRAULIC TANK OIL LEVEL

Check hydraulic tank oil level gauge (C). Add hydraulic oil, if necessary.

The hydraulic tank is filled with ISO-VG-68 Premium Hydraulic Oil. Refer to Hydraulic Tank in the Fuels & Lubricants section for more information.

Hydraulic oil tank capacity is 25 gal. (94.6 L).



6. INSPECT WATER/SOLUTION TANKS

Inspect water/solution tanks for damage. Repair or replace as needed.



7. FLUSH WATER/SOLUTION TANKS

The water/solution tanks must be flushed with clean water if:

- the solution will be sitting idle more than an overnight period. Check the directions on the polymer or bentonite bag/container for additional instructions.
- the solution will be sitting idle overnight in freezing weather. The tanks will also require draining and adding a RV anti-freeze solution. (refer to Cold Weather Protection in section 6, Operation.




8. INSPECT OUTLET TUBES & HOSES

Inspect outlet tubes and hoses and all hydraulic hoses for cracks, wear or damage. Replace as needed.



9. INSPECT DECALS

Visually inspect all decals so they are clean and readable. Replace decals if they are damaged, missing, or hard to read.



10. PUMP MAINTENANCE

The Moyno® pump (A) is designed for minimal maintenance with routine lubrication and adjustment of the packing gland and the infrequent lubrication of the bearings (refer to instructions below).

IMPORTANT:

1. **NEVER** dry run or operate the pump with both suction valves closed at the same time. Doing so **WILL** cause pump damage.
2. When performing maintenance to the packing gland, **NEVER** overtighten packing gland, otherwise pump damage will result.


MAINTENANCE

The Moyno pump has been designed for a minimum of maintenance, the extent of which is routine lubrication and adjustment of packing and infrequent lubrication of the bearings. The pump is one of the easiest to work on in that the main elements are very accessible and require few tools to disassemble.


Packing

The Moyno pump is normally furnished with die formed packing. The packing may be either grease lubricated through a grease fitting in the stuffing box or have plumbing connected to the housing to allow a water flush. (See Water Flush of Packing)

Packing gland adjusting nuts should be evenly adjusted so they are little more than finger tight. Over-tightening of the packing gland may result in premature packing failure and possible damage to the shaft and gland. When the packing is new, frequent minor adjustments are recommended for the first few hours of operation in order to compress and seat the packing. Greasing the packing often but with limited quantities of grease is the best practice. This can be done through a grease fitting which leads to a lantern ring in the mid-section of the packing. Do not use a one-piece spiral wrap of packing.




Cross section of stuffing box



Water Flush of Packing

When the material being pumped is abrasive in nature, it may be advantageous to flush the packing to prevent leakage under packing and excessive shaft wear.

Clean water can be injected through a 1/8" NPT tapped hole that normally houses the grease fitting for lubricating the packing. The water can be permitted to leak axially along the shaft in either direction or can be removed from the second tapped hole in the stuffing box. In both cases, the discharge from the stuffing box should be throttled slightly to maintain 10-15 PSI higher pressure in the stuffing box than is present in the suction housing.



Typical water flush to packing

This is a basic arrangement, other variations can be used.
(1) Throttling Valve (2) Pressure Gauge (3) Pressure Regulating Valve

Bearings

The Moyno pump is equipped with ball bearings in the drive end size L2 through L10. The bearings are lubricated at the factory and do not need additional lubrication for at least 1500 hours of normal operation.

When relubricating the bearings, the bearing-shaft assembly should be removed (See Disassembly Instructions) and cleaned of old grease. Add only enough grease to fill the area between the bearings 1/3 full. Add a few drops of oil to bearing seals before reassembling. It is normal for bearings to run warm to the touch for the first few hours of operation.

Any type of Ep Lithium soap base grease is satisfactory for bearing lubrication. The use of Sodium or Calcium base grease is not recommended.

The following is a partial listing of approved bearing lubricants:

Dow Corning	DC 33
Keystone Lubricating Co.	Keystone #89
Texaco	Regal AFB2
Shell Oil Co.	Cyprina #3
Humble Oil & Refining Co.	Beacon 325
American Oil Co.	Supermil Grease #A72832
Mobil	EP1
Shell Oil Co.	Alvania #2

The complete Operation - Assembly Instructions for "L6" Drive End can be found at the following link:
https://www.moyno.com/dmdocuments/L6_drive_end.pdf


WEEKLY OR EVERY 50 HOURS OF OPERATION

11. INSPECT & CLEAN OIL COOLER FINS

⚠ WARNING Oil cooler fins are SHARP and may cause injury if touched. Oil cooling system may be HOT and cause severe burns if contacted. Always use gloves when near the oil cooler. Perform service on oil cooler only when cool.



1. Inspect the oil cooler fins for dirt and bent or damaged fins.




⚠ CAUTION When using compressed air, always wear eye protection to prevent injury to eyes.

2. Use compressed air (maximum 28 psi) to blow off dirt, dust and debris from oil cooler fins. If there is a large amount of debris on the fins, use a mild soap to thoroughly clean fins and then rinse with water.
3. Carefully straighten any bent fins.
4. Inspect oil cooler tubes for cracks, kinks, dents and fractured seams. Repair or replace oil cooler as necessary.



12. CLEAN MOTOR COOLING FINS

Remove and clean dirt and debris from motor cooling fins (A).




MONTHLY OR EVERY 250 HOURS OF OPERATION

13. INSPECT MOTOR MOUNTS


Visually inspect all electric motor mounting bolts (A) for loose hardware or damaged parts.

Tighten all loose hardware and replace defective parts.




14. INSPECT PUMP MOUNTING BOLTS

Visually inspect pump mounting bolts (B) for loose hardware or damaged parts.



Visually inspect pump mounting plate bolts (C) for loose hardware or damaged parts.


Tighten all loose hardware and replace defective parts.



15. INSPECT PUMP MOTOR MOUNTS

Visually inspect pump motor mounting bolts (D) for loose hardware or damaged parts.

Tighten all loose hardware and replace defective parts.




EVERY 500 HOURS OF OPERATION

NOTICE

Refer to your engine operation manual for additional maintenance information.

16. DRAIN & FILL HYDRAULIC TANK


1. Remove drain plug (A) and drain oil into a catch pan.
2. Replace drain plug.



3. Remove fill cap.
4. Fill tank with approximately 25 gal. (94.6 L) of ISO-VG-68, a premium AW (All-Weather) hydraulic oil or refer to Hydraulic Tank Oil in the Lubricants section for more information.
5. Replace fill cap.



6. Check oil level with oil level gauge (B).



AFTER EACH DRIVE

17. FLUSH & CLEAN WATER/SOLUTION TANKS

After each drive, the EH2325 Lubrication Pump tanks must be flushed and cleaned, and then add RV anti-freeze to the fluid system so the pump will be ready for the next drive.

1. Flush and clean water system by using clean water to flush the tank and water system components until the water is clear and free of sediment. Failure to do so will result in clogging of the fluid in the tank, hoses and/or components. Refer to Cleaning Tanks in section 6, Operation for more information.
2. Once tank and water system is clean, completely drain system and add RV anti-freeze to the water system. Refer to Cold Weather Protection in section 6, Operation for more information.
3. Repeat steps 1 and 2 for other tank water system.



ANNUALLY

18. LUBRICATE MOTOR BEARINGS

NOTICE

For additional electric motor maintenance information, contact your Akkerman Aftermarket Support representative.

Lubricate the electric motor bearings (A) with two shots of Mobil Polyrex[®] EM grease or equivalent (refer to Grease Type below). There are two lubrication fittings on the electric motor.

When adding lubricant, keep dirt out of the lubrication area. Wipe the fitting completely clean and use clean greasing equipment.


GREASE TYPE (unless nameplate states otherwise:

Nameplate Ambient Temperature between -22°F (-30°C) to 150°F (65°C) inclusive:

Recommended grease for standard service conditions is Mobil Polyrex[®] EM. Equivalent and compatible greases include: Texaco Polystar RB, Rykon Premium #2, Pennzoil Pen 2 Lube, Chevron SRI & Mobil SHC 100.

Nameplate Ambient Temperature below

-22°F (-30°C): Special low temperature grease is recommended such as Aeroshell 7 or Beacon 325 for ball bearings and Mobil SHC 100 for roller bearings.



Storage

PREPARING FOR STORAGE

1. Repair worn or damaged parts.
2. Wash all equipment and tanks thoroughly.
3. Drain tanks. Flush and drain pump and all fluid lines including to prevent clogging or freezing during storage.
4. Lubricate all grease points.
5. Repaint equipment where necessary.
6. Drain hydraulic oil, flush oil reservoir, change hydraulic filter, and refill hydraulic tank. Check for leaks.
7. Wipe up lube spills. Dispose of rags and trash properly.
8. If possible, store equipment under cover and out of the weather in a ventilated area.
9. Clean and drain lubrication hoses. Store indoors to minimize UV damage.

REMOVING FROM STORAGE

1. Clean equipment thoroughly.
2. Check to make sure all decals are clean and readable.
3. Check condition of wires and cables. Repair or replace as necessary.
4. Check for leaks. Repair or replace as necessary.
5. Check oil level in hydraulic tank. Add oil if necessary (refer to section 8, Lubricants for oil specifications). Also, check condition of the oil; be sure there is no water in the oil.
6. Check hydraulic return filter indicator. Replace filter as needed per indicator.
7. Check condition of all hoses and connections. Tighten, repair or replace with new as needed.
8. Before operating, cycle hydraulic functions several times to purge air from hydraulic system.
9. Fill lubrication tanks with clean water.
10. Review this Operator's Manual and all other tunneling equipment manuals.

Troubleshooting

Problem	Cause	Solution
Motor does not start.	Power source not hooked up.	Hook up power source.
	Main power disconnect switch OFF.	Flip switch to ON position.
	Wrong phase.	Rewire connection.
	If motor still does not start, contact your Akkerman Aftermarket Support Representative.	
Pump cannot reach maximum pressure.	Relief valve is not set properly.	Adjust relief to 225 psi max.
	Worn packing or packing break-in.	See Moyno packing gland adjustment instructions.
	If max. pressure still cannot be reached, contact your Akkerman Aftermarket Support Representative.	
Lubrication pump is pulsating.	Air in water supply.	Add more water/solution in tank and check pump inlet connections.
	Outlet cam lock is not engaged.	Be sure cam lock is fully engaged.
	Hydraulic oil level is low.	Fill hydraulic oil tank as needed.
	If pump continues to pulsate, contact your Akkerman Aftermarket Support Representative.	
No water discharge out of pump.	No water in tank.	Fill tank.
	Suction hose not connected to pump.	Connect suction hose.
	Pump Control is in OFF position.	Move Pump Control to ON position.
	Suction valve on tank(s) closed.	Open tank suction valve(s).
	Mixer Speed Control is in Slow or Off position.	Move Mixer Speed Control to higher speed.
	Wall valve bentonite connection ball valve is turned to OFF position.	Turn wall valve to ON position.
	Outlet hose damaged.	Replace hose.
	Pump does not spin freely.	Carefully use a pipe or strap wrench to loosen stator.
	Rotor & stator adhesion.	Lubricate rotor and stator per Moyno instructions.
	If no water still does not discharge out of pump, contact your Akkerman Aftermarket Support Representative.	


(Continued on next page)

Troubleshooting

Problem	Cause	Solution
Hydraulics are running hot.	Dirty oil cooler.	Clean oil cooler.
	Incorrect relief valve setting.	Adjust valve to 225 psi max.
	Pump is worn.	Replace pump.
	If the hydraulics continue to run hot, contact your Akkerman Aftermarket Support Representative.	
Mixer not functioning.	Mixer Control is in OFF position.	Move Mixer Control to ON position.
	Hydraulic oil level is low.	Fill hydraulic oil tank as needed.
	If mixer is still not functioning contact your Akkerman Aftermarket Support Representative.	

Specifications

EH2325 LUBRICATION PUMP



Dimensions:

Height	61.5 in. (1,562 mm)
Width	
with steps in	88.25 in. (2,242 mm)
with steps out	109 in. (2,769 mm)
Length	104 in. (2,642 mm)
Weight* (empty tanks).....	3,800 lbs. (1,724 kg)
(full tanks)	9,000 lbs. (4,082 kg)
* approximate	

Power Unit:

Electric Motor @ 1,800 rpm .. 30 HP (22.5 kW)

Recommended Power Requirements:

- Recommended Operating Pwr: 40kW / 50 kVA @ 480VAC
- Generator Minimum Motor Starting KVA: 115 skVA with less than 30% instantaneous voltage dip and greater than 90% sustained voltage.

Drive System Direct Drive

Mixer (Agitator) Hydraulic-Driven, In-tank

Fluid Pumps

Pump 1 Flow (Max.).....	12 gpm (45 L/min)
Pump 2 Flow (Max.).....	12 gpm (45 L/min)
Pump 3 Flow (Max.).....	12 gpm (45 L/min)
Pressure Rating (Max.)	2,000 psi (13,790 kPa)

Progressive Cavity Pump

Pressure (Max.).....	225 psi (1,551 kPa)
Flow (Max.)	25 gpm (95 L/min)

Fluid Capacities

Water Tank	Two, 325 gal (1,230 L)
Hydraulic Reservoir	25 gal. (94.6 L)

TORQUE CHART

Use these torque values as a guideline when tightening hardware unless otherwise specified in this manual.

Lubricated Coarse UNC Threads Grade 8 Fasteners			Lubricated Fine UNF Threads Grade 8 Fasteners		
Bolt Size	Torque		Bolt Size	Torque	
	ft. lbs.	(N·m)		ft. lbs.	(N·m)
1/4 - 20	10	(14)	1/4 - 28	11	(15)
5/16 - 18	20	(27)	5/16 - 24	22	(30)
3/8 - 16	35	(47)	3/8 - 24	39	(53)
7/16 - 14	56	(76)	7/16 - 20	62	(84)
1/2 - 13	85	(115)	1/2 - 20	96	(130)
9/16 - 12	123	(167)	9/16 - 18	137	(186)
5/8 - 11	170	(231)	5/8 - 18	192	(260)
3/4 - 10	301	(408)	3/4 - 16	336	(456)
7/8 - 9	450	(610)	7/8 - 14	500	(678)
1 - 8	680	(922)	1 - 12	740	(1003)
1-1/8 - 7	960	(1302)	1-1/8 - 12	1030	(1397)
1-1/4 - 7	1360	(1844)	1-1/4 - 12	1500	(2034)
1-1/2 - 6	2360	(3200)	1-1/2 - 12	2660	(3607)

Identification Numbers

Model and serial numbers are required when ordering parts or requesting service information. Record your model and serial numbers below.

EH2325 LUBRICATION PUMP

Model Number _____ EH2325 _____

Serial Number _____



NOTES

Safety Data Sheets

The Federal Occupational, Safety, and Health Administration (OSHA) Standard 29 CFR 1910.1200, require that specific safety data sheets (SDS) be available to employees before operating this equipment. This may include information on substances contained in this equipment such as hydraulic fluid and gear lubricant.

Akkerman Inc. will provide, at no cost, SDS which apply to its product line. Simply contact your Akkerman Aftermarket Support representative for a copy.

To ensure a prompt response to your SDS request, include your return address (including zip or postal code) and the equipment's model numbers and serial numbers with your request.

NOTES

Warranty

Akkerman warrants that all equipment manufactured by it be free from defects due to workmanship or material when normally used and serviced for a period of 90 days from the date of shipment by Akkerman. Normal wear and tear to the equipment, including, but not limited to, wear on the cutter face tooling, hydraulic filters, augers, casings, slurry line and seals is not covered by this warranty. Akkerman does not warrant that the equipment meets the requirements of any particular safety code or rule governing equipment classification. If the Customer has questions about local safety codes, rules or ordinances, authorities local to the project should be consulted.

In order to be considered as a potential warranty claim, the component in question must be returned to Akkerman (freight prepaid) for factory inspection and analysis, and determination of warranty applicability. No warranty is provided for electronics or electrical components of any kind. The validity of all warranty claims are subject to the discretion and determination of the Akkerman Aftermarket Support Department. All such determinations are final.

Warranty

NOTES

Parts

Contents

Introduction	16-2
Decals	16-4
EH2325 - Right View, 1255-115	16-4
EH2325 - Left View, 1255-115	16-6
Parts	16-8
EH2325 F61600F	
Lubrication Pump Assembly, F61600F	16-8
Hydraulic Assembly, 061635A	16-10
Electrical Assembly, A62194A	16-13
Electrical Assembly, A49113A	16-14
Bentonite Moyno Assembly, 061633A	16-16
Moyno Pump Assembly, 061632A	16-18
Agitator Frame Assembly, 061655A	16-20
Lube Pump Guard, 061809A	16-21
Bentonite Valve Assembly, 061795A	16-22
Camlock Reducer Assembly, 061815A	16-23
Operator Controls	16-24
Moyno Pump, P0303-183	16-26

INTRODUCTION

This parts manual contains assembly illustrations of the Akkerman EH2325 Series Lubrication Pump. The illustrations in this manual are intended to show typical construction of various parts. In some instances, the details of parts illustrated may not exactly represent their actual appearance, but will help to identify parts performing the same functions.

LOCATING PARTS

This parts manual is organized to help you locate parts information quickly. An Alphabetical Index, Section 17, is provided to determine the page number of the assembly a part is used. If the part number is known, the Numerical Index, Section 18, can also be utilized to find the page number of the assembly.

USE GENUINE AKKERMAN PARTS

The use of second-rate parts could affect the efficient performance of the Lubrication Pump. ALWAYS use genuine Akkerman parts.

PARTS ORDERING

To order fast, accurate, and reliable parts service, call (800) 533-0386, (507) 567-2261, or fax (507) 567-2720, and provide the following information.

1. Model Number
2. Serial Number
3. Part Number, Description, and Quantity
4. Shipping Preference

MEASUREMENTS

The unit of measure in this manual is in inches unless indicated otherwise.

HARDWARE SPECIFICATION

All Akkerman products are assembled with SAE Grade 8 bolts, nuts, and washers. ALWAYS use matched fastener hardware when replacing or repairing the unit.

If you find any errors with this manual or have any suggestions for improvement, please let us know.

Mail your suggestions to:


Akkerman Inc, ATTN: Technical Publications, 58256 266th Street, Brownsdale, MN 55918.

Akkerman Inc. reserves the right to improve its product without notice or obligation.

NOTES

EH2325 LUBRICATION PUMP DECALS - RIGHT VIEW, 1255-115

EH2325 (SN: F61600F)



ITEM	QTY	PART NO.	DESCRIPTION
0	1	1255-115	KIT, Decal EH2325
1	3	1251-018	DECAL, Warning Suspended Loads
2	2	1251-218	DECAL, Hydraulic Oil Specification
3	1	1251-286F	DECAL, Hourmeter
4	1	1251-972	DECAL, Recommended Power Requirements
5	2	1252-184	DECAL, Notice Lifting Instructions
6	1	1252-193	DECAL, Right Tank Mixer Speed Control
7	3	1250-638	DECAL, Notice Position Level Ground
8	1	1251-677	DECAL, Never Operate Without Water/Solution
9	2	1250-558	DECAL, USA Flag Small
10	1	1251-221	DECAL, Tank Capacity 325 gal.
11	1	1250-311	DECAL, Warning Keep Away From Propeller

(Continued on next page)


EH2325 LUBRICATION PUMP DECALS - RIGHT VIEW, 1255-115

EH2325 (SN: F61600F)

ITEM	QTY	PART NO.	DESCRIPTION
12	1	1251-678	DECAL, Clean Water/Solution Only
13	1	1251-813	DECAL, Tank Drain
14	1	1251-246	DECAL, Akkerman, Large
15	1	1252-180	DECAL, Model EH2325
16	2	1250-069	DECAL, Notice Flush Drain Manifold
17	2	1250-089	DECAL, Notice Do Not Dry Run
18	1	1252-190	DECAL, Discharge Valve
19	1	1251-286E	DECAL, Main Power Disconnect
20	1	1251-286C	DECAL, Stop
21	1	1251-286B	DECAL, Start
22	1	1251-288	DECAL, Grease Motor Annually
23	1	3-700L	DECAL, Rotation Left
24	2	1250-004	DECAL, Warning Keep Guards In Place
25	1	1250-483	DECAL, Caution Oil Temp
26	1	1250-090	DECAL, Notice Do Not Overtighten Gland
27	1	1252-187	DECAL, Right Tank Suction Valve
28	1	1252-186	DECAL, Left Tank Suction Valve
29	1	1250-314	DECAL, Bentonite Pump Discharge PSI
30	1	40000-16	DECAL, Notice Change Filter
31	1	1251-245	DECAL, Akkerman X-Large

EH2325 LUBRICATION PUMP DECALS - LEFT VIEW, 1255-115

EH2325 (SN: F61600F)



ITEM	QTY	PART NO.	DESCRIPTION
1	2	1251-677	DECAL, Never Operate Without Water/Solution
2	2	1251-018	DECAL, Warning Suspended Loads
3	1	1252-192	DECAL, Left Tank Mixer Speed Control
4	1	1252-184	DECAL, Notice Lifting Instructions
5	1	1252-182A	DECAL, Pump Control
6	1	1252-182B	DECAL, Left Tank Mixer Control
7	1	1252-182C	DECAL, Right Tank Mixer Control
8	1	1250-385	DECAL, Danger Hazardous Voltage
9	1	1250-383	DECAL, Notice Electrical Equipment
10	1	1252-062	DECAL, Input Pwr Start Up
11	1	1250-544	DECAL, Made in USA
12	1	-	PLATE, Serial Number
13	1	1252-189	DECAL, Right Tank Recirc Valve
14	1	1252-188	DECAL, Left Tank Recirc Valve
15	1	1252-183A	DECAL, Bentonite Relief PSI
16	1	1252-183C	DECAL, Bentonite PSI Reducing Valve
17	1	1252-181C	DECAL, Right Tank Mixer PSI

(Continued on next page)


EH2325 LUBRICATION PUMP DECALS - LEFT VIEW, 1255-115

EH2325 (SN: F61600F)

ITEM	QTY	PART NO.	DESCRIPTION
18	1	1252-183B	DECAL, Bentonite Flow Control
19	1	1252-181B	DECAL, Left Tank Mixer PSI
20	1	1252-181A	DECAL, Pump PSI
21	1	3-700R	DECAL, Rotation Right
22	1	1251-749	DECAL, Warning Oil Cooler Fins Sharp
23	2	1250-069	DECAL, Notice Flush Drain Manifold
24	1	1252-191	DECAL, Drain
25	1	1250-638	DECAL, Notice Position Level Ground
26	1	1250-089	DECAL, Notice Do Not Dry Run
27	1	1252-180	DECAL, Model EH2325
28	1	1251-246	DECAL, Akkerman, Large
29	1	1251-813	DECAL, Tank Drain
30	1	1251-678	DECAL, Clean Water/Solution Only
31	1	1250-311	DECAL, Warning Keep Away From Propeller
32	1	1251-221	DECAL, Tank Capacity 325 gal.
33	1	1250-558	DECAL, USA Flag Small

EH2325 LUBRICATION PUMP ASSEMBLY, F61600F

EH2325 (SN F61088F)



ITEM	QTY	PART NO.	DESCRIPTION
0	1	F61600F	EH2325 LUBE PUMP ASSEMBLY
1*	1	061635A	ASSEMBLY, Hydraulic
2*	1	A62194A	ASSEMBLY, Electrical
3*	1	061633A	ASSEMBLY, Bentonite Moyno
4	1	061626P	PLATE, Panel - Top
5	12	P0001-04-002	BOLT, Hex 1/4 UNC x .5
6	12	P0040-004	WASHER, Hardened Flat 1/4
7* ^	1	1255-115	KIT, Decal EH2325
8*	1	061795A	ASSEMBLY, Bentonite Valve 1 x 10'
9*	1	061815A	ASSEMBLY, Camlock Reducer

* Refer to this section for parts information.

^ Not Shown

NOTES

HYDRAULIC ASSEMBLY, 061635A
EH2325 (SN F61600F)

ITEM	QTY	PART NO.	DESCRIPTION
0	1	061635A	HYDRAULIC ASSEMBLY
1	1	P0300-373	FITTING, 08MFOR-12MB90
2	3	P0301-142	GAUGE, 5000 psi
3	3	P0300-594	FITTING, 4FB-4MFFOR
4	3	P0302-803	VALVE
5	10	P0300-305	FITTING, 08MFOR-08MB
6	3	P0300-717	FITTING, 6MFFOR-8MB90
7	11	P0300-385	FITTING, 10MFFOR-10MB
8	6	P0001-04-009	BOLT, Hex 1/4 UNC x 2.25
9	6	P0003-04-000	NUT, Hex 1/4 UNC
10	14	P0040-004	WASHER, Hardened Flat 1/4
11	1	P0300-302	FITTING, 08MFOR-10MB90
12	2	P0300-193	PLUG, 08MB-PLUG
13	4	P0300-892	FITTING, 10MFFOR-8MB
14	1	P0300-423	FITTING, 10MFOR-10MB-10MFOR
15	1	P0300-667	FITTING, 10MB-10FB-10FB
16	1	P0300-788	FITTING, 10MB-08FB
17	1	P0300-542	FITTING, 08MB-08MB
18	1	P0300-383	FITTING, 10MFOR-10MB90
19	1	P0302-254	VALVE, Pressure Control Relief
20	1	P0302-254A	BODY
21	1	P0300-120	FITTING, 06MJ-08MP
22	1	P0125-139	TANK, 25 Gallon (Includes items 4a & 4b)
4a	1	P0125-139A	CAP, Breather
4b	1	P0125-139B	GAUGE, Sight
23	1	P0093-039	OIL COOLER
24	1	P0093-040A	SWITCH, Temp W/Soft Start
25	1	P0309-144B	ASSEMBLY, Filter Head
26	1	P0309-145A	ELEMENT, Filter 10 Micron
27	1	P0301-105	GAUGE, Filter Indicator
28	1	A09881A-019	HOSE ASSEMBLY, 5/8 x 19
29	1	P0300-536	FITTING, 12MB-12FB-12FB
30	1	A09853A-078	HOSE ASSEMBLY, 1/2 x 73
31	1	A09873A-034	HOSE ASSEMBLY, 1/2 x 34
32	100 QT	P0126-038	OIL, Hydraulic Duragard AW-68
33	6	P0040-005	WASHER, Hardened Flat 5/16
34	2	PM6A-16-1.00	BOLT, Hex M6 x 1.00 x 16 10.9
35	2	P0003-05-000	NUT, Hex 5/16 UNC
36	2	P0001-05-004	BOLT, Hex 5/16 UNC x 1
37	8	P0040-016	WASHER, Hardened Flat 1
38	6	P0001-10-007	BOLT, Hex 5/8 UNC x 1.75
39	12	P0040-010	WASHER, Hardened Flat 5/8
40	6	P0013-10-000	NUT, Lock 5/8 UNC
41	2	P0001-04-003	BOLT, Hex 1/4 UNC x .75
42	1	P0300-551	FITTING, 20MFFOR-20FFORX-20MFFOR
43	1	P0300-620	FITTING, 20MFOR-20MB90
44	4	P0300-325	FITTING, 08MJ-08MJBKHD
45	2	P0300-886	FITTING, 12MFFOR-16MBSPP
46	4	P0300-903	FITTING, 10MFFOR-10MFFOR-BKHD90
47	2	P0300-332	ORING, 08OR
48	1	A09864A-064	HOSE ASSEMBLY, 1/4 x 64
49	4	P0300-688	FITTING, 08MB-08FB-08FB
50	2	P0302-801	VALVE, Ball 08ORD-7250 PSI

(Continued on next page)

HYDRAULIC ASSEMBLY, 061635A
EH2325 (SN F61600F)


ITEM	QTY	PART NO.	DESCRIPTION
51	2	P0300-371	FITTING, 16MFOR-16MB90
52	4	P0300-580	FITTING, 10MFS-12MORB
53	1	P0300-890	FITTING, 12MFFOR-12MFFOR-12FFORX
54	1	P0300-658	FITTING, 20MB-12FB
55	2	P0300-319	FITTING, 16MFFOR-16MB
56	2	P0300-562	CAP, #8 JIC
57	1	A09875A-035	HOSE ASSEMBLY, 1 x 35
58	1	A10374A-026	HOSE ASSEMBLY, 1 x 26
59	1	A09870A-028	HOSE ASSEMBLY, 1 x 28
60	4	A09877A-039	HOSE ASSEMBLY, 5/8 x 39
61	2	A09877A-024	HOSE ASSEMBLY, 5/8 x 24
62	1	A09877A-064	HOSE ASSEMBLY, 5/8 x 64
63	1	A10324A-032	HOSE ASSEMBLY, 1/2 x 32
64	1	A10324A-071	HOSE ASSEMBLY, 1/2 x 71
65	1	A09877A-063	HOSE ASSEMBLY, 5/8 x 63
66	1	A10324A-042	HOSE ASSEMBLY, 1/2 x 42
67	1	P0301-110	GAUGE, 600 psi
68	1	A09877A-040	HOSE ASSEMBLY, 5/8 x 40
69	1	A10359A-030	HOSE ASSEMBLY, 1/2 x 30
70	1	A09881A-022	HOSE ASSEMBLY, 5/8 x 22
71	1	A09876A-032	HOSE ASSEMBLY, 5/8 x 32
72	1	A10359A-034	HOSE ASSEMBLY, 1/2 x 34
73	1	A10359A-036	HOSE ASSEMBLY, 1/2 x 36
74	1	A09876A-016	HOSE ASSEMBLY, 5/8 x 16
75	1	P0300-969	FITTING, 04FP-04MJBKHD
76	3	A10059A-018	HOSE ASSEMBLY, 1/4 x 18
77	1	A09832A-026	HOSE ASSEMBLY, 1/2 x 26
78	1	P0300-450	FITTING, 16MFOR-20MB90
79	1	A10342A-043	HOSE ASSEMBLY, 1 x 43
80	1	P0300-374	FITTING, 16MFOR-20MB
81	1	P0300-328	FITTING, 16MFOR-16FFORX-16MFOR
82	1	P0300-537	FITTING, 16MB-16FB-16FB
83	1	A09988A-030	HOSE ASSEMBLY, 3/4 x 30
84	1	P0300-060	PLUG, 10MB
85	1	A09873A-073	HOSE ASSEMBLY, 1/2 x 73
86	1	P0300-275	FITTING, 04MP-04FP-04FP
87	1	P0063-016	FITTING, Grease 1/4-NPT Straight
88	9	P0017-06-750	SCREW, Round Machine 6/32 x 3/4
89	9	P0003-03-000	NUT, Hex 6-32

QT - Quart

* Refer to this section for parts information.

ELECTRICAL ASSEMBLY, A62194A


EH2325 (SN F61600F)



ITEM	QTY	PART NO.	DESCRIPTION
0	1	A62194A	ELECTRICAL ASSEMBLY
1	1	P0251-447	MOTOR, Electric 30 HP
2	1	P0305-252	MOUNT, Pump Drive
3	1	P0305-225	SPLINE
4	1	P0305-112D	INSERT
5	1	P0305-201	COUPLER
6	14	P0040-008	WASHER, Hardened Flat 1/2
7	6	P0001-08-005	SCREW, Hex Cap 1/2 UNC x 1.25
8*	1	A49113A	ASSEMBLY, Electrical
9	2	A62193A	MOUNT, Electrical Box
10	4	P0040-006	WASHER, Hardened Flat 3/8
11	4	P0001-06-004	BOLT, Hex 3/8 UNC x 1
12	4	P0013-05-000	NUT, Nyloc 5/16 UNC
13	4	P0001-05-008	BOLT, Hex 5/16 UNC x 2
14	4	P0013-08A-000	NUT, Nyloc 1/2 UNC
15	4	P0001-08-008	BOLT, Hex 1/2 UNC x 2
16	1	P0303-890	PUMP

* Refer to this section for parts information.


ELECTRICAL ASSEMBLY, A49113A
EH2325 (SN F61600F)



ITEM	QTY	PART NO.	DESCRIPTION
0	1	A49113A	ELECTRICAL ASSEMBLY
1	1	P0251-845	ENCLOSURE
2	1	P0251-842	BREAKER, Circuit
3	1	P0251-482	BREAKER, Handle & Shaft
4	1	P0251-843	CONTACTOR, Non-Reversible
5	1	P0251-844	RELAY, Overload
6	1	P0310-499	CONTACT, Auxiliary N O
7	1	P0251-616	POWER SUPPLY, 24V, 10 Amp
8	1	P0310-503-005	RAIL, Din 5.0
9	5	P0020-83-022	SCREW, Truss Head 8-32 x .375
10	4	P0310-473B	HOLDER, Fuse Din Rail
11	1	P0310-471A	FUSE, 600 VAC 15A
12	4	P0310-571	FUSE HOLDER END STOP
13	1	P0310-503-012	RAIL, Din 12.0"
14	3	P0251-399	BLOCK, Distribution
15	3	P0310-472	FUSE, 6 Amp
16	1	P0251-1009	METER, Hour
17	1	P0310-412F	PUSHBUTTON, Illuminated
18	2	P0310-419F	LATCH, Mounting
19	2	P0251-563	LIGHT, White LED Pilot
20	1	P0056-122F	BLOCK, Contact N C

(Continued on next page)


ELECTRICAL ASSEMBLY, A49113A EH2325 (SN F61600F)



ITEM	QTY	PART NO.	DESCRIPTION
21	1	P0310-411F	PUSHBUTTON, Illuminated
22	1	P0056-121F	CONTACT, N O
23	1	P0310-432	STRIP, 15 Position Barrier
24	2	P0017-06-323	SCREW, Round Head Machine 6-32 x .5
25	1	P0310-433	STRIP, Jumper 15 Position
26	1	P0055-157	LUGS
27	2	P0055-174	FORK, # 6 Stud 16-14 Wire
28	28	P0055-245	FORK, Locking #6 Red
29	3	P0311-075	RELIEF, Strain 3/4
30	48 LI	P0054-013	WIRE, 14 GA
31	140 LI	P0054-596B	WIRE, 18 GA Blue/White Stripe
32	1	P0054-030-120	CORD, Power #8 8 GA x 120
33	1	P0311-032	BUSHING, Insulating 1/2
34	75 LI	P0054-018	CABLE, 16 GA
35	1	P0311-121	RELIEF, Strain
36	1	P0311-018	NUT, Lock 1/2
37	2	P0311-019	NUT, Lock 3/4
38	1	P0251-906	MONITOR, Phase 500 VAC
39	2	P0311-033	BUSHING Insulating 3/4
40	1	P0054-030-1200	CORD, Power #8 8 GA x 1200

LI - Linear Inch

BENTONITE MOYNO ASSEMBLY, 061633A
 EH2325 (SN F61600F)




**BENTONITE MOYNO ASSEMBLY, 061633A
EH2325 (SN F61600F)**

ITEM	QTY	PART NO.	DESCRIPTION
0	1	061633A	BENTONITE MOYNO ASSEMBLY
1	1	A61141A	FRAME
2*	1	061632A	ASSEMBLY, Moyno Pump
3	1	P0201-159-016	HOSE, Suction 2 x 16
4	1	P0201-159-038	HOSE, Suction 2 x 38
5	4	P0201-183	CLAMP, T-Bolt 2-5/32 To 2-15/32
6	4	P0201-205	CLAMP, T 1-3/4 Hose
7	2	P0258-112	TEE, Socket 2
8	2	P0258-115	NIPPLE, 2 x 2
9	1	P0258-114	ELBOW, Street 2 90°
10	2	P0258-110	BUSHING, Reducing 2 x 1
11	1	P0258-109	ADAPTER, 1 Barbed x MNPT
12	2	P0258-113	ELBOW, 1 Barbed x 1 MNPT 90°
13	1	P0258-039	HOSE BARB, 2 MNPT
14	1	061628P	COVER, Valve
15	7	P0040-006	WASHER, Hardened Flat 3/8
16	3	P0001-06-002	BOLT, Hex 3/8 UNC x .5
17	2	P0001-06-004	BOLT, Hex 3/8 UNC x 1
18	2	P0003-06-000	NUT, Hex 3/8 UNC
19	1	061627P	MOUNT, Flow Control
20	2	A48401P	TANK, 325 Gallon
21	1	P0305-132A	COUPLER, 1 Bore x 1/4 Keyway
22	1	P0305-132B	COUPLER, 1-1/8 Bore x 1/4 Keyway
23	1	P0305-182	INSERT
24	1	P0201-238-062	HOSE, Water Suction 1 x 62
25	1	P0258-108	CAP, Nylon Cam & Groove Hose
26	1	P0201-238-050	HOSE, Water Suction Hose 1 x 50
27*	2	061655A	FRAME, Agitator
28	2	P0258-075	PLUG, 1 NPT Poly Threaded
29	2	A48479P	SHAFT, Agitator Ext
30	2	A48411P	PROPELLER 10
31	8	P0032-002	SCREW, Socket Set 5/16 x .375
32	2	P0047-003-1.75	KEY, Square 1/4 x 1.75
33	56	P0040-008	WASHER, Hardened Flat 1/2
34	2	A45054A	STEP
35	2	A45057A	BRACE, Step
36	4	A45170P	BUSHING,
37	12	P0013-08A-000	NUT, Nylock 1/2 UNC
38	4	P0001-08-012	BOLT, Hex 1/2 UNC x 3
39	4	P0001-08-007	BOLT, Hex 1/2 UNC x 1.75
40	1	P0095-133	CANISTER, Manual
41	2	P0013-04-000	NUT, Nyloc 1/4
42	2	P0040-004	WASHER, Hardened Flat 1/4
43	2	P0020-14-205	SCREW, Truss Head Machine 1
44	2	A48824A	STRAP, Tank W/Bag Shelf
45	2	A48823A	STRAP, Tank
46	16	P0001-08-005	SCREW, Hex Cap 1/2 UNC x 1.25
47	4	P0001-08-009	BOLT, 1/2 UNC x 2.25
48	4	P0003-08-000	NUT, Hex 1/2 UNC
49	1	P0304-376	MOTOR
50	2	P0001-06-005	BOLT, Hex 3/8 UNC x 1.25
51	1	P0302-921	CONTROL, Flow
52	2	P0001-04-010	BOLT, Hex 1/4 UNC x 2.5
53	2	P0003-04-000	NUT, Hex 1/4 UNC
54	2	P0304-347	MOTOR (Includes item 54a)
54a	1	P0304-347B	KIT, Seal
55	4	P0031-08-007	SCREW, Socket Head Cap 1/2 UNC x 1.75
56*	1	061809A	GUARD, Lube Pump

* Refer to this section for parts information.

MOYNO PUMP ASSEMBLY, 061632A

EH2325 (SN F61600F)



ITEM	QTY	PART NO.	DESCRIPTION
0	1	061632A	MOYNO PUMP ASSEMBLY
2	1	P0304-142	BRACKET
3	2	P0402-008	NIPPLE, Close 2
4	2	P0302-208	VALVE, Ball 2 NPT
5	1	061629A	MANIFOLD, Suction
6	1	P0416-006	PLUG, Square 1-1/4
7	4	P0001-06-005	BOLT, Hex 3/8 UNC x 1-1/4
8	4	P0040-006	WASHER, Hardened Flat 3/8
9	1	061624A	BASE, Pump
10	6	P0001-08-007	BOLT, Hex 1/2 UNC x 1.75
11	6	P0040-008	WASHER, Hardened Flat 1/2
12	1	061620A	MANIFOLD, Discharge
13	2	P0258-109	ADAPTER, 1 Barbed x MNPT
14	2	P0300-013	FITTING, 16MP-16MP
15	2	P0302-864	VALVE, Ball 1 1000 psi
16	4	P0300-057	FITTING, 16MP-16FP90
17	2	P0100-023	CAM LOCK, 1 BRASS
18	2	P0100-024	PLUG, FPT 1
19	1	P0302-207	VALVE, Ball 1-1/2 NPT
20	2	P0402-007	NIPPLE, Close 1-1/2
21	1	P0413-012A	BUSHING, Reducer 2 x 1-1/2


(Continued on next page)

MOYNO PUMP ASSEMBLY, 061632A
EH2325 (SN FA61600F)

ITEM	QTY	PART NO.	DESCRIPTION
22	1	P0100-021	SOCKET, FPT 2
23	1	P0100-027	PLUG Dust
24	1	P0258-075	PLUG, 1 NPT
25	2	P0258-039	HOSE BARB, 2 Male NPT
26	1	P0258-114	ELBOW, Street 2 90°
27	1	P0258-090	ADAPTER, 1-1/2 x 1-1/2
28	1	P0426-030B	GASKET, Flange 3
29	4	P0001-10-006	BOLT, Hex 5/8 UNC a 1.5
30	4	P0040-010	WASHER, Hardened Flat 5/8
31	1	P0302-349	VALVE, Pressure Relief
32	1	P0300-064	FITTING, 12MJ-12MP90
33	2	P0300-063	FITTING, 12MJ-12MP
34	1	P0300-100	FITTING, 12FP-12FPX90
35	1	A09874A-042	HOSE ASSEMBLY, 3/4 x 42


* Refer to this section for parts information.

AGITATOR FRAME ASSEMBLY, 061655A
EH2325 (SN FA61600F)




ITEM	QTY	PART NO.	DESCRIPTION
0	1	061655A	AGITATOR FRAME ASSEMBLY
1	1	A48424A	MOUNT, Agitator
2	1	A08330A	FRAME, Agitator
3	1	P0258-066	COUPLING, Reducing 8 x 4
4	1	A48477P	TUBE, PVC Bentonite Mix
5	1	P0258-067	COUPLING, Reducing 4 x 3
6	1	A48478P	TUBE, PVC Agitator Mix
7	1	P0001-04-003	BOLT, Hex 1/4 UNC x .75
8	5	P0013-04-000	NUT, Nyloc 1/4
9	8	P0040-008	WASHER, Hardened Flat 1/2
10	4	P0001-08-005	SCREW, Hex Cap 1/2 UNC x 1.25
11	2	P0001-08-012	BOLT, Hex 1/2 UNC x 3
12	2	P0013-08A-000	NUT, Nyloc 1/2
13	4	P0020-14-205	SCREW, Truss Head Machine 1

LUBE PUMP GUARD, 061809A
EH2325 (SN FA61600F)




ITEM	QTY	PART NO.	DESCRIPTION
0	1	061809A	LUBE PUMP GUARD
1	4	P0001-04-004	BOLT, Hex 1/4 UNC x 1
2	6	P0040-004	WASHER, Flat Narrow 1/4 UNC
3	2	P0001-04-003	BOLT, Hex 1/4 UNC x .75

BENTONITE VALVE ASSEMBLY, 061795A
EH2325 (SN FA61600F)




ITEM	QTY	PART NO.	DESCRIPTION
0	1	061795A	BENTONITE VALVE ASSEMBLY 1" x 10'
1	1	A09986A-124	HOSE ASSEMBLY, 1 X 124
2	1	P0302-864	VALVE, Ball 1000 psi
3	1	P0100-023	CAM LOCK 1
4	1	P0100-024	PLUG, FPT 1
5	1	P0300-013	FITTING, 16MP-16MP
6	1	P0400-005	COUPLING, Pipe 1

CAMLOCK REDUCER ASSEMBLY, 061815A
EH2325 (SN FA61600F)



ITEM	QTY	PART NO.	DESCRIPTION
0	1	061815A	CAM LOCK REDUCER ASSEMBLY
1	1	P0100-022	PLUG, FPT 2
2	1	P0413-010	BUSHING, Hex 2 x 1
3	1	A10340A-025	HOSE ASSEMBLY, 1 x 25
4	1	P0400-005	COUPLING, Pipe 1
5	1	P0100-023	CAM LOCK 1


OPERATOR CONTROLS
EH2325 (SN FA61600F)



ITEM	QTY	PART NO.	DESCRIPTION
1	3	P0301-142	GAUGE, 5000 PSI
2	2	P0302-801	VALVE, Mixer Control
3	1	P0301-105	GAUGE, Filter Indicator
4	1	P0251-1009	HOURMETER
5	1	P0310-412F	PUSHBUTTON, Illuminated
6	1	P0310-411F	PUSHBUTTON, Illuminated
7	1	P0251-482	SWITCH, Disconnect
8	1	P0302-207	VALVE, Ball 1-1/2
9	2	P0302-864	VALVE, Ball 1
10	2	P0302-208	VALVE, Ball 2
11	1	P0302-921	CONTROL, Flow
12	1	P0301-110	GAUGE, 600 psi
13	3	P0302-803	VALVE

NOTES

MOYNO PUMP, P0303-183



MOYNO PUMP, P0303-183

ITEM	QTY	PART NO.	DESCRIPTION
0	1	P0303-183	PUMP
1*	1	P0303-183I	SEAL
2	1	P0303-183G	PLATE, Bearing Cover
3*	1	-	NUT, Bearing Lock
4*	1	-	WASHER, Bearing Lock
5*	1	-	BEARING, Ball
6*	1	-	BEARING, Spacer
7*	1	-	BEARING, Ball
8	1	P0303-196	SHAFT, Drive
9*	1	P0303-183H	SEAL, Grease
10**	2	P0303-183D	SCREW, Pin Retaining
11**	2	P0303-183E	WASHER, Pin Retaining
12**	1	P0303-183C	PIN, Shaft
13	2	P0303-202	SET, Packing
14	2	P0303-183B	RING, Half
15	1	P0303-203	WASHER, Packing
16**	2	P0303-183K	WASHER, Connecting
17**	1	-	ROD, Connecting
18	1	P0303-200	PIN, Retainer
19**	1	P0303-201	PIN, Rotor
20	1	P0303-205	ROTOR
21	1	P0303-204	STATOR
22	1	P0303-225	REDUCER
23	1	P0303-183J	SUPPORT, Pump, W/Cap

NOTE:

* Bearing Kit, P0303-221 includes items 1, 3, 4, 5, 6, 7, and 9

**Pump Kit, P0303-195 includes items 10, 11, 12, 16, 17, and 19

NOTES

Alphabetical Index

A

After each drive 9-5, 9-13
Agitator frame assembly 16-20
Air monitoring 6-1
Annually 9-5, 9-14

B

Bearing grease, electric motor 8-1
Bentonite flow control 4-1, 6-2
Bentonite injection 6-2
Bentonite moyno assembly 16-16
Bentonite pump discharge pressure 4-1
Bentonite valve assembly 16-22

C

Camlock reducer assembly 16-23
Capacity, hydraulic oil tank 4-4, 8-1, 9-7
Chart, torque 12-2
Check hydraulic return filter indicator 9-7
Check hydraulic tank oil level 9-7
Checklist 5-1
Checklist, inspection 5-1
Chemical exposure 1-3, 6-14
Clean and inspect equipment 1-5
Cleaning tanks 6-14
Clean motor cooling fins 9-10
Clogging 6-14
Clothing, protective 1-1
Cold weather operation 6-1, 6-17
Cold weather protection 6-18
Combustible gas detectors 6-1
Conductive geology 6-2
Confined space permit 5-1
Contact with mixer shaft & propeller 1-2
Contents iii
Contents, parts 16-1
Control, bentonite flow 4-1, 6-2
Control panel 4-4
Control panel - EH2325, terminology 3-2
Control, pump 4-1
Controls & instruments 4-1
Controls, in-tank mixer 4-2
Controls, mixer speed 4-2
Controls, operator 16-24
Controls, tank mixer 4-2
Controls, tank mixer speed 4-2
Crushing hazard 1-4

D

Daily inspection 5-1
Daily or every 10 hours of operation 9-2, 9-6
Daily shutdown 6-1, 6-8
Decals 2-1
Decals, EH2325 lube pump - left view 16-6
Decals, EH2325 lube pump - right view 16-4

D (continued)

Decals, inspect 9-8
Decals, safety 2-1
Detectors, oxygen deficiency 5-1, 6-1
Detectors, ventilation 6-1
Discharge outlet hose connection 6-3
Discharge outlet plug 6-14, 6-15, 6-18
Discharge outlet shutoff valve 4-3, 6-9
Discharge pressure gauge 6-8
Discharge shutoff valve 6-13, 6-14,
..... 6-15, 6-18, 6-19
Disconnect switch, main power 4-4, 6-5
Drain cap 6-15, 6-18
Drain & fill hydraulic tank 9-12
Dry run or operate pump 4-1

E

EH2325 lubrication pump assembly 16-8
EH2325 lubrication pump decals - left view .. 16-6
EH2325 lubrication pump decals - right view 16-4
EH2325 lubrication pump terminology 3-1
Electrical assembly 16-13, 16-14
Electrical connections, inspect 1-3
Electrical motor rotation 6-1
Electric motor bearing grease 8-1
Electric motor mounting bolts 9-11
Electric motor, set up 6-4
Electric motor, shutting down 6-5
Electric motor, starting 6-5
Engineering project data requirements 6-2
Errors 16-2
Escaping oil 1-2
E-stop buttons 1-8
Every 500 hours of operation 9-4, 9-12
Exposure to chemicals 1-3, 6-14

F

Filter indicator 4-4, 9-7
Filter indicator, hydraulic return 4-4
Fire extinguisher 1-4, 6-1
Fire prevention 1-4
Flow control 6-13
Flow control, bentonite 4-1, 6-2
Fluid under pressure, hydraulic 1-2, 9-1
Flush & clean water/solution tanks 9-13
Flush tanks 6-19
Flush water/solution tanks 9-8
Foreign objects 6-1
Frame lifting 7-1
Freezing temperatures 6-17

G

Gas detectors, combustible 6-1
Gauge, pump psi 4-1
Gauge, tank mixer psi 4-2

G (continued)

Genuine parts i, 16-2
 Geology, conductive 6-2
 Geology, nonconductive 6-2
 Geology of project 6-2
 Grease, electric motor bearing 8-1
 Grease, polyrex em 8-1
 Grease type 8-1, 9-14
 Green start light 4-4
 Guideline, lockout tagout procedure 1-8
 Guidelines, lubrication 6-2
 Guidelines, operating 6-1
 Guidelines, transporting 7-1

H

Hardware specification 16-2
 Hazard, crushing 1-4
 High quality lubricants 8-1
 Hopper 6-15
 Hourmeter 4-4
 Hydraulic assembly 16-10
 Hydraulic fluids under pressure 1-2
 Hydraulic fluid under pressure 9-1
 Hydraulic oil, recommended 4-4
 Hydraulic oil tank capacity 4-4, 8-1, 9-7
 Hydraulic oil tank level 6-6
 Hydraulic oil under pressure 1-2, 9-1
 Hydraulic return filter indicator 4-4
 Hydraulics are running hot 11-2
 Hydraulic tank 4-4, 8-1
 Hydraulic tank 9-12
 Hydraulic tank oil 8-1
 Hydraulic tank oil level 9-7
 Hydraulic tank sight gauge 4-4

I

Identification numbers 13-1
 Indicator, hydraulic return filter 4-4
 Inferior lubricants 8-1
 Inspect and clean equipment 1-5
 Inspect & clean oil cooler fins 9-10
 Inspect covers & guards 9-6
 Inspect decals 9-8
 Inspection, checklist 5-1
 Inspection, daily 5-1
 Inspection, pre-start 5-1
 Inspect motor mounts 9-11
 Inspect outlet tubes & hoses 9-8
 Inspect pump motor mounts 9-11
 Inspect pump mounting bolts 9-11
 Inspect valves and levers 9-6
 Inspect water/solution tanks 9-8
 Inspect wiring & cables 9-6
 Instructions, lifting 7-1
 Instruments & controls 4-1
 In-tank mixer controls 4-2

I (continued)

Intervals of maintenance 9-1
 Introduction i
 Introduction, parts 16-2

J

Job site clean and organized 1-6

K

Keep all decals clean and readable 2-1
 Keep personnel away from moving parts 1-4

L

Lifting, frame 7-1
 Lifting instructions 7-1
 Locating parts 16-2
 Lockout tagout 1-8, 6-4, 6-5, 6-6, 6-9, 6-19
 Lockout tagout EH2325 control panel box 1-8
 Lockout tagout power 1-3, 6-1, 9-1
 Lockout/tagout procedure 1-8, 5-1
 Lockout tagout procedure guideline 1-8
 Lockout tagout EH2325 control panel option ... 1-9
 Lockout tagout the power source 1-8
 Lube pump guard 16-21
 Lubricants 8-1
 Lubricants, high quality 8-1
 Lubricants, inferior 8-1
 Lubricants, storing 8-2
 Lubricate motor bearings 9-14
 Lubricating pipe line 4-1
 Lubrication guidelines 6-2
 Lubrication pump assembly, EH2325 16-8
 Lubrication pump is pulsating 11-1
 Lubrication pump, set up 6-3
 Lubrication pump set up, microtunneling 6-3
 Lubrication pump set up, tbm 6-3

M

Main power disconnect switch 4-4, 6-5, 6-7, 6-9
 Maintenance charts 9-2
 after each drive 9-5
 annually 9-5
 daily or every 10 hours of operation 9-2
 every 500 hours of operation 9-4
 monthly or every 250 hours of operation . 9-4
 weekly or every 50 hours of operation ... 9-3
 Maintenance detail,
 after each drive 9-13
 annually 9-14
 daily or every 10 hours of operation 9-6
 every 500 hours of operation 9-12
 monthly or every 250 hours of operation ..9-11
 weekly or every 50 hours of operation ... 9-10
 Maintenance intervals 9-1
 Maintenance, periodic 9-1

M (continued)

Maintenance, practice safe 1-5
 Maintenance, pump 9-9
 Measurements 16-2
 Medical help 1-2
 Microtunneling lubrication pump set up 6-3
 Mixer controls 6-11
 Mixer controls, in-tank 4-2
 Mixer controls, tank 4-2
 Mixer not functioning 11-2
 Mixer off 4-2
 Mixer on 4-2
 Mixer psi gauge, tank 4-2
 Mixer speed control 6-11
 Mixer speed controls 4-2, 6-8
 Mixer speed controls, tank 4-2
 Mixing chemicals 6-14
 Mixing polymers 6-10
 Mixing tanks 6-10
 Modifications, unauthorized 1-1
 Monitoring, air 6-1
 Monthly or every 250 hours of operation 9-4,9-11
 Motor bearing grease, electric 8-1
 Motor bearings, lubricate 9-14
 Motor does not start 11-1
 Motor rotation, electrical 6-1
 Motor, shutting down electric 6-5
 Motor, starting electric 6-5
 Moyno pump 16-26
 Moyno pump assembly 16-18
 MSHA 5-1

N

Nameplate ambient temperature 8-1, 9-14
 Nonconductive geology 6-2
 No water discharge out of pump 11-1
 Numbers, identification 13-1
 Numbers, serial 13-1

O

Oil cooler fins 1-4
 Oil cooler fins 9-10
 Oil, hydraulic tank 8-1
 Oil level gauge 9-12
 Oil, recommended hydraulic 4-4
 Oil tank capacity, hydraulic 4-4, 8-1, 9-7
 Oil under pressure, hydraulic 9-1
 Operating guidelines 6-1
 Operation 6-1
 Operation, cold weather 6-1, 6-17
 Operator controls 16-24
 Operator's manual, read 1-1
 OSHA 5-1
 OSHA approved protective clothing 1-1
 OSHA prescribed safety equipment 1-8
 Outlet shutoff valve 4-3

O (continued)

Outlet shutoff valve, discharge 4-3
 Outlets, tank supply 4-3
 Oxygen deficiency detectors 5-1
 Oxygen deficient detectors 6-1

P

Panel, control 4-4
 Parts 16-1
 Parts contents 16-1
 Parts, genuine 16-2
 Parts introduction 16-2
 Parts ordering 16-2
 Periodic maintenance 9-1
 Personal protective equipment.. 1-1,1-3,5-1,6-10,6-14
 Pinch points 1-4, 9-1
 Pipe line, lubricating 4-1, 6-2
 Polymers, mixing 6-10
 Polymer supplier 6-2
 Polyrex em grease 8-1
 Power disconnect switch, main 4-4, 6-5
 Power requirements, recommended 6-4
 PPE 1-1, 1-3, 5-1, 6-10, 6-14
 Practice safe maintenance 1-5
 Preparing for storage 10-1
 Pressure, bentonite pump discharge 4-1
 Pre-start inspection 5-1
 Prevent component damage 6-18
 Procedure guideline, lockout tagout 1-8
 Project data requirements, engineering 6-2
 Propeller, contact with mixer shaft & 1-2
 Protection, cold weather 6-18
 Protective clothing 1-1
 Psi gauge, tank mixer 4-2
 Pump cannot reach max pressure 11-1
 Pump control 4-1, 6-7, 6-8, 6-11, 6-15, 6-19
 Pump discharge pressure, bentonite 4-1
 Pump maintenance 9-9
 Pump mounting bolts 9-11
 Pump mounting plate bolts 9-11
 Pump, moyno 16-26
 Pump psi gauge 4-1

R

Recirculating manifold plug 6-14, 6-15, 6-18
 Recirculation, tank 6-2
 Recirculation valves 4-3,6-12,6-14,6-15,6-18
 Recommended hydraulic oil 4-4
 Recommended power requirements: 6-4
 Recycle waste 1-6
 Red stop light 4-4
 Release pressure 9-1
 Removing from storage 10-2
 Return filter housing 4-4
 Return filter indicator, hydraulic 4-4
 Rv anti-freeze 6-19, 9-13
 Rv anti-freeze solution 6-15, 6-17, 6-18

S

Safe maintenance, practice 1-5
 Safety 1-1
 Safety data sheets 14-1
 Safety decals 2-1
 Safety equipment, OSHA prescribed 1-8
 Safety information 1-1
 Safety instructions 2-1
 Safety program i, 5-1
 Safety regulations 1-8
 Safety signal words i
 Serial numbers 13-1
 Setting up lubrication pump 6-3
 Setting up the electric motor 6-4
 Shutdown, daily 6-8
 Shutoff valve, discharge outlet 4-3
 Shutting down electric motor 6-5
 Sight gauge, hydraulic tank 4-4
 Signal words, safety i
 Slippery when wet 1-6
 Specification, hardware 16-2
 Specifications 12-1
 Specifications, eh2325 lubrication pump 12-1
 Speed controls, tank mixer 4-2
 Start button 4-4, 6-7
 Starting electric motor 6-5
 Starting pump, before 4-1
 Start up procedure 6-6
 Stop button 4-4, 6-9
 Storage 10-1
 Storage, preparing for 10-1
 Storage, removing from 10-2
 Storing lubricants 8-2
 Structural failure 6-1
 Suction manifold drain plug 6-14, 6-15, 6-18
 Suction valve 6-12, 6-15
 Suction valves, tank 4-3
 Supplier, polymer 6-2
 Supply outlets, tank 4-3
 Suspended loads 1-2
 Switch, main power disconnect 4-4, 6-5

T

Tank capacity, hydraulic oil 4-4, 8-1, 9-7
 Tank covers 6-15, 6-19
 Tank drains 6-19
 Tank fumes 6-14
 Tank, hydraulic 4-4, 8-1
 Tank mixer controls 4-2, 6-8
 Tank mixer psi gauge 4-2
 Tank mixer speed controls 4-2
 Tank oil, hydraulic 8-1
 Tank recirculation 6-2
 Tanks, cleaning 6-14
 Tanks, flush 6-19
 Tanks, mixing 6-10

T (continued)

Tank suction valve 6-10
 Tank suction valves 4-3,6-1,6-8,6-14,6-15,6-18
 Tank supply outlets 4-3
 Tbm lubrication pump set up 6-3
 Terminology 3-1
 Terminology, control panel - EH2325 3-2
 Terminology, EH2325 lubrication pump 3-1
 Torque chart 12-2
 Transporting guidelines 7-1
 Troubleshooting 11-1
 hydraulics are running hot 11-2
 lubrication pump is pulsating 11-1
 mixer not functioning 11-2
 motor does not start 11-1
 no water discharge out of pump 11-1
 pump cannot reach max pressure 11-1

U

Unauthorized modifications 1-1
 Unauthorized welding 1-5
 Using recirculation valves to transfer fluid 6-12

V

Valve, discharge outlet shutoff 4-3
 Valves, recirculation 4-3
 Valves, tank suction 4-3
 Ventilation detectors 6-1

W

Warranty 15-1
 Waste, recycle 1-6
 Water level 6-18
 Weather operation, cold 6-17
 Weather protection, cold 6-18
 Weekly or every 50 hours of operation 9-3,9-10
 Welding, unauthorized 1-5

Numerical Index

PART NO.	PAGE NO.	PART NO.	PAGE NO.	PART NO.	PAGE NO.
1250-004	16-5	1252-182C	16-6	A09874A-042	16-19
1250-069	16-5	1252-183A	16-6	A09875A-035	16-12
1250-069	16-7	1252-183B	16-7	A09876A-016	16-12
1250-089	16-5	1252-183C	16-6	A09876A-032	16-12
1250-089	16-7	1252-184	16-4	A09877A-024	16-12
1250-090	16-5	1252-184	16-6	A09877A-039	16-12
1250-311	16-4	1252-186	16-5	A09877A-040	16-12
1250-311	16-7	1252-187	16-5	A09877A-063	16-12
1250-314	16-5	1252-188	16-6	A09877A-064	16-12
1250-383	16-6	1252-189	16-6	A09881A-019	16-11
1250-385	16-6	1252-190	16-5	A09881A-022	16-12
1250-483	16-5	1252-191	16-7	A09986A-124	16-22
1250-544	16-6	1252-192	16-6	A09988A-030	16-12
1250-558	16-4	1252-193	16-4	A10059A-018	16-12
1250-558	16-7	1255-115	16-4	A10324A-032	16-12
1250-638	16-4	1255-115	16-8	A10324A-042	16-12
1250-638	16-7	3-700L	16-5	A10324A-071	16-12
1251-018	16-4	3-700R	16-7	A10340A-025	16-23
1251-018	16-6	40000-16	16-5	A10342A-043	16-12
1251-218	16-4	061620A	16-18	A10359A-030	16-12
1251-221	16-4	061624A	16-18	A10359A-034	16-12
1251-221	16-7	061626P	16-8	A10359A-036	16-12
1251-245	16-5	061627P	16-17	A10374A-026	16-12
1251-246	16-5	061628P	16-17	A45054A	16-17
1251-246	16-7	061629A	16-18	A45057A	16-17
1251-286B	16-5	061632A	16-17	A45170P	16-17
1251-286C	16-5	061632A	16-18	A48401P	16-17
1251-286E	16-5	061633A	16-8	A48411P	16-17
1251-286F	16-4	061633A	16-17	A48424A	16-20
1251-288	16-5	061635A	16-8	A48477P	16-20
1251-677	16-4	061635A	16-11	A48478P	16-20
1251-677	16-6	061655A	16-17	A48479P	16-17
1251-678	16-5	061655A	16-20	A48823A	16-17
1251-678	16-7	061795A	16-8	A48824A	16-17
1251-749	16-7	061795A	16-22	A49113A	16-13
1251-813	16-5	061809A	16-17	A49113A	16-14
1251-813	16-7	061809A	16-21	A61141A	16-17
1251-972	16-4	061815A	16-8	A62193A	16-13
1252-062	16-6	061815A	16-23	A62194A	16-8
1252-180	16-5	A08330A	16-20	A62194A	16-13
1252-180	16-7	A09832A-026	16-12	F61600F	16-8
1252-181A	16-7	A09853A-078	16-11	P0001-04-002	16-8
1252-181B	16-7	A09864A-064	16-11	P0001-04-003	16-11
1252-181C	16-6	A09870A-028	16-12	P0001-04-003	16-20
1252-182A	16-6	A09873A-034	16-11	P0001-04-003	16-21
1252-182B	16-6	A09873A-073	16-12	P0001-04-004	16-21

Numerical Index

PART NO.	PAGE NO.	PART NO.	PAGE NO.	PART NO.	PAGE NO.
P0001-04-009.....	16-11	P0040-008.....	16-17	P0251-845.....	16-14
P0001-04-010.....	16-17	P0040-008.....	16-18	P0251-906.....	16-15
P0001-05-004.....	16-11	P0040-008.....	16-20	P0258-039.....	16-17
P0001-05-008.....	16-13	P0040-010.....	16-11	P0258-039.....	16-19
P0001-06-002.....	16-17	P0040-010.....	16-19	P0258-066.....	16-20
P0001-06-004.....	16-13	P0040-016.....	16-11	P0258-067.....	16-20
P0001-06-004.....	16-17	P0047-003-1.75.....	16-17	P0258-075.....	16-17
P0001-06-005.....	16-17	P0054-013.....	16-15	P0258-075.....	16-19
P0001-06-005.....	16-18	P0054-018.....	16-15	P0258-090.....	16-19
P0001-08-005.....	16-13	P0054-030.....	16-15	P0258-108.....	16-17
P0001-08-005.....	16-17	P0054-596B.....	16-15	P0258-109.....	16-17
P0001-08-005.....	16-20	P0055-157.....	16-15	P0258-109.....	16-18
P0001-08-007.....	16-17	P0055-174.....	16-15	P0258-110.....	16-17
P0001-08-007.....	16-18	P0055-245.....	16-15	P0258-112.....	16-17
P0001-08-008.....	16-13	P0056-121F.....	16-15	P0258-113.....	16-17
P0001-08-009.....	16-17	P0056-122F.....	16-14	P0258-114.....	16-17
P0001-08-012.....	16-17	P0063-016.....	16-12	P0258-114.....	16-19
P0001-08-012.....	16-20	P0093-039.....	16-11	P0258-115.....	16-17
P0001-10-006.....	16-19	P0093-040A.....	16-11	P0300-013.....	16-18
P0001-10-007.....	16-11	P0095-133.....	16-17	P0300-013.....	16-22
P0003-03-000.....	16-12	P0100-021.....	16-19	P0300-057.....	16-18
P0003-04-000.....	16-11	P0100-022.....	16-23	P0300-060.....	16-12
P0003-04-000.....	16-17	P0100-023.....	16-18	P0300-063.....	16-19
P0003-05-000.....	16-11	P0100-023.....	16-22	P0300-064.....	16-19
P0003-06-000.....	16-17	P0100-023.....	16-23	P0300-100.....	16-19
P0003-08-000.....	16-17	P0100-024.....	16-18	P0300-120.....	16-11
P0013-04-000.....	16-17	P0100-024.....	16-22	P0300-193.....	16-11
P0013-04-000.....	16-20	P0100-027.....	16-19	P0300-275.....	16-12
P0013-05-000.....	16-13	P0125-139.....	16-11	P0300-302.....	16-11
P0013-08A-000.....	16-13	P0125-139A.....	16-11	P0300-305.....	16-11
P0013-08A-000.....	16-17	P0125-139B.....	16-11	P0300-319.....	16-12
P0013-08A-000.....	16-20	P0126-038.....	16-11	P0300-325.....	16-11
P0013-10-000.....	16-11	P0201-159-016.....	16-17	P0300-328.....	16-12
P0017-06-323.....	16-15	P0201-159-038.....	16-17	P0300-332.....	16-11
P0017-06-750.....	16-12	P0201-183.....	16-17	P0300-371.....	16-12
P0020-14-205.....	16-17	P0201-205.....	16-17	P0300-373.....	16-11
P0020-14-205.....	16-20	P0201-238-050.....	16-17	P0300-374.....	16-12
P0020-83-022.....	16-14	P0201-238-062.....	16-17	P0300-383.....	16-11
P0031-08-007.....	16-17	P0251-1009.....	16-14	P0300-385.....	16-11
P0032-002.....	16-17	P0251-1009.....	16-24	P0300-423.....	16-11
P0040-004.....	16-8	P0251-399.....	16-14	P0300-450.....	16-12
P0040-004.....	16-11	P0251-447.....	16-13	P0300-536.....	16-11
P0040-004.....	16-17	P0251-482.....	16-14	P0300-537.....	16-12
P0040-004.....	16-21	P0251-482.....	16-24	P0300-542.....	16-11
P0040-005.....	16-11	P0251-563.....	16-14	P0300-551.....	16-11
P0040-006.....	16-13	P0251-616.....	16-14	P0300-562.....	16-12
P0040-006.....	16-17	P0251-842.....	16-14	P0300-580.....	16-12
P0040-006.....	16-18	P0251-843.....	16-14	P0300-594.....	16-11
P0040-008.....	16-13	P0251-844.....	16-14	P0300-620.....	16-11

Numerical Index

PART NO.	PAGE NO.	PART NO.	PAGE NO.
P0300-658	16-12	P0303-225	16-27
P0300-667	16-11	P0303-890	16-13
P0300-688	16-11	P0304-142	16-18
P0300-717	16-11	P0304-347	16-17
P0300-788	16-11	P0304-347B	16-17
P0300-886	16-11	P0304-376	16-17
P0300-890	16-12	P0305-112D	16-13
P0300-892	16-11	P0305-132A	16-17
P0300-903	16-11	P0305-132B	16-17
P0300-969	16-12	P0305-182	16-17
P0301-105	16-11	P0305-201	16-13
P0301-105	16-24	P0305-225	16-13
P0301-110	16-12	P0305-252	16-13
P0301-110	16-24	P0309-144B	16-11
P0301-142	16-11	P0309-145A	16-11
P0301-142	16-24	P0310-411F	16-15
P0302-207	16-18	P0310-411F	16-24
P0302-207	16-24	P0310-412F	16-14
P0302-208	16-18	P0310-412F	16-24
P0302-208	16-24	P0310-419F	16-14
P0302-254	16-11	P0310-432	16-15
P0302-254A	16-11	P0310-433	16-15
P0302-349	16-19	P0310-471A	16-14
P0302-801	16-11	P0310-472	16-14
P0302-801	16-24	P0310-473B	16-14
P0302-803	16-11	P0310-499	16-14
P0302-803	16-24	P0310-503-005	16-14
P0302-864	16-18	P0310-503-012	16-14
P0302-864	16-22	P0310-571	16-14
P0302-864	16-24	P0311-018	16-15
P0302-921	16-17	P0311-019	16-15
P0302-921	16-24	P0311-032	16-15
P0303-183	16-27	P0311-033	16-15
P0303-183B	16-27	P0311-075	16-15
P0303-183C	16-27	P0311-121	16-15
P0303-183D	16-27	P0400-005	16-22
P0303-183E	16-27	P0400-005	16-23
P0303-183G	16-27	P0402-007	16-18
P0303-183H	16-27	P0402-008	16-18
P0303-183I	16-27	P0413-010	16-23
P0303-183J	16-27	P0413-012A	16-18
P0303-183K	16-27	P0416-006	16-18
P0303-196	16-27	P0426-030B	16-19
P0303-200	16-27	PM6A-16-1.00	16-11
P0303-201	16-27		
P0303-202	16-27		
P0303-203	16-27		
P0303-204	16-27		
P0303-205	16-27		

NOTES